



AC SERVO MOTOR and SERVO AMPLIFIER Series S-FLAG

S-FLAG II Instruction Manual

- EtherCAT -

Thank you for your purchase of the S-FLAG II products. This Instruction Manual includes precautions for the product use.

- Please study this manual first and use the product properly and safely.
- Before using the product, be sure to carefully read the "Before Using".
- After reading this Instruction Manual, always keep it handy for easy access.
- The specifications or features of the product may change without notice because of further development of the product.
- We prepared the contents of this Instruction Manual with extreme care. Please do not hesitate to contact us if you have any questions.
- We always strive to have up-to-date information in the Instruction Manual; therefore, it is subject to change without prior notice.
- The illustrations and screenshot images of S-TUNE II included in this document may be different from the actual S-TUNE II views.
- No reproduction in any form of this Instruction Manual, in whole or in part, may be made without written authorization from Nidec Sankyo Corporation.

DEC. 2019



Trademarks and Patents

EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany. Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

Inquiries

If you have any questions about this product, please contact our distributor.

Please ask our distributor for the latest exclusive software (S-TUNEII) and user's manual.

Manufactured and Distributed by

NIDEC SANKYO CORPORATION

Tokyo Office

Nidec Tokyo bldg., south bldg., 1-20-13, Osaki, Shinagawa-ku, Tokyo 141-0032, Japan

Tel:81-3-5740-3006 Fax:81-3-6843-3123

NIDEC SANKYO ELECTRONICS (SHENZHEN) CORPORATION

No.38 Shangtang Road, Shilong, Dongguan, Guangdong Province 523325, P.R. China

TEL: (86) 769-8611-4520 FAX: (86) 769-8611-6590

NIDEC SANKYO ELECTRONICS (SHANGHAI) CORPORATION

12F, Tower B, 100 Zunyi Road, Shanghai, 200051 P.R China

TEL: (86) 21-5275-3290 FAX: (86) 21-5276-9119

A GENERAL

This chapter describes safety precautions.

1. Before Using

B HARDWARE

This chapter describes the specifications and installation of the motor and amplifier, and wiring of the system and I/O connector.

1. Specifications
2. Mounting and Wiring

C PARAMETER

This chapter describes parameters and tuning methods.

1. Setup Panel
2. Parameter
3. Tuning

D SOFTWARE

This chapter describes how to use "S-TUNE II".



1. About S-TUNE II
2. Operations

E

COMMUNICATIONS



This chapter describes EtherCAT communications.

1. System Overview
2. Communication Specification
3. Object Dictionary
4. Errors related to EtherCAT
5. EtherCAT Communication Monitor

F

OPERATION



This chapter explains how to drive the motor by EtherCAT communication.

1. Operation
 - Position Control Mode (CSP)
 - Velocity Control Mode (CSV)
 - Torque Control Mode (CST)
 - Homing Mode (HM)
2. Connecting to the Master Controller
 - Use Beckhoff's "TwinCAT"
3. Timing diagrams

Z

APPENDICES

This chapter describes troubleshooting and maintenance when an alarm occurs.

1. Troubleshooting
2. Technical Information
 - Absolute System
 - Function
 - Amplifier Circuit System Block Diagram
 - Status Display

[illegible]

A

GENERAL

1. Before Using



Before Using

1. Important Safety Instructions	2
1. Safety Precautions	2
2. Other Considerations and Precautions	7
3. Safety Standards	8
4. Maintenance and Inspection	9
5. Warranty	10
2. About Our Products	11
1. Product Label	12
2. Danger Signs	13



1. Important Safety Instructions

1. Safety Precautions







This manual uses the signs below to indicate serious but avoidable problems caused by misuse of the product. One is for death or serious bodily harm. The other is for bodily injury or product or equipment damage.

 DANGER	Identifies information about imminent hazards that will result in death or serious injury.
 CAUTION	Identifies information about hazards that could result in injury or equipment damage.









































Throughout this document, the safety precautions that users must follow are marked as follows.

	Safety Precaution - Prohibited Action
	Safety Precaution - Mandatory Action




















The possible hazardous events are marked as follows.

	<u>Cautions and Dangers</u> Causes unexpected, unstable, or uncontrolled motions. Compromises the performance or reliability of the product. Shortens the service life of the product.
	<u>Electric shock hazard</u>
	<u>Burn hazard</u>
	<u>Fire hazard</u>
	<u>Injury hazard</u>
	<u>Failure and damage hazard</u>


































1. Important Safety Instructions

 DANGER		
Sign	Precautionary Measures	If Not Observed
Installation and Wiring		
	Never connect the motor directly to a commercial power supply.	 
	Do not place any flammable items near the motor or amplifier.	
	Protect the amplifier with a protective case and ensure the clearance between the amplifier, the case and other devices as specified in this manual.	  
	Install the product in a place with little dust and free from water or oil splash.	  
	Mount the motors and amplifiers on metallic or other noncombustible materials.	
	All wiring work must be performed by certified electricians.	
	Ground the FG terminals of mother and amplifiers.	
	Turn off the upstream circuit breaker before wiring. Wiring must be performed correctly.	  
	Be sure with secure cable connections. The current-carrying components must be insulated.	  
Operations		
	Never touch the inside of the amplifier.	 
	Be careful not to damage the cables. Do not apply excessive force to them or place heavy objects on top of them. Do not let any part of cables become pinched or twisted.	 
	Never touch the rotating component of the motor during operation.	
	Do not use the product where it may be subjected to water, corrosive atmosphere, flammable gas, or combustible materials.	
	Do not use the product where excessive vibration or impact load is present.	  
	Do not use cables soaked in water or oil.	 
	Do not handle wiring nor operate the motor with wet hands.	  
	Do not touch the keyway if you are using a motor with a shaft-end keyway.	
	Do not touch the motor or amplifier heat sink. It becomes very hot.	 
	Do not use external power to run the motor.	




















1. Important Safety Instructions

 DANGER		
Sign	Precautionary Measures	If Not Observed
Additional Precautions		
	Be sure to confirm the safe condition of the equipment after each earthquake.	  
	To prevent a fire or personal injury during an earthquake, carry out installation work securely and properly.	   
	Install external emergency stop circuitry so that the operation can be stopped and the power supply can be shut down immediately in case of emergency.	   
Maintenance and Inspection		
	Never attempt to disassemble the product.	  
	There are hazardous voltage sections in the amplifier. Before performing any wiring or inspection, be sure to allow more than 15 minutes after the power shuts off for the internal voltage to completely discharge.	

1. Important Safety Instructions

 CAUTION		
Sign	Precautionary Measures	If Not Observed
Installation and Wiring		
	Do not directly touch the terminal portion of any connectors.	 
	Do not block the air vents. Do not allow ingress of any foreign objects to the product.	 
	Keep the motor-amplifier pairing as specified.	 
	Before a test run, confirm that the motor is fixed in place, check the motions while the motor is isolated from the machinery first, then install the motor in the machinery.	
	Observe the mounting method and orientation as specified.	 
	Install the product in an appropriate way suitable for its main body mass and the rated output of the product.	 
Operations		
	Do not step on the product or place any heavy object on it.	  
	Never make drastic changes during tuning, which if not observed, will result in unstable motions.	
	Do not come close to the machinery right after power restoration following a power outage. The machinery may restart unexpectedly at any moment. Take appropriate measures to ensure safety against an unexpected restart.	
	Do not use the product where it may be exposed to direct sunlight.	
	Do not apply impact load.	
	Never use the electromagnetic contactor installed on the main power supply-side to operate or stop the motor.	
	Do not use the built-in brake of the motor for regular braking purposes. It is a holding brake.	 
	Do not use faulty, damaged motors or amplifiers.	 
	Confirm that the power specifications are normal.	
	The holding brake is not a stopping device to secure the safety of the machine. The machine requires a separate stopping device to secure safety.	
	Upon occurrence of an alarm, remove the cause and ensure the safe condition of the equipment before resetting the alarm and restarting the machine.	
	Connect the brake control relay and the emergency stop relay in series.	 

1. Important Safety Instructions

 CAUTION		
Sign	Precautionary Measures	If Not Observed
Transportation and Storage		
	Do not store the product at a location subject to water or moisture, or where toxic gases or liquids are present.	
	Do not hold the cables or motor shafts during transportation.	 
	When transporting the amplifier and monitor, do not drop them or let them fall.	 
	When the product has been stored for an extended time, contact our customer service center.	
	Store the product in suitable storage environments as specified in the instruction manual.	
Additional Precautions		
	Prior to disposal of the batteries, insulate them with tape or other material. Dispose of them following the local laws and regulations.	
	When disposing of the S-FLAG II product, treat it as industrial waste.	
Maintenance and Inspection		
	Never attempt to overhaul the product.	
	Do not power cycle too frequently.	
	The motor, heat sink of the amplifier, and regenerative resistor may become dangerously hot. Do not touch any of them with hands when power is on or for a while after power shutdown.	 
	If the amplifier or motor fails, shut down both the control power supply and the main circuit power supply.	
	When not using the product for an extended period, be sure to turn the power off.	

1. Before Using

1. Important Safety Instructions

2. Other Considerations and Precautions

Export of this product or its applications

If the end user or applications of the product is involved in military activities or weapons, its export may be subject to "Foreign Exchange and Foreign Trade Law (Japan)" (or equivalent in your country).

Have adequate legal reviews and follow any required export procedures.

Follow the laws and regulations of the destination.

Use of the product – Not in human life related field

This product is designed and manufactured to be used for general industrial products.

Medical applications are not allowed.

Applications for special environments or purposes such as nuclear power, aerospace and transportation

Please contact us in advance of use.

Application that could cause serious accidents or damage due to product failure

Be sure to have safety device or protection device installed before using your equipment.

Applying voltage beyond the rated power range of this product

Doing so could become a fire or smoke hazard to the amplifier. Be sure to check and confirm proper wiring before turning the power on. Be particularly careful in a location such as a clean room.

Operations with the motor shaft not electrically grounded

Depending on the device or installation environment, bearing noise might be increased by galvanic corrosion of the motor bearings. Perform careful check on grounding.

Operations in environment under significant influence of external noise and static electricity

This product has been designed and manufactured to pass extensive noise tests. However, there is a possibility of unexpected behavior depending on user's environment.

Practice a fail-safe design and take adequate measures to ensure safety within the range of machine motion.

Use of the product in a manner not rated by the manufacture

Such use shall void the manufacture warranty. Be mindful before you attempt to do so.

1. Important Safety Instructions

3. Safety Standards



Rating		Motor	Amplifier
EU/EC Directives	Low Voltage Directive (*1)	EN60034-1 EN60034-5	EN61800-5-1
	EMC Directive (*2)	—	EN61000-6-2 EN55011 (Class A. Group1)
	Machinery Directive	(N/A)	
UL Standards (*1)		UL1004-1 UL1004-6 (File No.E470950)	UL61800-5-1 (File No.E471456)
CSA Standards		C22.2 No.100	C22.2 No.274
South Korea Radio Law (KC)		—	KN61000-6-2 KN11
China Compulsory Product Certification System (CCC)		(N/A)	

*1) Install the product in the environment that meets the following requirements:



- Overvoltage Category III
- Class I
- Pollution Degree 2 (Circuitry)

*2) The test conditions for the machinery and equipment with this product installed may be different from our test conditions.
Such machinery or equipment must meet the safety standards for their final configurations.

*3) The motor of "MX 951" is not UL compliant.

1. Important Safety Instructions

4. Maintenance and Inspection

	Never overhaul the product.
	For safe use of the product, be sure to perform regular maintenance and inspection on the amplifier and motor.
	Ensure the electrical and mechanical safety before each inspection.

This product assumes the following operating conditions.

Ambient Temperature	Average annual temperature of 30°C (not exceeding the rated temperature range)
Load Factor	80% max
Operating Hours	20 hours a day

Maintenance

For safe use of the product, perform daily and periodic inspections.

Daily Inspection: Check the following before each operation:

- Ambient temperature, humidity and atmosphere
- No foreign objects or dust; especially ensure that nothing is blocking the vent holes
- No excessive bending or damage of the wires
- Power supply voltage is within the specifications
- No foreign objects in mobile components of the device and the range of motion.
- No unusual noise or smell right after the machinery starts.

Periodic Inspection: Check the following at least once a year:

- No loose clamp screw problems in the amplifier and motor.
- No deformation or discoloration in the amplifier, motor, cables, and terminal blocks due to overheating.
- No looseness in wiring fixings and terminal block screws.

1. Important Safety Instructions

5. Warranty

Terms of Warranty

The term of warranty for this product is eighteen (18) months after the date of product manufacture. However, brake-equipped motors whose number of axis accelerations and decelerations exceeded the rated maximum shall not be covered by the warranty.

Conditions of Warranty

Should any failure develop during the warranty period under normal operations in accordance to the S-FLAG II instruction manual, Sankyo agrees to make repairs at free of charge. However, even during the warranty period, Sankyo will make only fee-based repair if the failure is due to the following reasons:

- Misuse, improper repair, or alteration of the product
- Product is dropped after purchase or damaged during transportation
- Use of this product is not within the product specifications
- Fire, earthquake, lightning, storm and flood damage, salt damage, abnormal voltage, or any other acts of God or natural disasters
- Ingress of foreign matter such as water, oil or metal chips.

This warranty does not apply to any parts or accessories that have been used longer than their rated service life.

The warranty applies to delivered products only. Sankyo shall not be liable for any indirect, incidental or consequential damage caused by the product failure or damage.

Misuse or mishandling of the product will not only result in its suboptimal performance, but also failure or shorter service life.

For safety and proper use of the product, please read the instruction manuals carefully.

About This Product and This Instruction Manual

- Product features and parts are subject to change without prior notice due to potential future product improvement initiatives.
- Please contact us in advance if you are to acquire safety standards certification etc. for equipment with this product installed.
- We have prepared the contents of this manual with extreme care. Please do not hesitate to contact us if you have any questions.
- Include the following precautions in the User Guide of your S-FLAG II application product:
 - This is a high-voltage product which can be hazardous.
 - Residual voltage exists at the terminals and inside the equipment (even after power shutoff), which is hazardous.
 - The product contains high temperature components.
 - It is prohibited to disassemble the product.
- For optimal service life of the S-FLAG II product, use of the product under proper conditions is essential. Follow the safety precautions and instructions described in this manual.
- We always strive to include up-to-date information in the instruction manual; therefore, it is subject to change without prior notice.
- For a copy of the latest version of the instruction manual, please contact us.
- Reproducing or copying this document, in whole or in part, without prior approval of Sankyo, is strictly prohibited.

Check Items Upon Unpacking

- Please compare the actual items received with your product purchase order.
- Inspect all items received for evidence of damage during transit.
- Should you have any problems, please contact our sales department.

2. About Our Products

1. Product Label

Motor Label

Label 1

Motor ModelSpecificationsAC SERVO MOTOR
MX401N2SN01INPUT 3 ϕ AC150V 2.7A
RATED OUTPUT 400 W
RATED REV. 3000 rpm**Nidec**

Label 2

SpecificationsProduct Number (Produced year and month + Serial No.)

A product number is indicated by 11 digits.

S/N: ** * *****
Year Month(*) Serial No.

RATED FREQ. 250 Hz

RATED TORQUE 1.27 N·m

IP 65 TE 40°C

INS. B

S/N *****



MADE IN CHINA

Amplifier Label

Amplifier ModelProduct Number (Produced year and month + Serial No.)

A product number is indicated by 11 digits.

S/N: ** * *****
Year Month(*) Serial No.Specifications

AC SERVO DRIVER

MODEL DB63841

S/N

RATED INPUT 1 ϕ AC200-240V 1.5kVA

50/60Hz

OUTPUT 3 ϕ 0-240V 0-500Hz 4.2A750
IP2XMISAP-REM.
805-0963841UL LISTED
IND. CONT. EQ.
AAAA

EtherCAT

Conformance tested

MADE IN CHINA

*) About indication of "the month".

"1" = Jan., ... "9" = Sep., "X" = Oct., "Y" = Nov., and "Z" = Dec.

2. Danger Signs

NO IMPACT/NO DISASSEMBLY LABEL



Do not remove the encoder cover. Never overhaul the encoder.
Beating the encoder cover will cause encoder failure.
Do not apply strong impact to the motor and its shaft.

HOT SURFACE WARNING



Do not touch the product during operation or for a while afterward, or you may get burned from the heat.

ELECTRIC SHOCK WARNING



Do not touch the amplifier during operation and within 15 minutes after operation, or you may get injured.

DANGER • CAUTION



Incorrect use of the amplifier may cause injury or damage. Avoid misuse or improper handling of the amplifier, or injury will result.

FG (FRAME GROUND/PROTECTIVE GROUNDING) SYMBOL



Be sure to perform grounding with the screw located at this sign.

MEMO

B

HARDWARE

1. Specifications

2. Mounting and Wiring

Specifications


1. Motors	2
1. Model Codes	2
Motors with a 23 bit Absolute Encoder	2
Motors with a 17 bit Absolute Encoder	3
Motors with a 17 bit Incremental Encoder	4
2. Names of parts	6
3. Specifications	7
23 bit	8
17 bit	31
2. Encoder	54
1. Specifications	54
3. Amplifiers	55
1. Model Codes	55
2. Names of parts	56
3. Specifications	58
4. External Dimensions	62
5. Overload Detection Feature	64

1. Specifications

1. Motors

1. Model Codes

Motors with a 23 bit Absolute Encoder




Inertia	Flange Size	Rotational Speed	Encoder Resolution	IP Code
Low Inertia	40 mm × 40 mm	Rated Motor Speed / Max. 1,500 r/min / 3,000 r/min	23 bit/rev	IP65
Middle Inertia	60 mm × 60 mm	2,000 r/min / 3,000 r/min	17 bit/rev	IP67
High Inertia	80 mm × 80 mm	3,000 r/min / 5,000 r/min		
	100 mm × 100 mm	3,000 r/min / 6,000 r/min		
	130 mm × 130 mm			


1. Specifications

1. Motor

Motors with a 17 bit Absolute Encoder



Motors with a 17 bit Incremental Encoder






















































1. Specifications

1. Motor

1
Specifications

1. Motor

Motor Rated Capacity	Motor Model Name			Mounting Flange Size	Encoder Resolution	Rotational Speed	IP	Amplifier	Page
	Rotor Inertia & Series								
	 Low Inertia	 Middle Inertia	 High Inertia						
	MX	MY MG MM MJ	MZ MH						
	—	MY500 MG500	—		 / 			DB6YZ41	p. 8- /p. 31-
	—	MY101 MG101	—		 / 			DB6Z141	p. 10- /p. 33-
	MX201	MG201	MZ201		 / 			DB61241	P. 12- /p. 35-
	MX401	MG401	MZ401		 / 			DB62441	p. 15- /p. 38-
	MX751	—	MZ751		 / 			DB63841	p. 18- /p. 41-
	—	MJ851	—		 / 	 15°		DB65B41	p. 20 /p. 43
	MX951	—	—		 / 			DB64A41	p. 21 /p. 44
	MX102	—	—		 / 			DB64A41	p. 22 /p. 45
	—	MM102	MH102		 / 	 20°		DB64A41	p. 23- /p. 46-
	—	MJ132	—		 / 	 15°		DB67C41	p. 25 /p. 48
	MX152	—	—		 / 			DB66B41	p. 26 /p. 49
	—	MM152	MH152		 / 	 20°		DB66B41	p. 27- /p. 50-
	MX202	—	—		 / 			DB68C41	p. 29 /p. 52
	—	MM202	—		 / 	 20°		DB68C41	p. 30 /p. 53

1. Motor

2. Names of parts

Figure 1

Motor rated
output power

50
W

100
W

200
W

400
W

750
W

850
W

1
kW

1.3
kW

1.5
kW

2
kW

MX951




Figure 2

Motor rated
output power

50
W

100
W

200
W

400
W

750
W


850
W

1
kW

1.3
kW

1.5
kW

2
kW

MX102
MM102
MH102


1. Specifications

1. Motor

3. Specifications

Item	Specifications
Ambient temperature for operation	0–40 °C
Ambient humidity for operation	20 to 85% RH (no condensation)
Ambient temperature for storage	– 20 to 65 °C (no condensation) (not subjected to direct sunlight) 80 °C for 72 hours
Ambient humidity for storage	20 to 85% RH (no condensation)
Atmosphere for operation / storage	Indoors (not subject to direct sunlight), Free from corrosive gases, flammable gases, oil mist, dust, flammables, grinding fluid
Insulation resistance	$\geq 5 \text{ M}\Omega$ at 1,000 VDC
Dielectric strength	AC 1500 V for one minute across the primary and FG
Operating altitude	$\leq 1,000 \text{ m}$
Vibration class	V15 (JEC2121)
Vibration resistance	49 m/s^2 (5 G)
Impact resistance	98 m/s^2 (10 G)
Protective structure	IP65 : 50 W to 750 W, 1kW (Only MX951) IP67 : 1 kW (Except for MX951) to 2 kW
Electric shock protection	Class I (Mandatory grounding)
Installation environment	Pollution degree 2

**The brake has polarity.**

Lead wire color: Connection
Yellow (BRK +): +24 V
Blue (BRK –): GND

Incorrect wiring may result in motor failure or suboptimal performance of the motor.



1. Specifications

1. Motor



50 W

Motor Model : MY500P2 ☐ ☐ ** (Without brake)
MY500B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	Middle
Fitting flange size	mm	40 sq.
Approximate mass	Without brake	kg 0.4
	With brake	kg 0.6
Compatible amplifier model	-	DB6YZ41
Voltage	V	AC200-240 V
Rated output	W	50
Rated torque	N·m	0.16
Instantaneous maximum torque	N·m	0.56
Rated current (stall current)	A	0.68
Instantaneous maximum current	A	2.4
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.25
Induced voltage constant per phase	mV/(r/min)	8.8
Rated power rate	Without brake	kW/s 7.1
	With brake	kW/s 5.8
Mechanical time constant	Without brake	ms 1.76
	With brake	ms 2.15
Electrical time constant	ms	0.74
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.036
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.043

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.25
Static friction torque	N·m	≥ 0.16
Suction time	ms	≤ 35
Release time	ms	≤ 20
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	68
Thrust	N	58



Brake	Without		With	
	Oil Seal	Without	With	Without
Motor Model	MY500P2S	MY500P2T	MY500B2S	MY500B2T
	MY500P2K	MY500P2L	MY500B2K	MY500B2L
LL	66.4	72.0	106.8	112.4

1. Specifications

1. Motor

Motor Model : MG500P2 ☐ ☐ ** (Without brake)
MG500B2 ☐ ☐ ** (With brake)



Basic Specifications




Item		Unit	Specifications
Rotor inertia		—	Middle
Fitting flange size		mm	40 sq.
Approximate mass	Without brake	kg	0.4
	With brake		0.6
Compatible amplifier model		—	DB6YZ41
Voltage		V	AC200–240 V
Rated output		W	50
Rated torque		N·m	0.16
Instantaneous maximum torque		N·m	0.56
Rated current (stall current)		A	0.71
Instantaneous maximum current		A	2.4
Rated revolving speed		r/min	3,000
Maximum revolving speed		r/min	6,000
Torque constant		N·m/A	0.25
Induced voltage constant per phase		mV/(r/min)	8.7
Rated power rate	Without brake	kW/s	6.4
	With brake		5.3
Mechanical time constant	Without brake	ms	2.14
	With brake		2.58
Electrical time constant		ms	0.65
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$	0.040
	With brake		0.048

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V±10%
Rated current	A	0.26
Static friction torque	N·m	≥ 0.16
Suction time	ms	≤ 35
Release time	ms	≤ 20
Release voltage	V	≥ DC1 V

Permissible Load

Item	Unit	Specifications
Radial	N	68
Thrust	N	58



*) The cable included in the MG500 series is 350 mm.
Please contact us if you need a 210 mm cable.

1. Specifications

1. Motor

100 W

Motor Model : MY101P2 ☐ ☐ ** (Without brake)
MY101B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	Middle
Fitting flange size	mm	40 sq.
Approximate mass	Without brake	kg 0.5
	With brake	kg 0.8
Compatible amplifier model	–	DB6Z141
Voltage	V	AC200–240 V
Rated output	W	100
Rated torque	N·m	0.32
Instantaneous maximum torque	N·m	1.12
Rated current (stall current)	A	0.97
Instantaneous maximum current	A	3.3
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.35
Induced voltage constant per phase	mV/(r/min)	12.3
Rated power rate	Without brake	kW/s 17.4
	With brake	kW/s 15.4
Mechanical time constant	Without brake	ms 1.10
	With brake	ms 1.25
Electrical time constant	ms	0.89
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.058
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.066

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.25
Static friction torque	N·m	≥ 0.32
Suction time	ms	≤ 35
Release time	ms	≤ 20
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	68
Thrust	N	58



Brake	Without		With	
	Oil Seal	Without	With	Without
Motor Model	MY101P2S	MY101P2T	MY101B2S	MY101B2T
	MY101P2K	MY101P2L	MY101B2K	MY101B2L
LL	82.4	88.0	122.8	128.4

1. Specifications

1. Motor

Motor Model : MG101P2 ☐ ☐ ** (Without brake)
MG101B2 ☐ ☐ ** (With brake)



Basic Specifications




Item		Unit	Specifications
Rotor inertia		—	Middle
Fitting flange size		mm	40 sq.
Approximate mass	Without brake	kg	0.5
	With brake		0.7
Compatible amplifier model		—	DB6Z141
Voltage		V	AC200–240 V
Rated output		W	100
Rated torque		N·m	0.32
Instantaneous maximum torque		N·m	1.12
Rated current (stall current)		A	0.99
Instantaneous maximum current		A	3.4
Rated revolving speed		r/min	3,000
Maximum revolving speed		r/min	6,000
Torque constant		N·m/A	0.37
Induced voltage constant per phase		mV/(r/min)	12.7
Rated power rate	Without brake	kW/s	15.5
	With brake		13.8
Mechanical time constant	Without brake	ms	1.28
	With brake		1.43
Electrical time constant		ms	0.78
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$	0.065
	With brake		0.073

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V±10%
Rated current	A	0.26
Static friction torque	N·m	≥ 0.32
Suction time	ms	≤ 35
Release time	ms	≤ 20
Release voltage	V	≥ DC1 V

Permissible Load

Item	Unit	Specifications
Radial	N	68
Thrust	N	58



*) The cable included in the MG101 series is 350 mm.
Please contact us if you need a 210 mm cable.

1. Specifications

1. Motor

200 W

Motor Model : MX201P2 ☐ ☐ ** (Without brake)
MX201B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	Low
Fitting flange size	mm	60 sq.
Approximate mass	Without brake	kg 0.8
	With brake	kg 1.3
Compatible amplifier model	-	DB61241
Voltage	V	AC200-240 V
Rated output	W	200
Rated torque	N·m	0.64
Instantaneous maximum torque	N·m	1.91
Rated current (stall current)	A	1.7
Instantaneous maximum current	A	5.2
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.41
Induced voltage constant per phase	mV/(r/min)	14.3
Rated power rate	Without brake	kW/s 29.9
	With brake	kW/s 24.7
Mechanical time constant	Without brake	ms 0.68
	With brake	ms 0.83
Electrical time constant	ms	2.53
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.14
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.16

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.3
Static friction torque	N·m	≥ 1.27
Suction time	ms	≤ 50
Release time	ms	≤ 15
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	245
Thrust	N	98



Brake	Without	With
Motor Model	MX201P	MX201B
LL	76.5	113.0

1. Specifications

1. Motor

Motor Model : MG201P2 ☐ ☐ ** (Without brake)
 MG201B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	Middle
Fitting flange size	mm	60 sq.
Approximate mass	Without brake	kg 0.9
	With brake	kg 1.3
Compatible amplifier model	-	DB61241
Voltage	V	AC200-240 V
Rated output	W	200
Rated torque	N·m	0.64
Instantaneous maximum torque	N·m	1.91
Rated current (stall current)	A	1.7
Instantaneous maximum current	A	5.2
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.41
Induced voltage constant per phase	mV/(r/min)	14.3
Rated power rate	Without brake	kW/s 15.9
	With brake	kW/s 14.5
Mechanical time constant	Without brake	ms 1.28
	With brake	ms 1.41
Electrical time constant	ms	2.53
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.26
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.28

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.3
Static friction torque	N·m	≥ 1.27
Suction time	ms	≤ 50
Release time	ms	≤ 15
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	245
Thrust	N	98



Brake	Without	With
Motor Model	MG201P	MG201B
LL	78.0	108.5

1. Motor

Motor Model : MZ201P2 ☐ ☐ ** (Without brake)
MZ201B2 ☐ ☐ ** (With brake)



Basic Specifications




Item		Unit	Specifications
Rotor inertia		-	High
Fitting flange size		mm	60 sq.
Approximate mass	Without brake	kg	1.0
	With brake		1.5
Compatible amplifier model		-	DB61241
Voltage		V	AC200-240 V
Rated output		W	200
Rated torque		N·m	0.64
Instantaneous maximum torque		N·m	1.91
Rated current (stall current)		A	1.7
Instantaneous maximum current		A	5.2
Rated revolving speed		r/min	3,000
Maximum revolving speed		r/min	6,000
Torque constant		N·m/A	0.41
Induced voltage constant per phase		mV/(r/min)	14.3
Rated power rate	Without brake	kW/s	9.3
	With brake		8.7
Mechanical time constant	Without brake	ms	2.19
	With brake		2.34
Electrical time constant		ms	2.53
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$	0.44
	With brake		0.46

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V±10%
Rated current	A	0.3
Static friction torque	N·m	≥ 1.27
Suction time	ms	≤ 50
Release time	ms	≤ 15
Release voltage	V	≥ DC1 V

Permissible Load

Item	Unit	Specifications
Radial	N	245
Thrust	N	98



		(mm)
Brake	Without	With
Motor Model	MZ201P	MZ201B
LL	93.5	130.0

1. Specifications

1. Motor

400 W

Motor Model : MX401P2 ☐ ☐ ** (Without brake)
 MX401B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	Low
Fitting flange size	mm	60 sq.
Approximate mass	Without brake	kg 1.1
	With brake	kg 1.6
Compatible amplifier model	-	DB62441
Voltage	V	AC200-240 V
Rated output	W	400
Rated torque	N·m	1.27
Instantaneous maximum torque	N·m	3.82
Rated current (stall current)	A	2.7
Instantaneous maximum current	A	8.5
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.49
Induced voltage constant per phase	mV/(r/min)	17.1
Rated power rate	Without brake	kW/s 71.8
	With brake	kW/s 63.8
Mechanical time constant	Without brake	ms 0.45
	With brake	ms 0.51
Electrical time constant	ms	2.92
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.23
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.25

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.3
Static friction torque	N·m	≥ 1.27
Suction time	ms	≤ 50
Release time	ms	≤ 15
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	245
Thrust	N	98



Brake	Without	With
Motor Model	MX401P	MX401B
LL	93.5	130.0

1. Specifications

1. Motor

Motor Model : MG401P2 ☐ ☐ ** (Without brake)
 MG401B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	Middle
Fitting flange size	mm	60 sq.
Approximate mass	Without brake	kg 1.1
	With brake	kg 1.5
Compatible amplifier model	–	DB62441
Voltage	V	AC200–240 V
Rated output	W	400
Rated torque	N·m	1.27
Instantaneous maximum torque	N·m	3.82
Rated current (stall current)	A	2.7
Instantaneous maximum current	A	8.5
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.49
Induced voltage constant per phase	mV/(r/min)	17.1
Rated power rate	Without brake	kW/s 33.7
	With brake	kW/s 32.1
Mechanical time constant	Without brake	ms 0.96
	With brake	ms 1.01
Electrical time constant	ms	2.92
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.48
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.51

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.3
Static friction torque	N·m	≥ 1.27
Suction time	ms	≤ 50
Release time	ms	≤ 15
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	245
Thrust	N	98





Brake	Without	With
Motor Model	MG401P	MG401B
LL	98.0	128.5

1. Motor

1 Specifications

Permissible Load

Item	Unit	Specifications
Radial	N	245
Thrust	N	98



		(mm)
Brake	Without	With
Motor Model	MZ401P	MZ401B
LL	110.5	147.0

1. Specifications

1. Motor

750 W

Motor Model : MX751P2 □ □ ** (Without brake)
MX751B2 □ □ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	Low
Fitting flange size	mm	80 sq.
Approximate mass	Without brake	kg 2.2
	With brake	kg 3.0
Compatible amplifier model	-	DB63841
Voltage	V	AC200-240 V
Rated output	W	750
Rated torque	N·m	2.39
Instantaneous maximum torque	N·m	7.1
Rated current (stall current)	A	4.2
Instantaneous maximum current	A	12.2
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.63
Induced voltage constant per phase	mV/(r/min)	21.9
Rated power rate	Without brake	kW/s 77.5
	With brake	kW/s 61.3
Mechanical time constant	Without brake	ms 0.39
	With brake	ms 0.50
Electrical time constant	ms	4.60
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.74
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.93

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.4
Static friction torque	N·m	≥ 2.39
Suction time	ms	≤ 70
Release time	ms	≤ 20
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	392
Thrust	N	147



(mm)

Brake	Without	With
Motor Model	MX751P	MX751B
LL	107.3	144.3

1. Specifications

1. Motor

Motor Model : MZ751P2 ☐ ☐ ** (Without brake)
MZ751B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	High
Fitting flange size	mm	80 sq.
Approximate mass	Without brake	kg 2.5
	With brake	3.3
Compatible amplifier model	-	DB63841
Voltage	V	AC200-240 V
Rated output	W	750
Rated torque	N·m	2.39
Instantaneous maximum torque	N·m	7.1
Rated current (stall current)	A	4.2
Instantaneous maximum current	A	12.2
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.63
Induced voltage constant per phase	mV/(r/min)	21.9
Rated power rate	Without brake	kW/s 35.5
	With brake	31.7
Mechanical time constant	Without brake	ms 0.85
	With brake	0.96
Electrical time constant	ms	4.60
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 1.60
	With brake	1.80

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.4
Static friction torque	N·m	≥ 2.39
Suction time	ms	≤ 70
Release time	ms	≤ 20
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	392
Thrust	N	147



(mm)		
Brake	Without	With
Motor Model	MZ751P	MZ751B
LL	122.3	159.3

1. Specifications

1. Motor

850 W

Motor Model : MJ851P2 ☐ ☐ ** (Without brake)
MJ851B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	High
Fitting flange size	mm	130 sq.
Approximate mass	Without brake	kg 6.2
	With brake	kg 7.9
Compatible amplifier model	–	DB65B41
Voltage	V	AC200–240 V
Rated output	W	850
Rated torque	N·m	5.39
Instantaneous maximum torque	N·m	14.2
Rated current (stall current)	A	6.9
Instantaneous maximum current	A	17.0
Rated revolving speed	r/min	1,500
Maximum revolving speed	r/min	3,000
Torque constant	N·m/A	0.83
Induced voltage constant per phase	mV/(r/min)	28.9
Rated power rate	Without brake	kW/s 21.1
	With brake	kW/s 18.3
Mechanical time constant	Without brake	ms 2.7
	With brake	ms 3.1
Electrical time constant	ms	8.45
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 13.9
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 16.0

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.41
Static friction torque	N·m	≥ 12.7
Suction time	ms	≤ 100
Release time	ms	≤ 60
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	98



(mm)

Brake	Without	With
Motor Model	MJ851P	MJ851B
LL	128.0	162.0
LM	97.0	131.0
LR	58.0	
KB1	70.0	
KB2	116.0	150.0
KB3	–	109.0

1. Specifications

1. Motor

1 kW

Motor Model : MX951P2 ☐ ☐ ** (Without brake)
 MX951B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	Low
Fitting flange size	mm	80 sq.
Approximate mass	Without brake	kg 2.8
	With brake	3.6
Compatible amplifier model	-	DB64A41
Voltage	V	AC200-240 V
Rated output	W	1,000
Rated torque	N·m	3.18
Instantaneous maximum torque	N·m	9.55
Rated current (stall current)	A	5.2
Instantaneous maximum current	A	15.2
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.65
Induced voltage constant per phase	mV/(r/min)	22.9
Rated power rate	Without brake	kW/s 90.8
	With brake	78.6
Mechanical time constant	Without brake	ms 0.34
	With brake	0.40
Electrical time constant	ms	3.95
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 1.12
	With brake	1.29

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.47
Static friction torque	N·m	≥ 3.18
Suction time	ms	≤ 70
Release time	ms	≤ 20
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	392
Thrust	N	147



(mm)		
Brake	Without	With
Motor Model	MX951P	MX951B
LL	127.3	164.3

1. Specifications

1. Motor

Motor Model : MX102P2 ☐ ☐ ** (Without brake)
MX102B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	Low
Fitting flange size	mm	100 sq.
Approximate mass	Without brake	kg 3.9
	With brake	5.2
Compatible amplifier model	–	DB64A41
Voltage	V	AC200–240 V
Rated output	W	1,000
Rated torque	N·m	3.18
Instantaneous maximum torque	N·m	9.55
Rated current (stall current)	A	6.6
Instantaneous maximum current	A	19.9
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	5,000
Torque constant	N·m/A	0.52
Induced voltage constant per phase	mV/(r/min)	18.2
Rated power rate	Without brake	kW/s 52.3
	With brake	43.2
Mechanical time constant	Without brake	ms 0.59
	With brake	0.72
Electrical time constant	ms	5.19
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 1.91
	With brake	2.35

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	1.0
Static friction torque	N·m	≥ 7.8
Suction time	ms	≤ 120
Release time	ms	≤ 30
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	196



(mm)

Brake	Without	With
Motor Model	MX102P	MX102B
LL	130.0	160.0
LM	106.0	136.0
LR	55.0	
KB1	63.5	
KB2	118.0	148.0
KB3	–	117.3

1. Specifications

1. Motor

Motor Model : MM102P2 ☐ ☐ ** (Without brake)
 MM102B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	High
Fitting flange size	mm	130 sq.
Approximate mass	Without brake	kg 5.6
	With brake	7.0
Compatible amplifier model	–	DB64A41
Voltage	V	AC200–240 V
Rated output	W	1,000
Rated torque	N·m	4.77
Instantaneous maximum torque	N·m	14.3
Rated current (stall current)	A	5.6
Instantaneous maximum current	A	16.8
Rated revolving speed	r/min	2,000
Maximum revolving speed	r/min	3,000
Torque constant	N·m/A	0.88
Induced voltage constant per phase	mV/(r/min)	30.9
Rated power rate	Without brake	kW/s 50.0
	With brake	36.5
Mechanical time constant	Without brake	ms 0.76
	With brake	1.05
Electrical time constant	ms	10.1
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 4.56
	With brake	6.24

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	1.0
Static friction torque	N·m	≥ 9.55
Suction time	ms	≤ 120
Release time	ms	≤ 30
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	196



(mm)		
Brake	Without	With
Motor Model	MM102P	MM102B
LL	128.0	153.0
LM	97.0	122.0
LR	55.0	
KB1	57.5	
KB2	116.0	141.0
KB3	–	102.8

1. Specifications

1. Motor

Motor Model : MH102P2 ☐ ☐ ** (Without brake)
 MH102B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	High
Fitting flange size	mm	130 sq.
Approximate mass	Without brake	7.6
	With brake	9.0
Compatible amplifier model	–	DB64A41
Voltage	V	AC200–240 V
Rated output	W	1,000
Rated torque	N·m	4.77
Instantaneous maximum torque	N·m	14.3
Rated current (stall current)	A	5.6
Instantaneous maximum current	A	16.8
Rated revolving speed	r/min	2,000
Maximum revolving speed	r/min	3,000
Torque constant	N·m/A	0.88
Induced voltage constant per phase	mV/(r/min)	30.9
Rated power rate	Without brake	9.2
	With brake	8.6
Mechanical time constant	Without brake	4.17
	With brake	4.43
Electrical time constant	ms	10.1
Rotor moment of inertia	Without brake	24.9
	With brake	26.4

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V±10%
Rated current	A	1.0
Static friction torque	N·m	≥ 9.55
Suction time	ms	≤ 120
Release time	ms	≤ 30
Release voltage	V	≥ DC1 V

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	196



(mm)		
Brake	Without	With
Motor Model	MH102P	MH102B
LL	163.0	188.0
LM	132.0	157.0
LR	70.0	
KB1	92.5	
KB2	151.0	176.0
KB3	–	137.8

1. Specifications

1. Motor

1.3 kW

Motor Model : MJ132P2 ☐ ☐ ** (Without brake)
 MJ132B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	High
Fitting flange size	mm	130 sq.
Approximate mass	Without brake	kg 7.7
	With brake	kg 9.8
Compatible amplifier model	-	DB67C41
Voltage	V	AC200-240 V
Rated output	W	1,300
Rated torque	N·m	8.34
Instantaneous maximum torque	N·m	23.3
Rated current (stall current)	A	10.7
Instantaneous maximum current	A	28.0
Rated revolving speed	r/min	1,500
Maximum revolving speed	r/min	3,000
Torque constant	N·m/A	0.85
Induced voltage constant per phase	mV/(r/min)	29.8
Rated power rate	Without brake	kW/s 34.7
	With brake	kW/s 31.3
Mechanical time constant	Without brake	ms 2.1
	With brake	ms 2.3
Electrical time constant	ms	8.42
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 19.8
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 21.9

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.41
Static friction torque	N·m	≥ 19.6
Suction time	ms	≤ 100
Release time	ms	≤ 60
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	686
Thrust	N	343



(mm)		
Brake	Without	With
Motor Model	MJ132P	MJ132B
LL	145.5	179.5
LM	114.5	148.5
LR	58.0	
KB1	87.5	
KB2	133.5	167.5
KB3	-	126.0

1. Specifications

1. Motor

1.5 kW

Motor Model : MX152P2 □□** (Without brake)
MX152B2 □□** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	Low
Fitting flange size	mm	100 sq.
Approximate mass	Without brake	kg 4.9
	With brake	kg 6.2
Compatible amplifier model	–	DB66B41
Voltage	V	AC200–240 V
Rated output	W	1,500
Rated torque	N·m	4.77
Instantaneous maximum torque	N·m	14.3
Rated current (stall current)	A	8.2
Instantaneous maximum current	A	24.9
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	5,000
Torque constant	N·m/A	0.64
Induced voltage constant per phase	mV/(r/min)	22.3
Rated power rate	Without brake	kW/s 81.4
	With brake	kW/s 70.2
Mechanical time constant	Without brake	ms 0.50
	With brake	ms 0.57
Electrical time constant	ms	5.95
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 2.80
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 3.25

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	1.0
Static friction torque	N·m	≥ 7.8
Suction time	ms	≤ 120
Release time	ms	≤ 30
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	196



(mm)

Brake	Without	With
Motor Model	MX152P	MX152B
LL	149.0	179.0
LM	125.0	155.0
LR	55.0	
KB1	82.5	
KB2	137.0	167.0
KB3	–	136.3

1. Specifications

1. Motor

Motor Model : MM152P2 ☐ ☐ ** (Without brake)
 MM152B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	High
Fitting flange size	mm	130 sq.
Approximate mass	Without brake	kg 7.0
	With brake	kg 8.4
Compatible amplifier model	–	DB66B41
Voltage	V	AC200–240 V
Rated output	W	1,500
Rated torque	N·m	7.16
Instantaneous maximum torque	N·m	21.5
Rated current (stall current)	A	9.0
Instantaneous maximum current	A	27
Rated revolving speed	r/min	2,000
Maximum revolving speed	r/min	3,000
Torque constant	N·m/A	0.81
Induced voltage constant per phase	mV/(r/min)	28.4
Rated power rate	Without brake	kW/s 76.9
	With brake	kW/s 61.4
Mechanical time constant	Without brake	ms 0.60
	With brake	ms 0.75
Electrical time constant	ms	12.2
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 6.67
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 8.35

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	1.0
Static friction torque	N·m	≥ 9.55
Suction time	ms	≤ 120
Release time	ms	≤ 30
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	196



(mm)		
Brake	Without	With
Motor Model	MM152P	MM152B
LL	145.5	170.5
LM	114.5	139.5
LR	55.0	
KB1	75.0	
KB2	133.5	158.5
KB3	–	120.3

1. Specifications

1. Motor

Motor Model : MH152P2 ☐ ☐ ** (Without brake)
 MH152B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	High
Fitting flange size	mm	130 sq.
Approximate mass	Without brake	kg 9.0
	With brake	10.4
Compatible amplifier model	–	DB66B41
Voltage	V	AC200–240 V
Rated output	W	1,500
Rated torque	N·m	7.16
Instantaneous maximum torque	N·m	21.5
Rated current (stall current)	A	9.0
Instantaneous maximum current	A	27
Rated revolving speed	r/min	2,000
Maximum revolving speed	r/min	3,000
Torque constant	N·m/A	0.81
Induced voltage constant per phase	mV/(r/min)	28.4
Rated power rate	Without brake	kW/s 13.8
	With brake	13.3
Mechanical time constant	Without brake	ms 3.32
	With brake	3.46
Electrical time constant	ms	12.2
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 37.12
	With brake	38.65

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	1.0
Static friction torque	N·m	≥ 9.55
Suction time	ms	≤ 120
Release time	ms	≤ 30
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	196



(mm)

Brake	Without	With
Motor Model	MH152P	MH152B
LL	180.5	205.5
LM	149.5	174.5
LR	70.0	
KB1	110.0	
KB2	168.5	193.5
KB3	–	155.3

1. Specifications

1. Motor

2 kW

Motor Model : MX202P2 ☐ ☐ ** (Without brake)
 MX202B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	Low
Fitting flange size	mm	100 sq.
Approximate mass	Without brake	kg 6.0
	With brake	kg 7.3
Compatible amplifier model	-	DB68C41
Voltage	V	AC200-240 V
Rated output	W	2,000
Rated torque	N·m	6.37
Instantaneous maximum torque	N·m	19.1
Rated current (stall current)	A	11.3
Instantaneous maximum current	A	33.9
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	5,000
Torque constant	N·m/A	0.62
Induced voltage constant per phase	mV/(r/min)	21.7
Rated power rate	Without brake	kW/s 110.2
	With brake	kW/s 99.2
Mechanical time constant	Without brake	ms 0.50
	With brake	ms 0.56
Electrical time constant	ms	5.44
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 3.68
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 4.09

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	1.0
Static friction torque	N·m	≥ 7.8
Suction time	ms	≤ 120
Release time	ms	≤ 30
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	196



(mm)

Brake	Without	With
Motor Model	MX202P	MX202B
LL	168.0	198.0
LM	144.0	174.0
LR	55.0	
KB1	101.5	
KB2	156.0	186.0
KB3	-	155.3

1. Specifications

1. Motor

Motor Model : MM202P2 ☐ ☐ ** (Without brake)
 MM202B2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	High
Fitting flange size	mm	130 sq.
Approximate mass	Without brake	kg 8.4
	With brake	9.8
Compatible amplifier model	–	DB68C41
Voltage	V	AC200–240 V
Rated output	W	2,000
Rated torque	N·m	9.55
Instantaneous maximum torque	N·m	28.6
Rated current (stall current)	A	11.9
Instantaneous maximum current	A	35.7
Rated revolving speed	r/min	2,000
Maximum revolving speed	r/min	3,000
Torque constant	N·m/A	0.85
Induced voltage constant per phase	mV/(r/min)	29.6
Rated power rate	Without brake	kW/s 104.9
	With brake	87.9
Mechanical time constant	Without brake	ms 0.58
	With brake	0.69
Electrical time constant	ms	12.2
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 8.70
	With brake	10.38

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	1.0
Static friction torque	N·m	≥ 9.55
Suction time	ms	≤ 120
Release time	ms	≤ 30
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	196



(mm)		
Brake	Without	With
Motor Model	MM202P	MM202B
LL	163.0	188.0
LM	132.0	157.0
LR	55.0	
KB1	92.5	
KB2	151.0	176.0
KB3	–	137.8

1. Specifications

1. Motor



50 W

Motor Model : MY500N2 ☐ ☐ ** (Without brake)
 MY500A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	Middle
Fitting flange size	mm	40 sq.
Approximate mass	Without brake	kg 0.4
	With brake	kg 0.6
Compatible amplifier model	-	DB6YZ41
Voltage	V	AC200-240 V
Rated output	W	50
Rated torque	N·m	0.16
Instantaneous maximum torque	N·m	0.56
Rated current (stall current)	A	0.68
Instantaneous maximum current	A	2.4
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.25
Induced voltage constant per phase	mV/(r/min)	8.8
Rated power rate	Without brake	kW/s 7.1
	With brake	kW/s 5.8
Mechanical time constant	Without brake	ms 1.76
	With brake	ms 2.15
Electrical time constant	ms	0.74
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.036
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.043

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.25
Static friction torque	N·m	≥ 0.16
Suction time	ms	≤ 35
Release time	ms	≤ 20
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	68
Thrust	N	58



Brake	Without		With	
	Oil Seal	Without	With	Without
Motor Model	MY500N2S	MY500N2T	MY500A2S	MY500A2T
	MY500N2K	MY500N2L	MY500A2K	MY500A2L
LL	66.4	72.0	106.8	112.4

1. Specifications

1. Motor

Motor Model : MG500N2 ☐ ☐ ** (Without brake)
 MG500A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	Middle
Fitting flange size	mm	40 sq.
Approximate mass	Without brake	kg 0.4
	With brake	0.6
Compatible amplifier model	-	DB6YZ41
Voltage	V	AC200-240 V
Rated output	W	50
Rated torque	N·m	0.16
Instantaneous maximum torque	N·m	0.56
Rated current (stall current)	A	0.71
Instantaneous maximum current	A	2.4
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.25
Induced voltage constant per phase	mV/(r/min)	8.7
Rated power rate	Without brake	kW/s 6.4
	With brake	5.3
Mechanical time constant	Without brake	ms 2.14
	With brake	2.58
Electrical time constant	ms	0.65
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.040
	With brake	0.048

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.26
Static friction torque	N·m	≥ 0.16
Suction time	ms	≤ 35
Release time	ms	≤ 20
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	68
Thrust	N	58



Brake	Without		With	
	Oil Seal	Without	With	Without
Motor Model	MG500N2S	MG500N2T	MG500A2S	MG500A2T
	MG500N2K	MG500N2L	MG500A2K	MG500A2L
LL	57.1	64.7	89.5	97.1

*) The cable included in the MG500 series is 350 mm.
 Please contact us if you need a 210 mm cable.

1. Specifications

1. Motor

100 W

Motor Model : MY101N2 ☐ ☐ ** (Without brake)
 MY101A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	Middle
Fitting flange size	mm	40 sq.
Approximate mass	Without brake	kg 0.5
	With brake	kg 0.8
Compatible amplifier model	–	DB6Z141
Voltage	V	AC200–240 V
Rated output	W	100
Rated torque	N·m	0.32
Instantaneous maximum torque	N·m	1.12
Rated current (stall current)	A	0.97
Instantaneous maximum current	A	3.3
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.35
Induced voltage constant per phase	mV/(r/min)	12.3
Rated power rate	Without brake	kW/s 17.4
	With brake	kW/s 15.4
Mechanical time constant	Without brake	ms 1.10
	With brake	ms 1.25
Electrical time constant	ms	0.89
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.058
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.066

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.25
Static friction torque	N·m	≥ 0.32
Suction time	ms	≤ 35
Release time	ms	≤ 20
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	68
Thrust	N	58



Brake	Without		With	
	Oil Seal	Without	With	Without
Motor Model	MY101N2S	MY101N2T	MY101A2S	MY101A2T
	MY101N2K	MY101N2L	MY101A2K	MY101A2L
LL	82.4	88.0	122.8	128.4

1. Specifications

1. Motor

Motor Model : MG101N2 ☐ ☐ ** (Without brake)
 MG101A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	Middle
Fitting flange size	mm	40 sq.
Approximate mass	Without brake	kg 0.5
	With brake	kg 0.7
Compatible amplifier model	-	DB6Z141
Voltage	V	AC200-240 V
Rated output	W	100
Rated torque	N·m	0.32
Instantaneous maximum torque	N·m	1.12
Rated current (stall current)	A	0.99
Instantaneous maximum current	A	3.4
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.37
Induced voltage constant per phase	mV/(r/min)	12.7
Rated power rate	Without brake	kW/s 15.5
	With brake	kW/s 13.8
Mechanical time constant	Without brake	ms 1.28
	With brake	ms 1.43
Electrical time constant	ms	0.78
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.065
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.073

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.26
Static friction torque	N·m	≥ 0.32
Suction time	ms	≤ 35
Release time	ms	≤ 20
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	68
Thrust	N	58



Brake	Without		With	
	Oil Seal	Without	With	Without
Motor Model	MG101N2S	MG101N2T	MG101A2S	MG101A2T
	MG101N2K	MG101N2L	MG101A2K	MG101A2L
LL	70.7	78.3	103.1	110.7

*) The cable included in the MG101 series is 350 mm.
 Please contact us if you need a 210 mm cable.

1. Specifications

1. Motor

200 W

Motor Model : MX201N2 ☐ ☐ ** (Without brake)
 MX201A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	Low
Fitting flange size	mm	60 sq.
Approximate mass	Without brake	kg 0.8
	With brake	kg 1.3
Compatible amplifier model	-	DB61241
Voltage	V	AC200-240 V
Rated output	W	200
Rated torque	N·m	0.64
Instantaneous maximum torque	N·m	1.91
Rated current (stall current)	A	1.7
Instantaneous maximum current	A	5.2
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.41
Induced voltage constant per phase	mV/(r/min)	14.3
Rated power rate	Without brake	kW/s 29.9
	With brake	kW/s 24.7
Mechanical time constant	Without brake	ms 0.68
	With brake	ms 0.83
Electrical time constant	ms	2.53
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.14
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.16

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.3
Static friction torque	N·m	≥ 1.27
Suction time	ms	≤ 50
Release time	ms	≤ 15
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	245
Thrust	N	98



Brake	Without	With
Motor Model	MX201N	MX201A
LL	76.5	113.0

1. Specifications

1. Motor

Motor Model : MG201N2 ☐ ☐ ** (Without brake)
 MG201A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	Middle
Fitting flange size	mm	60 sq.
Approximate mass	Without brake	kg 0.9
	With brake	kg 1.3
Compatible amplifier model	-	DB61241
Voltage	V	AC200-240 V
Rated output	W	200
Rated torque	N·m	0.64
Instantaneous maximum torque	N·m	1.91
Rated current (stall current)	A	1.7
Instantaneous maximum current	A	5.2
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.41
Induced voltage constant per phase	mV/(r/min)	14.3
Rated power rate	Without brake	kW/s 15.9
	With brake	kW/s 14.5
Mechanical time constant	Without brake	ms 1.28
	With brake	ms 1.41
Electrical time constant	ms	2.53
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.26
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.28

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.3
Static friction torque	N·m	≥ 1.27
Suction time	ms	≤ 50
Release time	ms	≤ 15
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	245
Thrust	N	98



Brake	Without	With
Motor Model	MG201N	MG201A
LL	78.0	108.5

1. Specifications

1. Motor

Motor Model : MZ201N2 ☐ ☐ ** (Without brake)
MZ201A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	High
Fitting flange size	mm	60 sq.
Approximate mass	Without brake	kg 1.0
	With brake	kg 1.5
Compatible amplifier model	-	DB61241
Voltage	V	AC200-240 V
Rated output	W	200
Rated torque	N·m	0.64
Instantaneous maximum torque	N·m	1.91
Rated current (stall current)	A	1.7
Instantaneous maximum current	A	5.2
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.41
Induced voltage constant per phase	mV/(r/min)	14.3
Rated power rate	Without brake	kW/s 9.3
	With brake	kW/s 8.7
Mechanical time constant	Without brake	ms 2.19
	With brake	ms 2.34
Electrical time constant	ms	2.53
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.44
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.46

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.3
Static friction torque	N·m	≥ 1.27
Suction time	ms	≤ 50
Release time	ms	≤ 15
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	245
Thrust	N	98



Brake	Without	With
Motor Model	MZ201N	MZ201A
LL	93.5	130.0

1. Specifications

1. Motor

400 W

Motor Model : MX401N2 ☐ ☐ ** (Without brake)
MX401A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	Low
Fitting flange size	mm	60 sq.
Approximate mass	Without brake	kg 1.1
	With brake	kg 1.6
Compatible amplifier model	-	DB62441
Voltage	V	AC200-240 V
Rated output	W	400
Rated torque	N·m	1.27
Instantaneous maximum torque	N·m	3.82
Rated current (stall current)	A	2.7
Instantaneous maximum current	A	8.5
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.49
Induced voltage constant per phase	mV/(r/min)	17.1
Rated power rate	Without brake	kW/s 71.8
	With brake	kW/s 63.8
Mechanical time constant	Without brake	ms 0.45
	With brake	ms 0.51
Electrical time constant	ms	2.92
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.23
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.25

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.3
Static friction torque	N·m	≥ 1.27
Suction time	ms	≤ 50
Release time	ms	≤ 15
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	245
Thrust	N	98



Brake	Without	With
Motor Model	MX401N	MX401A
LL	93.5	130.0

1. Specifications

1. Motor

Motor Model : MG401N2 ☐ ☐ ** (Without brake)
 MG401A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	Middle
Fitting flange size	mm	60 sq.
Approximate mass	Without brake	kg 1.1
	With brake	kg 1.5
Compatible amplifier model	-	DB62441
Voltage	V	AC200-240 V
Rated output	W	400
Rated torque	N·m	1.27
Instantaneous maximum torque	N·m	3.82
Rated current (stall current)	A	2.7
Instantaneous maximum current	A	8.5
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.49
Induced voltage constant per phase	mV/(r/min)	17.1
Rated power rate	Without brake	kW/s 33.7
	With brake	kW/s 32.1
Mechanical time constant	Without brake	ms 0.96
	With brake	ms 1.01
Electrical time constant	ms	2.92
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.48
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.51

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.3
Static friction torque	N·m	≥ 1.27
Suction time	ms	≤ 50
Release time	ms	≤ 15
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	245
Thrust	N	98



Brake	Without	With
Motor Model	MG401N	MG401A
LL	98.0	128.5

1. Motor

Motor Model : MZ401N2 ☐ ☐ ** (Without brake)
MZ401A2 ☐ ☐ ** (With brake)



Basic Specifications




Item		Unit	Specifications
Rotor inertia		-	High
Fitting flange size		mm	60 sq.
Approximate mass	Without brake	kg	1.3
	With brake		1.8
Compatible amplifier model		-	DB62441
Voltage		V	AC200-240 V
Rated output		W	400
Rated torque		N·m	1.27
Instantaneous maximum torque		N·m	3.82
Rated current (stall current)		A	2.7
Instantaneous maximum current		A	8.5
Rated revolving speed		r/min	3,000
Maximum revolving speed		r/min	6,000
Torque constant		N·m/A	0.49
Induced voltage constant per phase		mV/(r/min)	17.1
Rated power rate	Without brake	kW/s	23.2
	With brake		22.3
Mechanical time constant	Without brake	ms	1.40
	With brake		1.46
Electrical time constant		ms	2.92
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$	0.70
	With brake		0.73

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V±10%
Rated current	A	0.3
Static friction torque	N·m	≥ 1.27
Suction time	ms	≤ 50
Release time	ms	≤ 15
Release voltage	V	≥ DC1 V

Permissible Load

Item	Unit	Specifications
Radial	N	245
Thrust	N	98



		(mm)
Brake	Without	With
Motor Model	MZ401N	MZ401A
LL	110.5	147.0

1. Specifications

1. Motor

750 W

Motor Model : MX751N2 ☐ ☐ ** (Without brake)
 MX751A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	Low
Fitting flange size	mm	80 sq.
Approximate mass	Without brake	kg 2.2
	With brake	3.0
Compatible amplifier model	-	DB63841
Voltage	V	AC200-240 V
Rated output	W	750
Rated torque	N·m	2.39
Instantaneous maximum torque	N·m	7.1
Rated current (stall current)	A	4.2
Instantaneous maximum current	A	12.2
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.63
Induced voltage constant per phase	mV/(r/min)	21.9
Rated power rate	Without brake	kW/s 77.5
	With brake	61.3
Mechanical time constant	Without brake	ms 0.39
	With brake	0.50
Electrical time constant	ms	4.60
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 0.74
	With brake	0.93

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.4
Static friction torque	N·m	≥ 2.39
Suction time	ms	≤ 70
Release time	ms	≤ 20
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	392
Thrust	N	147



(mm)		
Brake	Without	With
Motor Model	MX751N	MX751A
LL	107.3	144.3

1. Specifications

1. Motor

Motor Model : MZ751N2 ☐ ☐ ** (Without brake)
MZ751A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	High
Fitting flange size	mm	80 sq.
Approximate mass	Without brake	kg 2.5
	With brake	kg 3.3
Compatible amplifier model	-	DB63841
Voltage	V	AC200-240 V
Rated output	W	750
Rated torque	N·m	2.39
Instantaneous maximum torque	N·m	7.1
Rated current (stall current)	A	4.2
Instantaneous maximum current	A	12.2
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.63
Induced voltage constant per phase	mV/(r/min)	21.9
Rated power rate	Without brake	kW/s 35.5
	With brake	kW/s 31.7
Mechanical time constant	Without brake	ms 0.85
	With brake	ms 0.96
Electrical time constant	ms	4.60
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 1.60
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 1.80

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.4
Static friction torque	N·m	≥ 2.39
Suction time	ms	≤ 70
Release time	ms	≤ 20
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	392
Thrust	N	147



(mm)		
Brake	Without	With
Motor Model	MZ751N	MZ751A
LL	122.3	159.3

1. Specifications

1. Motor

850 W

Motor Model : MJ851N2 ☐ ☐ ** (Without brake)
 MJ851A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	High
Fitting flange size	mm	130 sq.
Approximate mass	Without brake	kg 6.2
	With brake	kg 7.9
Compatible amplifier model	–	DB65B41
Voltage	V	AC200–240 V
Rated output	W	850
Rated torque	N·m	5.39
Instantaneous maximum torque	N·m	14.2
Rated current (stall current)	A	6.9
Instantaneous maximum current	A	17.0
Rated revolving speed	r/min	1,500
Maximum revolving speed	r/min	3,000
Torque constant	N·m/A	0.83
Induced voltage constant per phase	mV/(r/min)	28.9
Rated power rate	Without brake	kW/s 21.1
	With brake	kW/s 18.3
Mechanical time constant	Without brake	ms 2.7
	With brake	ms 3.1
Electrical time constant	ms	8.45
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 13.9
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 16.0

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.41
Static friction torque	N·m	≥ 12.7
Suction time	ms	≤ 100
Release time	ms	≤ 60
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	98



(mm)		
Brake	Without	With
Motor Model	MJ851N	MJ851A
LL	128.0	162.0
LM	97.0	131.0
LR	58.0	
KB1	70.0	
KB2	116.0	150.0
KB3	–	109.0

1. Specifications

1. Motor

1 kW

Motor Model : MX951N2 ☐ ☐ ** (Without brake)
MX951A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	Low
Fitting flange size	mm	80 sq.
Approximate mass	Without brake	kg 2.8
	With brake	kg 3.6
Compatible amplifier model	–	DB64A41
Voltage	V	AC200–240 V
Rated output	W	1,000
Rated torque	N·m	3.18
Instantaneous maximum torque	N·m	9.55
Rated current (stall current)	A	5.2
Instantaneous maximum current	A	15.2
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	6,000
Torque constant	N·m/A	0.65
Induced voltage constant per phase	mV/(r/min)	22.9
Rated power rate	Without brake	kW/s 90.8
	With brake	kW/s 78.6
Mechanical time constant	Without brake	ms 0.34
	With brake	ms 0.40
Electrical time constant	ms	3.95
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 1.12
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 1.29

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.47
Static friction torque	N·m	≥ 3.18
Suction time	ms	≤ 70
Release time	ms	≤ 20
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	392
Thrust	N	147



(mm)		
Brake	Without	With
Motor Model	MX951N	MX951A
LL	127.3	164.3

1. Specifications

1. Motor

Motor Model : MX102N2 ☐ ☐ ** (Without brake)
 MX102A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	Low
Fitting flange size	mm	100 sq.
Approximate mass	Without brake	kg 3.9
	With brake	kg 5.2
Compatible amplifier model	–	DB64A41
Voltage	V	AC200–240 V
Rated output	W	1,000
Rated torque	N·m	3.18
Instantaneous maximum torque	N·m	9.55
Rated current (stall current)	A	6.6
Instantaneous maximum current	A	19.9
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	5,000
Torque constant	N·m/A	0.52
Induced voltage constant per phase	mV/(r/min)	18.2
Rated power rate	Without brake	kW/s 52.3
	With brake	kW/s 43.2
Mechanical time constant	Without brake	ms 0.59
	With brake	ms 0.72
Electrical time constant	ms	5.19
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 1.94
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 2.35

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	1.0
Static friction torque	N·m	≥ 7.8
Suction time	ms	≤ 120
Release time	ms	≤ 30
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	196



(mm)

Brake	Without	With
Motor Model	MX102N	MX102A
LL	130.0	160.0
LM	106.0	136.0
LR	55.0	
KB1	63.5	
KB2	118.0	148.0
KB3	–	117.3

1. Specifications

1. Motor

Motor Model : MM102N2 ☐ ☐ ** (Without brake)
MM102A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	High
Fitting flange size	mm	130 sq.
Approximate mass	Without brake	kg 5.6
	With brake	7.0
Compatible amplifier model	–	DB64A41
Voltage	V	AC200–240 V
Rated output	W	1,000
Rated torque	N·m	4.77
Instantaneous maximum torque	N·m	14.3
Rated current (stall current)	A	5.6
Instantaneous maximum current	A	16.8
Rated revolving speed	r/min	2,000
Maximum revolving speed	r/min	3,000
Torque constant	N·m/A	0.88
Induced voltage constant per phase	mV/(r/min)	30.9
Rated power rate	Without brake	kW/s 50.0
	With brake	36.5
Mechanical time constant	Without brake	ms 0.76
	With brake	1.05
Electrical time constant	ms	10.1
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 4.56
	With brake	6.24

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	1.0
Static friction torque	N·m	≥ 9.55
Suction time	ms	≤ 120
Release time	ms	≤ 30
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	196



Brake	Without	With
Motor Model	MM102N	MM102A
LL	128.0	153.0
LM	97.0	122.0
LR	55.0	
KB1	57.5	
KB2	116.0	141.0
KB3	–	102.8

1. Specifications

1. Motor

Motor Model : MH102N2 ☐ ☐ ** (Without brake)
 MH102A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	High
Fitting flange size	mm	130 sq.
Approximate mass	Without brake	kg 7.6
	With brake	kg 9.0
Compatible amplifier model	–	DB64A41
Voltage	V	AC200–240 V
Rated output	W	1,000
Rated torque	N·m	4.77
Instantaneous maximum torque	N·m	14.3
Rated current (stall current)	A	5.6
Instantaneous maximum current	A	16.8
Rated revolving speed	r/min	2,000
Maximum revolving speed	r/min	3,000
Torque constant	N·m/A	0.88
Induced voltage constant per phase	mV/(r/min)	30.9
Rated power rate	Without brake	kW/s 9.2
	With brake	kW/s 8.6
Mechanical time constant	Without brake	ms 4.17
	With brake	ms 4.43
Electrical time constant	ms	10.1
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 24.9
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 26.4

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	1.0
Static friction torque	N·m	≥ 9.55
Suction time	ms	≤ 120
Release time	ms	≤ 30
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	196



(mm)		
Brake	Without	With
Motor Model	MH102N	MH102A
LL	163.0	188.0
LM	132.0	157.0
LR	70.0	
KB1	92.5	
KB2	151.0	176.0
KB3	–	137.8

1. Specifications

1. Motor

1.3 kW

Motor Model : MJ132N2 ☐ ☐ ** (Without brake)
MJ132A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	High
Fitting flange size	mm	130 sq.
Approximate mass	Without brake	kg 7.7
	With brake	kg 9.8
Compatible amplifier model	–	DB67C41
Voltage	V	AC200–240 V
Rated output	W	1,300
Rated torque	N·m	8.34
Instantaneous maximum torque	N·m	23.3
Rated current (stall current)	A	10.7
Instantaneous maximum current	A	28.0
Rated revolving speed	r/min	1,500
Maximum revolving speed	r/min	3,000
Torque constant	N·m/A	0.85
Induced voltage constant per phase	mV/(r/min)	29.8
Rated power rate	Without brake	kW/s 34.6
	With brake	kW/s 31.3
Mechanical time constant	Without brake	ms 2.1
	With brake	ms 2.3
Electrical time constant	ms	8.42
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 19.8
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 21.9

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	0.41
Static friction torque	N·m	≥ 19.6
Suction time	ms	≤ 100
Release time	ms	≤ 60
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	686
Thrust	N	343



(mm)		
Brake	Without	With
Motor Model	MJ132N	MJ132A
LL	128.0	153.0
LM	97.0	122.0
LR	55.0	
KB1	57.5	
KB2	116.0	141.0
KB3	–	102.8

1. Specifications

1. Motor

1.5 kW

Motor Model : MX152N2 ☐ ☐ ** (Without brake)
 MX152A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	Low
Fitting flange size	mm	100 sq.
Approximate mass	Without brake	kg 4.9
	With brake	kg 6.2
Compatible amplifier model	–	DB66B41
Voltage	V	AC200–240 V
Rated output	W	1,500
Rated torque	N·m	4.77
Instantaneous maximum torque	N·m	14.3
Rated current (stall current)	A	8.2
Instantaneous maximum current	A	24.9
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	5,000
Torque constant	N·m/A	0.64
Induced voltage constant per phase	mV/(r/min)	22.3
Rated power rate	Without brake	kW/s 81.4
	With brake	kW/s 70.2
Mechanical time constant	Without brake	ms 0.50
	With brake	ms 0.57
Electrical time constant	ms	5.95
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 2.80
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 3.25

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	1.0
Static friction torque	N·m	≥ 7.8
Suction time	ms	≤ 120
Release time	ms	≤ 30
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	196



(mm)

Brake	Without	With
Motor Model	MX152N	MX152A
LL	149.0	179.0
LM	125.0	155.0
LR	55.0	
KB1	82.5	
KB2	137.0	167.0
KB3	–	136.3

1. Specifications

1. Motor

Motor Model : MM152N2 ☐ ☐ ** (Without brake)
MM152A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	High
Fitting flange size	mm	130 sq.
Approximate mass	Without brake	kg 7.0
	With brake	8.4
Compatible amplifier model	–	DB66B41
Voltage	V	AC200–240 V
Rated output	W	1,500
Rated torque	N·m	7.16
Instantaneous maximum torque	N·m	21.5
Rated current (stall current)	A	9.0
Instantaneous maximum current	A	27
Rated revolving speed	r/min	2,000
Maximum revolving speed	r/min	3,000
Torque constant	N·m/A	0.81
Induced voltage constant per phase	mV/(r/min)	28.4
Rated power rate	Without brake	kW/s 76.9
	With brake	61.4
Mechanical time constant	Without brake	ms 0.60
	With brake	0.75
Electrical time constant	ms	12.2
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 6.67
	With brake	8.35

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	1.0
Static friction torque	N·m	≥ 9.55
Suction time	ms	≤ 120
Release time	ms	≤ 30
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	196



(mm)

Brake	Without	With
Motor Model	MM152N	MM152A
LL	145.5	170.5
LM	114.5	139.5
LR	55.0	
KB1	75.0	
KB2	133.5	158.5
KB3	–	120.3

1. Specifications

1. Motor

Motor Model : MH152N2 ☐ ☐ ** (Without brake)
 MH152A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	High
Fitting flange size	mm	130 sq.
Approximate mass	Without brake	kg 9.0
	With brake	10.4
Compatible amplifier model	–	DB66B41
Voltage	V	AC200–240 V
Rated output	W	1,500
Rated torque	N·m	7.16
Instantaneous maximum torque	N·m	21.5
Rated current (stall current)	A	9.0
Instantaneous maximum current	A	27
Rated revolving speed	r/min	2,000
Maximum revolving speed	r/min	3,000
Torque constant	N·m/A	0.81
Induced voltage constant per phase	mV/(r/min)	28.4
Rated power rate	Without brake	kW/s 13.8
	With brake	13.3
Mechanical time constant	Without brake	ms 3.32
	With brake	3.46
Electrical time constant	ms	12.2
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 37.12
	With brake	38.65

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	1.0
Static friction torque	N·m	≥ 9.55
Suction time	ms	≤ 120
Release time	ms	≤ 30
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	196



(mm)		
Brake	Without	With
Motor Model	MH152N	MH152A
LL	180.5	205.5
LM	149.5	174.5
LR	70.0	
KB1	110.0	
KB2	168.5	193.5
KB3	–	155.3

1. Specifications

1. Motor

2 kW

Motor Model : MX202N2 ☐ ☐ ** (Without brake)
MX202A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	-	Low
Fitting flange size	mm	100 sq.
Approximate mass	Without brake	kg 6.0
	With brake	kg 7.3
Compatible amplifier model	-	DB68C41
Voltage	V	AC200-240 V
Rated output	W	2,000
Rated torque	N·m	6.37
Instantaneous maximum torque	N·m	19.1
Rated current (stall current)	A	11.3
Instantaneous maximum current	A	33.9
Rated revolving speed	r/min	3,000
Maximum revolving speed	r/min	5,000
Torque constant	N·m/A	0.62
Induced voltage constant per phase	mV/(r/min)	21.7
Rated power rate	Without brake	kW/s 110.2
	With brake	kW/s 99.2
Mechanical time constant	Without brake	ms 0.50
	With brake	ms 0.56
Electrical time constant	ms	5.44
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 3.68
	With brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 4.09

Brake Specifications

Item	Unit	Specifications
Usage	-	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	1.0
Static friction torque	N·m	≥ 7.8
Suction time	ms	≤ 120
Release time	ms	≤ 30
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	196



(mm)

Brake	Without	With
Motor Model	MX202N	MX202A
LL	168.0	198.0
LM	144.0	174.0
LR	55.0	
KB1	101.5	
KB2	156.0	186.0
KB3	-	155.3

1. Specifications

1. Motor

Motor Model : MM202N2 ☐ ☐ ** (Without brake)
 MM202A2 ☐ ☐ ** (With brake)



Basic Specifications




Item	Unit	Specifications
Rotor inertia	–	Middle
Fitting flange size	mm	130 sq.
Approximate mass	Without brake	kg 8.4
	With brake	9.8
Compatible amplifier model	–	DB68C41
Voltage	V	AC200–240 V
Rated output	W	2,000
Rated torque	N·m	9.55
Instantaneous maximum torque	N·m	28.6
Rated current (stall current)	A	11.9
Instantaneous maximum current	A	35.7
Rated revolving speed	r/min	2,000
Maximum revolving speed	r/min	3,000
Torque constant	N·m/A	0.85
Induced voltage constant per phase	mV/(r/min)	29.6
Rated power rate	Without brake	kW/s 104.9
	With brake	87.9
Mechanical time constant	Without brake	ms 0.58
	With brake	0.69
Electrical time constant	ms	12.2
Rotor moment of inertia	Without brake	$\times 10^{-4} \text{ kg} \cdot \text{m}^2$ 8.70
	With brake	10.38

Brake Specifications

Item	Unit	Specifications
Usage	–	Holding
Rated voltage	V	DC24 V \pm 10%
Rated current	A	1.0
Static friction torque	N·m	≥ 9.55
Suction time	ms	≤ 120
Release time	ms	≤ 30
Release voltage	V	$\geq \text{DC1 V}$

Permissible Load

Item	Unit	Specifications
Radial	N	490
Thrust	N	196






(mm)		
Brake	Without	With
Motor Model	MM202N	MM202A
LL	163.0	188.0
LM	132.0	157.0
LR	55.0	
KB1	92.5	
KB2	151.0	176.0
KB3	–	137.8

1. Specifications

2. Encoder


1. Specifications

Item			Specifications		
Motor model			M□□□□P2□A** M□□□□B2□A**	M□□□□N2□A** M□□□□A2□A**	M□□□□N2□N** M□□□□A2□N**
Resolution			 Absolute 23 bit	 Absolute 17 bit	 Incremental 17 bit
Environmental requirements	Ambient operating temperature		0-90°C		
	External disturbance magnetic field		±2 mT (20 G) or below		
Electrical specifications	Power supply	Voltage	DC 4.5 to 5.5 V (Power supply ripple ≤ 5%)		
		Current consumption	80 mA typ. (*1)	160 mA typ. (*1)	
	External battery	Voltage	DC 2.7-4.0 V	DC 2.4-4.2 V	—
		Current consumption	15 μA typ. (*2)	10 μA typ. (*2)	—
	Multi-turn count		65,536 counts		
	Maximum revolving speed		6,000 r/min		
Communication specification	Count-up direction		CCW (*3)		
	Transmission method		Half-duplex asynchronous serial communication		
Communication specification	Communication speed		4.0 Mbps	2.5 Mbps	

*1) Inrush-current is not included.

*2) Measurement conditions room temperature, the motor not in motion, battery voltage of 3.6 V.

*3) CCW when viewed from the load side shaft end.



Precautions

Using the motor with rotations of 180 degrees or less will reduce the encoder's rotational accuracy. (17 bit encoder)


For a motor equipped with a brake, follow the brake voltage and polarity specifications.

If the brake voltage is less than 12 V or the polarity is reversed, the encoder's rotational accuracy will be reduced.



1. Specifications

3. Amplifiers

1. Model Codes



2. Names of parts



1. Specifications

3. Amplifier

Figure 3

Motor rated
output powerAmplifier model
DB63841
DB64A41

Mounting holes

M4 (Effective depth = 5 mm) two locations
(Same as bottom side)

Setting panel

Used for EtherCAT communication node
address setting and status display

Hazardous voltage display LED

This will be lit while there is residual
hazardous voltage inside the amplifier.

Accessories

C1 Main power / Control power input

Main power input, Control power input,
and Regenerative resistor connection

Accessories

C2 Motor power output

Motor power output

FG (Protective earth) terminal

Two terminals:
Attached M4x8 mm screw with spring washer

Mounting holes

ø 5.5 (one location)
The recommended screw: M5x12 mm,
with spring washer

C3 USB connector

Used for parameter settings, tuning,
and status display in the dedicated
software "S-TUNE II"

C5 User I/O connector

User I/O, ABZ output

ECIN, ECOUT connector

EtherCAT communication connector

Mounting notch

ø 5.5 (one location)
The recommended screw: M5x12 mm,
with spring washer

C8 Encoder connector

Encoder connection

Figure 4

Motor rated
output powerAmplifier model
DB65B41 DB67C41
DB66B41 DB68C41

Mounting holes

M4 (Effective depth = 5 mm) two locations
(Same as bottom side)

Setting panel

Used for EtherCAT communication node
address setting and status display

Hazardous voltage display LED

This will be lit while there is residual
hazardous voltage inside the amplifier.

Terminal block

Main power input, Control power input,
Regenerative resistor connection,
and Motor power output
(The recommended terminal:
2-4S insulation coating ring crimp terminals)

FG (Protective earth) terminal

Two terminals:
Attached M4x8 mm screw with spring washer

Mounting holes

ø 5.5 (two locations)
The recommended screw: M5x12 mm,
with spring washer

C3 USB connector

Used for parameter settings, tuning,
and status display in the dedicated
software "S-TUNE II"

C5 User I/O connector

User I/O, ABZ output

Mounting hole

ø 5.5 (one location)
The recommended screw: M5x12 mm,
with spring washer

ECIN, ECOUT connector






EtherCAT communication connector

C8 Encoder connector

Encoder connection

3. Specifications

Basic Specifications







Items		Specifications				
Amplifier model		DB6YZ41	DB6Z141	DB61241	DB62441	DB63841
Compatible Motor		M□500	M□101	M□201	M□401	M□751
						
External dimensions		(See "Dimensions")				
Mass (Kg)		0.8			1.0	1.1
Main circuit power & Control power		Single-phase AC200 V-240 V±10% 50 / 60 Hz				
Input current (Arms typ)		0.9	1.5	2.6	4.6	7.6
Control type		Three-phase PWM inverter sine-wave driven				
Output Rating	Rated current (A)	0.7	1.0	1.7	2.7	4.2
	Output frequencies (Hz)	0 - 500				
Encoder feedback		23 bit / 17 bit single-turn absolute (The product can function as a multi-turn absolute type when batteries are added.)				
Control signal ^{(*)2}	Input	7-point (24VDC system, photo-coupler input insulation)				
	Output	3-point (24VDC system, photo-coupler output insulation)				
Communication function		EtherCAT (Topology: "Daisy chain", "Star", or "Ring" are available) USB : connection to PC with "S-TUNE II" installed				
Amplifier status display function		Amplifier status display function 2 digits of 7-segment display on Setup Panel (Indicate EtherCAT node ID)				
Regeneration function		A regenerative resistor may be installed externally ^{(*)3}				
Dynamic brake		Built-in				
Speed observer		Available				
Auto-tuning		Available				
Encoder output Division/Multiplication		Available				
Tuning & Function Setup		Available through the S-FLAG II setup software "S-TUNE II"				
Protective functions	By hardware	Overvoltage, low voltage, Overcurrent, Abnormal temperature, Overload				
	By software	Overspeed, Position deviation too high, Parameter errors, Encoder error				
Alarm Log		Can be referenced with the setup software "S-TUNE II"				

1. Specifications

3. Amplifier

1
Specifications


3. Amplifier

Items		Specifications					
Amplifier model		DB64A41		DB65B41	DB66B41	DB67C41	DB68C41
Compatible Motor		MX951 	M□102 	MJ851 	M□152 	MJ132 	M□202 
External dimensions		(See "Dimensions")					
Mass (Kg)		1.1		2.0			
Main circuit power & Control power		Three-phaseAC200~240 V ^{(*)1} ±10% 50 / 60 Hz					
Input current (Arms typ)		Single-phase : 9.9 Three-phase : 5.3		5.3	6.3	8.1	9.2
Control type		Three-phase PWM inverter sine-wave driven					
Output Rating	Rated current (A)	5.8	5.8	6.9	9.5	10.7	12.2
	Output frequencies (Hz)	0-500					
Encoder feedback		23 bit / 17 bit single-turn absolute (The product can function as a multi-turn absolute type when batteries are added.)					
Control signal ^{(*)2}	Input	7-point (24VDC system, photo-coupler input insulation)					
	Output	3-point (24VDC system, photo-coupler output insulation)					
Communication function		EtherCAT (Topology: "Daisy chain", "Star", or "Ring" are available) USB : connection to PC with "S-TUNE II" installed					
Amplifier status display function		Amplifier status display function 2 digits of 7-segment display on Setup Panel (Indicate EtherCAT node ID)					
Regeneration function		A regenerative resistor may be installed externally ^{(*)3}					
Dynamic brake		Built-in					
Speed observer		Available					
Auto-tuning		Available					
Encoder output Division/Multiplication		Available					
Tuning & Function Setup		Available through the S-FLAG II setup software "S-TUNE II"					
Protective functions	By hardware	Overvoltage, low voltage, Overcurrent, Abnormal temperature, Overload					
	By software	Overspeed, Position deviation too high, Parameter errors, Encoder error					
Alarm Log		Can be referenced with the setup software "S-TUNE II"					

3. Amplifier

Notice

- *1) In the Amplifier DB64A41 (1 kW), single-phase can be used for primary circuit power source.
 To use single-phase 200 to 240 VAC, connect it to the primary circuit power connectors L1 and L3.
 For the control power supply, connect L1 and L3 of the main circuit power supply to L1C and L2C, respectively.

Item		Specifications	
Amplifier Model		DB64A41	
Compatible Motor		 (MX951 □ 2 □ □ **, M □ 102 □ 2 □ □ **)	
Primary Circuit Power Supply	Voltage Range	Three-phase 200 to 240 VAC ± 10% 50/60 Hz	Single-phase 200 to 240 VAC ± 10% 50/60 Hz
	Input Current	Rated at 4.5 A (200 VAC input) Rated at 3.8 A (230 VAC input) Up to approximately 13 A	Rated at 8.6 A (200 VAC input) Rated at 7.3 A (230 VAC input) Up to approximately 23 A

- *2) Use SELV (Safety Extra Low Voltage/Non-Hazardous Voltage) power supply to User I/O with reinforced isolation from hazardous voltage.
 As a countermeasure against amplifier failure, install overcurrent protection or use power output capacity of no higher than 100 W.
- *3) Regenerative resistor values do not guarantee optimal performance. If the generated heat temperature becomes too high, increase the resistance value or select a resistor whose allowable power is larger enough. Whether or not a regenerative resistor installation is necessary can be checked on the Setup Panel or S-TUNE II.

1. Specifications

3. Amplifier

Standard I/O

Items	Specifications
Control input	CW limit sensor, CCW limit sensor, Home sensor, External latch(2-point), Alarm reset, Emergency stop
Control output	Brake release, Alarm status, Servo ready

Operation mode

Item	Specifications
Operation mode	EtherCAT communication mode, test mode through S-TUNE II

Environmental Specification

Items	Specifications
Ambient temperature	For operation: 0 to 55°C , For storage: –20 to 65°C
Ambient humidity	For operation/For storage: 20 to 85%RH (No condensation)
Atmosphere for operation and storage	Indoors (not subject to direct sunlight), Free from corrosive gases, flammable gases, oil mist, dust, flammables, grinding fluid
Altitude	≤ 1,000 m
Vibration	≤ 5.8 m/s ² (0.6 G) 10 to 60 Hz (no continuous operation allowed at frequency of resonance)
Dielectric strength	AC 1,500 V for one minute across the primary and FG
Electric shock protection	Class I (mandatory grounding)
Overvoltage category	III
Installation environment	Pollution degree 2

EtherCAT communication Specifications


Items	Specifications
Device Profile	CoE (CANOpen over EtherCAT)
Control mode	csp, csv, cst, hm
hm method (homing mode)	1-6, 17-22, 33-37
Synchronous mode	DC (Synchronized), FreeRun (not-Synchronized)
Cycle Time	250 μs, 500 μs, 1 ms, 2 ms, 4 ms

4. External Dimensions

Figure 1

Motor rated
output power50
W100
W200
W400
W750
W850
W1
kW1.8
kW1.5
kW2
kW

Amplifier model
DB6YZ41
DB6Z141
DB61241




(mm)

Figure 2

Motor rated
output power50
W100
W200
W400
W750
W850
W1
kW1.8
kW1.5
kW2
kW

Amplifier model
DB62441



(mm)

Figure 3




Motor rated
output power50
W100
W200
W400
W750
W850
W1
kW1.8
kW1.5
kW2
kWAmplifier model
DB63841
DB64A41

Figure 4

Motor rated
output power50
W100
W200
W400
W750
W850
W1
kW1.8
kW1.5
kW2
kWAmplifier model
DB65B41
DB66B41
DB67C41
DB68C41

5. Overload Detection Feature

S-FLAG II series amplifiers features overload protection - overload alarm output and emergency stop upon alarm output - in case of motor operation with load level above the overload detection curve shown below.



Overload detection feature is reference data.




Be sure to use the motor within the specification temperature range and in the enough radiation environment. Detection time may change by the radiation condition of the motor.

Mounting and Wiring

1. Installation	2
1. Motor Installation	3
2. Amplifier Installation	5
2. System Wiring	7
1. System Wiring	8
2. Connecting Equipment and Recommended Peripherals	12
3. Wiring to Connectors and Signals	14
1. Motor Connector Pinouts	14
2. Amplifier Connectors and Pinouts	16
3. Wiring to C1 and C2 connectors, or Terminal Blocks	22
4. Descriptions of C5 Connector Signals	23
General-Purpose Output	24
General-Purpose Input	26
Encoder Output	28
5. C5 I/F Circuit	29
4. Cables	32

1. Installation

Installation and Operating Environment




	<p>Ensure that the environments for installation and operation meet the requirements specified in this document.</p> <p>Should you use the product in conditions different from the specifications, please contact us.</p>	 
---	--	---

- Do not install the product where it could be directly exposed to direct sunlight.
- Be sure to install each amplifier inside a control panel.
- Install the product in an environment free from humidity and ingress of water and oil such as cutting oil and oil mist.
- Never use the product in ambient air of explosive or flammable gases, chloride, acidic or alkaline corrosive ambience such as sulfur dioxide, chlorine, ammonia and so on.
- Use the product in an environment free from dust, iron dust, and chips.
- Do not use the product near locations exposed to high temperatures, continuous vibrations, or excessive shock.

Precautions

- I/O device and the host control device must share one power supply (24 VDC).
- When performing maintenance, be sure to turn off the circuit breaker of the main power in advance.
- Be aware of the residual voltage in the amplifier remaining for 15 minutes after the main power shut off.
- Never attempt to replace a fuse.
- Do not touch or block the air vent of the amplifier. Do not place objects which would block the air vent.

Dust-proof and Waterproof



	<p>Be sure to compliance with the IP-code of the motor and amplifier.</p>	 
---	---	---

Amplifier

S-FLAG II Amplifiers are not waterproof structure.

Motor

The protective enclosure rating of motors depends on the rated output. (*)

<p>IP65</p> 	<div> <div>50 W</div> <div>100 W</div> <div>200 W</div> <div>400 W</div> <div>750 W</div> <div>850 W</div> <div>1 kW</div> <div>1.3 kW</div> <div>1.5 kW</div> <div>2 kW</div> </div> <p>MX951</p>
<p>IP67</p> 	<div> <div>50 W</div> <div>100 W</div> <div>200 W</div> <div>400 W</div> <div>750 W</div> <div>850 W</div> <div>1 kW</div> <div>1.3 kW</div> <div>1.5 kW</div> <div>2 kW</div> </div> <p>MX102 MM102 MH102</p>

*) Except for the shaft output component and the connectors.

2. Mounting and Wiring

1. Installation


1. Motor Installation



Do not use any other screws but those in the recommended sizes.








The motor mounting screws are depending on its flange size.



Mounting Hole

Recommended Motor Mounting Screws

Fitting flange size	Mounting Hole	Hexagon socket head bolt	Motor
 40 mm x 40 mm	2- \varnothing 4.5	M4 \times L12 mm	• 50 W • 100 W
 60 mm x 60 mm	4- \varnothing 5.5	M5 \times L12 mm	• 200 W • 400 W
 80 mm x 80 mm	4- \varnothing 6.6	M6 \times L14 mm	• 750 W • 1 kW (MX951)
 100 mm x 100 mm	4- \varnothing 9.0	M8 \times L18 mm	• 850 W • 1 kW (M□ 102)
 130 mm x 130 mm			• 1.3 kW • 1.5 kW • 2 kW

Use a screw longer than the recommended length.

Installation Precautions

Never remove the encoder from the motor or disassemble the motor.

The motor shaft has anti-rust oil applied at the time of shipment. Before installing the motor, wipe off the oil completely.

Perform precise axis alignments. Otherwise, the motor operation will cause vibration or result in shorter service life of the motor.

Shock and Impact Force

When transporting, installing or removing the motor, do not apply excessive impact force or load.

Do not hold the encoder unit, cables, or connectors when carrying the motor.

Shock resistance of the motor is 200 m/s² (20 G) or less.

During installation or operation, radial load or axial load applied to each motor has to be within the withstand rating.

When attaching a coupling to the motor shaft end or removing it, avoid direct impact by a tool such as hammer.

To remove the pulley, coupling, or any other parts from the shaft, use a puller.

1. Installation

Connection with Machines

Use a coupling to absorb angle and direction deviations so that the motor shaft load will be less than the rated allowable axial load.

Otherwise, the bearing life in the motor will be shorter, or the shaft may become damaged.

If you are using a rigid coupling, install it very carefully such that the axial misalignment will be minimal. (Using a flexible coupling is recommended.)

Countermeasure for Oil and Water

Do not use any cable immersed in water or oil.

Install the motor such that the cable side is facing downward.

Do not use the motor in an environment where it will be constantly subjected to oil or water splash.

In the case that a speed reducer to be connected to a motor will be located over the motor shaft, use an oil-sealed motor so that no oil from the speed reducer permeates into the motor.

Types of Mounting and Oil Seal

Our motors can be mounted in two different ways, horizontally and vertically. Observe the following precautions for motor installation.

Horizontal Installation

To protect the motor from oil or water, have the cable-pull side downward.

Vertical Installation

If a speed reducer is connected to a motor such that it will be located over the motor shaft, use an oil-sealed motor so that no oil from the speed reducer permeates into the motor.

Stress to the Cables

Be careful not to apply stress, such as excessive bending or motor weight, to the cable-pull part or its connecting section.

In motor movable operation, be sure to use a flexible cable.

When placing the cable in a cableveyor, minimize the bending stress to the cable.

Bending radii of the motor power cable must be more than R20 mm.

2. Mounting and Wiring

1. Installation

2. Amplifier Installation




Do not turn on the primary circuit power or the control power until all wiring work is completed.



Mounting Orientation and Clearance



When installing amplifiers, secure required clearances for protective enclosures and control panels for heat dissipation and air flow.



- Install all amplifiers vertically. Use M5 screws

50 W, 100 W, 200 W, 750 W, 1 kW : Two-location
400 W, 850 W, 1.3 kW, 1.5 kW, 2 kW : Three-location

B-1 Specifications: Amplifier Dimensions

- If you are mounting the amplifier into an enclosure such as protective casing, use a fan or air conditioner so that the ambient temperature inside each board will not exceed 55°C.
- The temperature of the heat sink at its surface may become 30°C (or more) higher than the ambient temperature.
- Use heat resistant wiring materials and keep amplifiers away from heat-sensitive equipment and wiring.
- The service life of each amplifier depends on the ambient temperatures of the internal electrolytic capacitor. Electrolytic capacitors last approximately 5 to 6 years under the conditions of 30°C annual average temperature, 80% load factor, and 20 hours or less average daily operation.

1. Installation


Mounting Amplifiers



Be sure to mount each amplifier on conductive surface such as aluminum brushed plate.


STEP 1

Hook the U-shaped installation notch of the amplifier to the bolt that has been screwed in advance.




STEP 2







Tighten the mounting screws on the amplifier top.



STEP 3

Loosely screw all amplifier to the chassis first, and then securely tighten them all together. (Tightening torque: 1.4 to 1.6 N·m)



 DANGER		
	Be mindful when wiring and handling high voltage materials	  
	To comply with the EC Directive, select appropriate devices, each of which is compliant with its applicable standards.	
	FG connection is a must.	
	Connect the input power of control power to the same power supply that the primary circuit power is connected to.	
	Do not use the electromagnetic contactor (installed on the primary circuit power side) to run or stop the motor.	
	For high-voltage cables, use wires of 600 V withstand voltage or more.	
	For a C5 connector cable, use a shielded twisted-pair cable of 2 m or less.	
	The encoder cable length must be 20 meters or less.	
	For stranded wire, use insulation coating, rod or ring crimp terminals.	

1. System Wiring

Wiring Pattern 1

Motor rated
output power

50 W

100 W

200 W

400 W

750 W


850 W

1 kW

1.3 kW

1.5 kW

2 kW



This wiring diagram depicts one example configuration:
a 200 W motor and its compatible amplifier.

Wiring Pattern 2

Motor rated
output power

50 W

100 W

200 W

400 W

750 W


850 W

1 kW
MX951

1.3 kW

1.5 kW

2 kW



2. System Wiring

Wiring Pattern 3

Motor rated
output power

50 W

100 W

200 W

400 W

750 W


850 W

1 kW

1.3 kW

1.5 kW

2 kW


MX102
MW102
MH102

When having single-phase power wired to a 1 kW amplifier (DB64A41), wire the main power AC200 V between the L1 and L3 terminals of the amplifier.

Wiring Pattern 4

Motor rated
output power

50 W	100 W	200 W	400 W	750 W	850 W	1 kW	1.3 kW	1.5 kW	2 kW
------	-------	-------	-------	-------	-------	------	--------	--------	------



2. System Wiring

2. Connecting Equipment and Recommended Peripherals

Main circuit power

Please use this product in the power supply environment of Over-Voltage Category II defined by IEC60664-1. This is the primary circuit power for amplifiers.

Using a overvoltage protection relay is recommended.

50 W to 750 W : Single-phase AC200 V to 240 V \pm 10% 50/60 Hz

850 W to 2 kW : Three-phase AC200 V to 240 V \pm 10% 50/60 Hz

- When having single-phase power wired to a 1 kW amplifier, wire the primary circuit AC200 V between the L1 and L3 terminals of the amplifier.
- To avoid unbalance of the three-phase AC200 V wiring in your factory, we recommend that you consider balance of currencies in your three-phase wirings.
- Confirm that your contract with the electric power company is not limited to use of three-phase.

I/O power

This is power supply of DC24 V \pm 10% for I/O power and motor brake release power.

Use a SELV (Safety Extra Low Voltage) power supply with reinforced insulation against hazardous voltages.

Be sure to connect a varistor to the motor braking release power supply.

Cables

Use of UL wires and cables suitable for motor rated output are recommended.

Should you use a cable longer than the specification, please contact us in advance.

High-voltage cables (Main circuit power cable, Control power cable), FG cables:

AWG14 / 600 V breakdown voltage or equivalent

Regenerative resistor connecting cable

AWG18 / 600 V breakdown voltage or equivalent

Motor power cables:

50-750 W : AWG18 / 300 V breakdown voltage or equivalent

850 W-2 kW : AWG14 / 300 V breakdown voltage or equivalent

NOTE: 1 kW motors may use AWG16 cables as well.

Encoder cables:

AWG22 and AWG24 compound / 30 V breakdown voltage or equivalent

Shielded cables with twisted pair wires

Length not exceeding 20 m

User I/O cable:

AWG26 / 300 V breakdown voltage or equivalent

Shielded cables with twisted pair wires

Length not exceeding 2 m

Circuit breaker

To protect the power supply line, circuit breakers shut the circuit down in the event of over-current.

Be sure to use an IEC standard and UL-certified circuit breaker between the power supply and the noise filter.

To ensure compliance with EMC, use an earth leakage circuit breaker that we recommend.

Recommended Product	Fuji Electric Co., Ltd.	Single-phase : EW32AAG-2P020B
		Three-phase : EW32AAG-3P020B

20 A for single-phase (three-phase) 200 V Leakage current of 30 mA.

An equivalent product is acceptable. Select the capacity and other characteristics according to your entire system configuration.

Noise filter

Noise filters prevent ingress of external noise from the power supply line. To ensure compliance with EMC, use the recommended noise filter.

Recommended Product	OKAYA Electric Industries Co., Ltd.	Three-phase: 3SUPF-BE □□ -ER-6- □
---------------------	-------------------------------------	-----------------------------------

Included in S-FLAG II amplifier's EMC testing.

Select the capacity and other characteristics according to your entire system configuration.

2. System Wiring

Electromagnetic contactor

This is an on/off switch for the main power supply. Use a surge absorber on the input side of the primary circuit power supply.

Recommended Product	Fuji Electric Co., Ltd.	SK06G-E10
---------------------	-------------------------	-----------

An equivalent product is acceptable.
Select the capacity and other characteristics according to your entire system configuration.

Surge absorber

To ensure compliance with EMC, connect the recommended surge absorber to the primary side of primary circuit power supply.

Recommended Product	OKAYA Electric Industries Co., Ltd.	Single-phase: LV275DI-Q4 Three-phase: LV275DI-U4
---------------------	-------------------------------------	---

Included in S-FLAG II amplifier's EMC testing

Signal line noise filter/ferrite core

To ensure compliance with EMC, use the recommended signal line noise filter/ferrite core.

Recommended Product	SEIWA ELECTRIC MFG. CO., LTD. (MISUMI)	E045R401938 (ATCK-1130)
---------------------	---	----------------------------

Included in S-FLAG II amplifier's EMC testing

Regenerative resistor










This product is not equipped with regenerative resistor. If the smoothing capacitor inside the servo amplifier cannot absorb regenerative power, an external regenerative resistor is required. As a guideline, check the regeneration state on the settings panel, and use a regenerative resistor if the regenerative voltage warning is ON.

Build an overheating prevention circuit using a resistor which has built-in thermostat.

If the temperature of generated heat becomes high, you can suppress the heat by installing a cooling device, or selecting a resistor whose allowable power is 5 to 10 times larger than regenerative voltage.

Recommended Product	Chiba Techno Co., Ltd.	For 50-750 W : CAN100S 47 Ω J For 1 kW : CAN400S 30 Ω J For 850 W, 1.3-2 kW : CAN750S 20 Ω J
---------------------	------------------------	--

When considering a regenerative resistor other than the recommended above, use the following as a guideline.

Motor Model	 50 W M□ 500	 100 W M□ 101	 200 W M□ 201	 400 W M□ 401	 750 W M□ 751	 1 kW MX951 M□ 102	 850 W MJ851	 1.3 kW MJ132	 1.5 kW M□ 152	 2 kW M□ 202
Rated output	50 W	100 W	200 W	400 W	750 W	1 kW	850 W	1.3 kW	1.5 kW	2 kW
Regeneration resistance	40-50 Ω					30 Ω	20 Ω			
Regeneration allowable voltage	20 W					40 W	60 W			
Recommended Wattage	100-200 W					400-800 W	600-1,200 W			

The regeneration resistance values do not guarantee the optimal performance. Regeneration allowable voltages above are minimum values as a point of reference.

The regeneration resistor may become very hot. It requires sufficient margin of regeneration allowable power.


Grounding

Since this product is Class I device, protective grounding is mandatory.

(Type D grounding: grounding resistance of up to 100 Ω)

Properly ground the product using protective grounding terminals through EMC-compatible casing and control panel.

1. Motor Connector Pinouts



Name	Pin No.	Signal	Description
Motor Power	1	U	Motor power U-phase
	2	V	Motor power V-phase
	3	W	Motor power W-phase
	4	FG	Motor frame ground
Brake ^(*)	1	BRK+	Brake power supply DC24V
	2	BRK-	Brake power supply GND
Encoder (Incremental)	1	-	(No Connect)
	2	+D	Serial communication data + Data
	3	-D	Serial communication data - Data
	4	VCC	Encoder power supply +5 V
	5	SG	Signal ground
	6	SHIELD	Shield
Encoder (Absolute)	1	BAT	External battery ^(*)
	2	-	(No Connect)
	3	SHIELD	Shield
	4	+D	Serial communication data + Data
	5	-D	Serial communication data - Data
	6	-	(No Connect)
	7	VCC	Encoder power supply +5 V
	8	SG	Signal ground
	9	-	(No Connect)

*1) Only for a motor equipped with a brake

*2) Connect the negative pole of the battery to SG (Signal Ground).

2. Mounting and Wiring

3. Wiring to Connectors and Signals

Motor Connector Pinout

Motor rated
output power

50 W

100 W

200 W

400 W

750 W

850 W

1 kW


1.3 kW

1.5 kW

2 kW

MX102
MW102
MH102

Encoder Connector



- Incremental / Absolute
CM10-R10P-D (D7)
(DDK)



- Incremental / Absolute

Straight Plug CM10-SP10S-□-D


Right Angle Plug CM10-AP10S-□-D

□: S, M or L


(DDK)

Wires : AWG22 (Power),
AWG24 (Signal)

Brake Connector



- CM10-R2P-D (D7)
(DDK)



Straight Plug CM10-SP2S-□-D

Right Angle Plug CM10-AP2S-□-D

□: S, M or L

(DDK)

Wires : AWG18

Motor Power Connector



- JL04V-2E18-10PE-B-R
(JAE)



Straight Plug JL04V-6A18-10SE-EB-R

Right Angle Plug JL04V-8A18-10SE-EB-R

(JAE)

Wires : AWG14 (UL)

NOTE: 1 kW motors may use AWG16 cables as well.

Pin orientations are viewed this way

Name	Pin No.	Signal	Description
Motor Power	A	U	Motor power U-phase
	B	V	Motor power V-phase
	C	W	Motor power W-phase
	D	FG	Motor frame ground
Brake ^(*)	1	BRK+	Brake power supply DC24V
	2	BRK-	Brake power supply GND
Encoder (Incremental)	1	VCC	Encoder power supply +5 V
	2	SG	Signal ground
	3, 4	-	(No Connect)
	5	+D	Serial communication data + Data
	6	-D	Serial communication data - Data
	7, 8, 9	-	(No Connect)
	10	SHIELD	Shield
Encoder (Absolute)	1	VCC	Encoder power supply +5 V
	2	SG	Signal ground
	3	-	(No Connect)
	4	BAT	External battery ^(*)
	5	+D	Serial communication data + Data
	6	-D	Serial communication data - Data
	7, 8	-	(No Connect)
	9	SG	Signal ground
	10	SHIELD	Shield

*1) Only for a motor equipped with a brake

*2) Connect the negative pole of the battery to SG (Signal Ground).

3. Wiring to Connectors and Signals

2. Amplifier Connectors and Pinouts

Amplifier Connector Layout

Amplifier Connectors

Motor rated
output power50
W100
W200
W400
W750
W850
W1
kW1.3
kW1.5
kW2
kW

C1

Accessories

Main power and
Control power input
connector (*)

C2


Accessories

Motor power output
connector (*)


*) A special spring opener commonly used in these connectors is an accessory.
To prevent loss, please store in the designated place after use.

Accessories

Spring Opener



1981045-1
(Tyco Electronics JAPAN)



C3

USB connector

C5

User I/O connector

ECIN

EtherCAT Input

ECOUT

EtherCAT Output

C8

Encoder connector

The shape of this amplifier is an example of 200 W.
The connector arrangement is the same for other amplifiers.


Amplifier Connectors

Motor rated
output power50
W100
W200
W400
W750
W850
W1
kW1.3
kW1.5
kW2
kW

Terminal blocks

- Main power and Control power input connector
- External regenerative resistor
- Motor power output connector

Vinyl Insulated
RING TONGUE
TERMINAL 2-4S



C3

USB connector

C5

User I/O connector

ECIN

EtherCAT Input

ECOUT

EtherCAT Output

C8

Encoder connector

The 850 W and 1.3 -2 kW amplifiers shapes are all the same.

2. Mounting and Wiring

3. Wiring to Connectors and Signals

2

Mounting and wiring

3. Wiring to Connectors and Signals

Amplifier Connectors Pinout

Amplifier Connectors Pinout

Motor rated
output power50
W100
W200
W400
W750
W850
W1
kW1.3
kW1.5
kW2
kW

C1

Accessories

Main power and Control
power input connector1-2229794-1
(Tyco Electronics JAPAN)

Pin No.	Signal	Description
1	L1	Main Power (Main Circuit)
2	L2	Main Power (Main Circuit)
3	L3	Main Power (Main Circuit)
4	L1C	Main Power (Control Circuit)
5	L2C	Main Power (Control Circuit)
6	B1/+	External Regenerative resistor connection (+)
7	B2	External Regenerative resistor connection (-)
8	B3	Regenerative resistor connection Switch
9	⊖ 1	(Reserved)
10	⊖ 2	(Reserved)
11	⊖	No Connect

When having single-phase power wired to a 1 kW amplifier (DB64A41), wire the main power AC200 V between the L1 and L3 terminals of the amplifier.

C2

Accessories

Motor Power output
connector3-2229794-1
(Tyco Electronics JAPAN)


Pin No.	Signal	Description
1	U	Motor power U-phase
2	V	Motor power V-phase
3	W	Motor power W-phase

Amplifier Connectors Pinout

Motor rated
output power50
W100
W200
W400
W750
W850
W1
kW1.3
kW1.5
kW2
kW

Terminal blocks

- Main power and Control power input connector
- External regenerative resistor
- Motor power output connector



Signal	Description
L1	Main Power (Main Circuit)
L2	Main Power (Main Circuit)
L3	Main Power (Main Circuit)
L1C	Main Power (Control Circuit)
L2C	Main Power (Control Circuit)
P	External Regenerative resistor connection (+)
RB	(No Connect)
B	External Regenerative resistor connection (-)
N	(No Connect)
U	Motor power U-phase
V	Motor power V-phase
W	Motor power W-phase

3. Wiring to Connectors and Signals


Amplifier Connectors Pinout

Amplifier Connectors Pinout

Motor rated
output power50
W100
W200
W400
W750
W850
W1
kW1.3
kW1.5
kW2
kW

C3

USB connector




USB mini B

Pin No.	Signal	Description
1	VBUS	USB power supply +5 V
2	D-	USB data -
3	D+	USB data +
4	-	(No Connect)
5	SG	USB signal ground

C8

Encoder connector




Connector: 3E206-0100KV (3M)
 Cover: 3E306-3200-008 (3M)
 Wires: AWG22 (Power), AWG24 (Signal)

Pin No.	Signal	Description
1	VCC	Encoder power supply +5 V
2	SG	Signal ground
3, 4	-	(No Connect)
5	+D	Encoder signal data +
6	-D	Encoder signal data -
SHELL	FG	SHIELD wired to the connector casing

ECIN

ECOUT

EtherCAT Connector




RJ45

Pin No.	Signal	Description
1	TX+	Transmit / Receive data +
2	TX-	Transmit / Receive data -
3	RX+	Receive / Transmit data +
4, 5	-	(No Connect)
6	RX-	Receive / Transmit data -
7, 8	-	(No Connect)
SHELL	FG	SHIELD wired to the connector casing

Be sure to use TIA/EIA -568 Category 5 e or higher (Shielded) cables.

C5

User I/O connector



(26 pin)

Connector 10126-3000-PE (3M)
 Cover 10326 (3M)
 or Equivalent alternatives
 Wires : AWG26

2. Mounting and Wiring

3. Wiring to Connectors and Signals


Pinout Diagram

A pinout diagram of C5 connector pinout. Pins are grouped to three categories.

Pins Group	Description
General-Purpose Input INPUT	Input terminals connecting from the host controller, such as I/O power, and control signals. You can change the input logic. (*)
General-Purpose Output OUTPUT	An output terminal such as Servo Status that connects to the host controller. You can change the output logic. (*)
Encoder Output	A terminal to output encoder pulse to the host controller.

*)  Page 23 Descriptions of C5 Connector Signals

A pinout diagram illustrates the pinout on the User I/O Connector soldering surface. Do not connect anything to reserved pins.



C5 Connector Wiring Example

Example of C5 Connector wiring.

For actual wiring, check the pin numbers etched on the connector body as well.

For further details, refer to Descriptions of C5 Connector Signals and Interface Circuit of C5 Connector.


 Page 23 Descriptions of C5 Connector Signals

 Page 29 I/F Circuit of C5 Connector

3. Wiring to Connectors and Signals

C5 User I/O Connector

Pinout Diagram




Connector 10126-3000-PE (3M)
 Cover 10326 (3M)
 or Equivalent alternatives
 Wires : AWG26

Encoder Output

Pin No.	Signal Description
16	SG Signal ground
17	OUT_A A-phase
18	/OUT_A /A-phase
19	OUT_B B-phase
20	/OUT_B /B-phase
21	OUT_Z Z-phase
22	/OUT_Z /Z-phase

General-Purpose Output



I/O Connector pinout
on the soldering surface

General-Purpose Output		General-Purpose Input	
Pin No.	Signal Description	Pin No.	Signal Description
1	MBRK+ Brake release +	6	COM+ I/O Power 24 V
2	MBRK- Brake release -	7	POT CW Limit Sensor
3	ALM + Alarm status +	8	NOT CCW Limit Sensor
4	ALM- Alarm status -	9	ORG Home position sensor
25	SRDY + Servo ready +	10	EXT1 External Latch 1
26	SRDY- Servo ready -	11	EXT2 External Latch 2
		12	RESET Alarm reset
		13	E-STOP Emergency stop

3. Wiring to Connectors and Signals

3. Wiring to C1 and C2 connectors, or Terminal Blocks



DANGER



Be sure to follow the following precautions when wiring to the C1 and C2 connectors.

- Be sure to disconnect the connector from the amplifier before wiring.
- Insert one cable at each wire insertion point.
- When inserting the cable, be careful not to let the whiskers of the wires protrude from the wire insertion port, and do not touch other wires or electrodes.
- Connect the power to the amplifier after all wiring is completed.



STEP
1

Trimming the cable wrap.



C1 and C2 connector:



Terminal Blocks:



STEP
2

Amplifiers of 1 kW and 750 W or less are wired to C1 and C2 connectors. Remove the C1 and C2 connectors from the amplifier.


STEP
2

Amplifiers of 850 W and 1.3 kW or higher are screw terminals. Connect the cable with round terminals.

Recommended Terminal:
2 -4 S Round Terminal with Insulation


STEP
3

Attach the spring opener to the connector and press it down.



STEP
4

Insert the wires until they meet. Then release the spring opener to fix the wires.




STEP
5

Connect the C1 and C2 connectors to the amplifier.

STEP
3

Tighten the round terminals.
(tightening torque of 1.0 -1.2 N·m.)




2. Mounting and Wiring

3. Wiring to Connectors and Signals


4. Descriptions of C5 Connector Signals

Review the functions of each pin of C5 connector before using the product.



3. Wiring to Connectors and Signals

General-Purpose Output


Pin No.	1, 2	I/F Circuit	PO (P. 30)
Signal	Description		
	<div>OFF</div> <p>Does not release the brake.</p>		
	<div>ON</div> <p>Releases the brake.</p>		
	<p>■ TIP</p> <p>The motor brake cannot be driven directly. To drive the motor brake, be sure to use a relay.</p> <p>Place a surge absorber to suppress surge voltage caused by relay's on/off. Note that, if you use a diode instead of a surge absorber, the time between brake release and brake clamp is longer.</p>		

OUTPUT

MBRK+ (Pin No.1)

MBRK- (Pin No.2)

Brake Release

Pin No.	3, 4	I/F Circuit	PO (P. 30)
Signal	Description		
	<div>OFF</div> <p>In one of the following conditions</p> <p>An alarm is occurring.</p> <p>Control power is not supplied to the amplifier.</p>		
	<div>ON</div> <p>The following conditions are met at the same time.</p> <p>No alarm is occurring.</p> <p>Control power is supplied to the amplifier.</p>		
	<p>■ TIP</p> <p>The emitter side of the output transistor is independent of COM-. Cascade connection to multiple amplifiers is possible.</p>		


OUTPUT

ALM+ (Pin No.21)

ALM- (Pin No.22)




Alarm

 Z- 1 Troubleshooting Alarms and Remedies

Pin No.	25, 26	I/F Circuit	PO (P. 30)
Signal	Description		
 OUTPUT SRDY+ (Pin No.25) SRDY- (Pin No.26) Servo ready	OFF In one of the following conditions An alarm is occurring. The primary circuit power is not supplied to the amplifier.		
	ON The following conditions are met at the same time. No alarm is occurring. The primary circuit power is supplied to the amplifier.		
	TIP The emitter side of the output transistor is independent of COM-. Cascade connection to multiple amplifiers is possible.		

3. Wiring to Connectors and Signals

General-Purpose Input


Pin No.	6	I/F Circuit	PS (P. 29)
Signal	Description		
COM+ I/O power supply 24 V input	<p>A common power supply for optical isolators of general-purpose input circuit. Power voltage: DC24 V \pm 10% Use SELV power supply with reinforced insulation that is isolated from hazardous voltages.</p>		
Pin No.	7	I/F Circuit	PI (P. 29)
Signal	Description		
<div>INPUT</div>  <p>POT CW Limit Sensor</p>	<div>OPEN</div> <p>CW Limit Sensor signal input is not detected.</p> <div>CLOSED</div> <p>CW Limit Sensor signal input is detected.</p>		
Pin No.	8	I/F Circuit	PI (P. 29)
Signal	Description		
<div>INPUT</div>  <p>NOT CCW Limit Sensor</p>	<div>OPEN</div> <p>CCW Limit Sensor signal input is not detected.</p> <div>CLOSED</div> <p>CCW Limit Sensor signal input is detected.</p>		
Pin No.	9	I/F Circuit	PI (P. 29)
Signal	Description		
 <div>INPUT</div> <p>ORG Home Sensor</p>	<div>OPEN</div> <p>Home sensor has not been detected.</p> <div>CLOSED</div> <p>Home sensor has been detected.</p> <p>■ Related Parameters</p> <ul style="list-style-type: none"> •No.645.0 Enables you to select home-dog-front. •No.646.1 Enables you to change the polarity of home sensor detection. 		



2. Mounting and Wiring


3. Wiring to Connectors and Signals

2
Mounting and wiring

3. Wiring to Connectors and Signals

Pin No.	10, 11	I/F Circuit	PI (P. 29)
Signal	Description		
<input type="button" value="INPUT"/> EXT1 External Latch 1 EXT2 External Latch 2	 <div> <input type="button" value="OPEN"/> Position feedback data is not latched. <input type="button" value="CLOSED"/> Position feedback data is latched by the timing to which a signal was input. </div>		

Pin No.	12	I/F Circuit	PI (P. 29)
Signal	Description		
 <input type="button" value="INPUT"/> RESET Alarm Reset	<div> <input type="button" value="CLOSED"/> Resets an alarm. </div> <div> <p>■ TIP</p> <ul style="list-style-type: none"> •Be sure to turn off this signal after alarm reset execution. •Encoder-, product code-, and system- alarms are not reset by this signal. •You must cycle control power of the amplifier. </div> <div>  Z- 1 Troubleshooting Alarms and Remedies </div>		


Pin No.	13	I/F Circuit	PI (P. 29)
Signal	Description		
<input type="button" value="INPUT"/> E-STOP Emergency Stop	<div> <input type="button" value="OPEN"/> The motor makes an emergency stop. Deceleration stop starts upon Servo OFF and the motor stops its motion. No alarm occurs. A warning is output by parameter setting. </div> <div>  Z- 2 Technical Information Functions </div>		

Encoder Output

Pin No.	16–22	I/F Circuit	EO (P. 31)
Signal	Description		
OUT_A (Pin No.17) /OUT_A (Pin No.18) A-phase output	OUT_A, /OUT_A: OUT_B, /OUT_B: OUT_Z, /OUT_Z: Differential output of encoder signal divided and multiplied (equivalent to RS-422)		
OUT_B (Pin No.19) /OUT_B (Pin No.20) B-phase output	SG: Signal ground of the communication IC in the output circuit. This signal is connected to signal ground inside the amplifier. It is isolated from control power (G24 V, COM–). Make the connection to signal ground of the communication IC of the host controller.		
OUT_Z (Pin No.21) /OUT_Z (Pin No.22) Z-phase output			
SG (Pin No.16) Signal ground			

PS Connection to DC24V Power Supply

Connect I/O power supply.


**PI** Connections to General-Purpose Input Signal**Pin No.6**

Connect to I/O power supply. Use power supply of $24\text{ V} \pm 10\%$.

Pin No.7 to No.13

Connect to input devices such as switch, open-collector output transistor, and relay contact.

When the input device contact is closed and the contact pair of general-purpose pin and power supply GND becomes closed, the amplifier turns on.



3. Wiring to Connectors and Signals

PO Connections to General-Purpose Output Signal


The motor brake cannot be driven directly. To drive the motor brake, be sure to use a relay.

When driving a load containing inductance component such as relay, connect a protection circuit (diode). Install a diode in the direction shown in the figure below.

The output circuit configuration is an open collector Darlington transistor output. Connects to relays and optical isolators. When the transistor is on, connector-emitter voltage $V_{CE(SAT)}$ is approximately 1 V; a standard TTL IC does not satisfy V_{IL} , and cannot be directly connected.

The maximum rating of output circuit is 30 V 50 mA.

The emitter side of the output transistor is independent.



EO Connection to Encoder Output Circuit

Differential output of encoder signal (A-phase, B-phase, Z-phase) which has been processed with pulse division ratio.


Be sure to connect a termination resistor to the receiver circuit of the host controller.

Approximately $220\ \Omega$ (1/4 W or more)


Signal ground of the communication IC in the output circuit is connected to signal ground inside the amplifier.

Connect signal ground of communications IC of the host controller to Pin No.16.

Be sure to use shielded twisted-pair cable as a noise countermeasure.



Encoder Z-phase is synchronized with A-phase and output.



2. Mounting and Wiring

4. Cables

Recommended cable wires

Connection cables required for this product are sold separately. Those can be purchased at the MISUMI online store.

Use our recommendations below to select cables based on your actual usage. (Equivalent alternatives are also good)
Should you use a cable longer than the specification, please contact us in advance.

Cable Name	AWG	UL	Temperature Rating	Voltage Rating	Note
Motor power (≤ 750 W)	18	2517	105°C	300 V	
Motor power (≥ 850 W)	14	2517	105°C	300 V	AWG16 wires can be used only for 1 kW motors
Main circuit power (Including FG cable)	14	1015	105°C	600 V	AWG16 wires can be used only for 1 kW motors.
Encoder	Power : 22 Signal : 24	20276	80°C	30 V	Shielded twisted pair cables of length no exceeding 20 m
User I/O	26	1007	80°C	300 V	Shielded twisted pair cables of length no exceeding 2 m
Regenerative resistor	18	1015	105°C	600 V	
Brake	18	2517	105°C	300 V	1 pair (2 cores)

Cable Name	Specification	Note
EtherCAT communication	CAT5e	Shielded cable is recommended

2. Mounting and Wiring

4. Cables


Motor Power Cable

Motor rated
output power50
W100
W200
W400
W750
W850
W1
kW1.3
kW1.5
kW2
kW

MX951

4 HOUSING

Pin No.	Signal	Color
1	U	RED
2	V	WHITE
3	W	BLUE
4	FG	GREEN - YELLOW




No.	Item	Model	Supplier
1	CABLE	NA3CT-18-4 (for fixed wiring) NA3CTR-18-4 (for movable wiring)	MISUMI Group Ink
2	RING TONGUE TERMINAL	R2-4	J.S.T. Mfg. Co., Ltd.
3	FERRULE	216-143	WAGO JAPAN
4	HOUSING	172159-1	Tyco Electronics JAPAN
5	TERMINAL	170366-1	Tyco Electronics JAPAN
6	SUMITUBE	F(Z) 11x0.25	Sumitomo Electric Industries
7	(MARKER TUBE)	(arbitrary)	(arbitrary)

Motor Power Cable

Motor rated
output power50
W100
W200
W400
W750
W850
W1
kW1.3
kW1.5
kW2
kWMX102
MM102
MH102

4 PLUG

Pin No.	Signal	Color
1	U	RED
2	V	WHITE
3	W	BLUE
4	FG	GREEN - YELLOW



No.	Item	Model	Supplier
1	CABLE	NA6CT-14-4 (for fixed wiring) NA6CTR-14-4 (for movable wiring)	MISUMI Group Ink
2	RING TONGUE TERMINAL	R2-4	J.S.T. Mfg. Co., Ltd.
3	FERRULE	216-106	WAGO JAPAN
4	PLUG	JL04V-6A18-10SE-EB-R	JAЕ
5	CABLE CLAMP	JL04V-18CK13-CR-R	JAЕ
6	SUMITUBE	F(Z) 14x0.3	Sumitomo Electric Industries
7	(MARKER TUBE)	(arbitrary)	(arbitrary)


4. Cables

Encoder Cable

Motor rated
output power50
W100
W200
W400
W750
W850
W1
kW1.3
kW1.5
kW2
kW

(Incremental)

MX951



No.	Item	Model	Supplier
1	CABLE	NA20276TSB-C (for fixed wiring) NA20276RRSB-C (for movable wiring)	MISUMI Group Ink
2	HOUSING	3E206-0100KV	3M
3	COVER	3E306-3200-008	3M
4	HOUSING	172160-1	Tyco Electronics JAPAN
5	TERMINAL	170365-1	Tyco Electronics JAPAN
6	SUMITUBE	F(Z) 7x0.25	Sumitomo Electric Industries
7	SUMITUBE	F(Z) 3/64 or 1.5x0.2	Sumitomo Electric Industries

Encoder Cable


Motor rated
output power50
W100
W200
W400
W750
W850
W1
kW1.3
kW1.5
kW2
kW

(Incremental)

MX102

MM102

MH102



No.	Item	Model	Supplier
1	CABLE	NA20276TSB-C (for fixed wiring) NA20276RRSB-C (for movable wiring)	MISUMI Group Ink
2	HOUSING	3E206-0100KV	3M
3	COVER	3E306-3200-008	3M
4	HOUSING	CM10-SP10S-M	DDK
5	TERMINAL	CM10-#22SC(C1)(D8)	DDK
6	TERMINAL	CM10-#22SC(C2)(D8)	DDK
7	SUMITUBE	F(Z) 7x0.25	Sumitomo Electric Industries
8	SUMITUBE	F(Z) 3/64 or 1.5x0.2	Sumitomo Electric Industries

2. Mounting and Wiring


4. Cables

Encoder Cable

Motor rated
output power50
W100
W200
W400
W750
W850
W1
kW1.3
kW1.5
kW2
kW

(Absolute)

MX951



No.	Item	Model	Supplier
1	CABLE	NA20276TSB-C (for fixed wiring) NA20276RRSB-C (for movable wiring)	MISUMI Group Ink
2	HOUSING	3E206-0100KV	3M
3	COVER	3E306-3200-008	3M
4	HOUSING	172161-1	Tyco Electronics JAPAN
5	TERMINAL	170365-1	Tyco Electronics JAPAN
6	TERMINAL	170366-1	Tyco Electronics JAPAN
7	SUMITUBE	F(Z) 7x0.25	Sumitomo Electric Industries
8	SUMITUBE	F(Z) 3/64 or 1.5x0.2	Sumitomo Electric Industries
9	HOUSING	DF3-2EP-2C	Hirose Electric
10	TERMINAL	DF3-EP2428PCFA	Hirose Electric
11	CABLE	NAUL1007-24-BK	MISUMI Group Ink
12	CABLE	NAUL1007-24-R	MISUMI Group Ink

4. Cables

Encoder Cable

Motor rated
output power

50 W

100 W

200 W

400 W

750 W

850 W


1 kW

1.3 kW

1.5 kW

2 kW

(Absolute)

MX102
MM102
MH102

No.	Item	Model	Supplier
1	CABLE	NA20276TSB-C (for fixed wiring) NA20276RRSB-C (for movable wiring)	MISUMI Group Ink
2	HOUSING	3E206-0100KV	3M
3	COVER	3E306-3200-008	3M
4	HOUSING	CM10-SP10S-M	DDK
5	TERMINAL	CM10-#22SC(C1)(D8)	DDK
6	TERMINAL	CM10-#22SC(C2)(D8)	DDK
7	SUMITUBE	F(Z) 7x0.25	Sumitomo Electric Industries
8	SUMITUBE	F(Z) 3/64 or 1.5x0.2	Sumitomo Electric Industries
9	HOUSING	DF3-2EP-2C	Hirose Electric
10	TERMINAL	DF3-EP2428PCFA	Hirose Electric
11	CABLE	NAUL1007-24-BK	MISUMI Group Ink
12	CABLE	NAUL1007-24-R	MISUMI Group Ink

2. Mounting and Wiring

4. Cables


Brake Cable

Motor rated
output power50
W100
W200
W400
W750
W850
W1
kW1.3
kW1.5
kW2
kW

MX951

2 HOUSING

Pin No.	Signal	Color
1	BRK +	BRACK
2	BRK -	BRACK




No.	Item	Model	Supplier
1	CABLE	MAST-UL2517-19-2 (for fixed wiring) NA3UCR-18-2 (for movable wiring)	MISUMI Group Ink
2	HOUSING	172157-1	Tyco Electronics JAPAN
3	TERMINAL	170366-1 or 170639-1	Tyco Electronics JAPAN
4	SUMITUBE	F(Z) 8x0.25	Sumitomo Electric Industries

Brake Cable

Motor rated
output power50
W100
W200
W400
W750
W850
W1
kW1.3
kW1.5
kW2
kWMX102
MM102
MH102

2 PLUG

Pin No.	Signal	Color
1	BRK +	BRACK
2	BRK -	BRACK



No.	Item	Model	Supplier
1	CABLE	MAST-UL2517-19-2 (for fixed wiring) NA3UCR-18-2 (for movable wiring)	MISUMI Group Ink
2	PLUG	CM10-SP2S-M-D	DDK
3	CONTACT	CM10-#22SC(S2)(D8)-100	DDK
4	SUMITUBE	F(Z) 8x0.25	Sumitomo Electric Industries

MEMO



PARAMETER

1. Setup Panel
2. Parameter
3. Tuning

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Setup Panel

1. Names of Parts.....	2
2. Functions — 7-segment display.....	3

1. Names of Parts



7-segment display

2-digit

EtherCAT node address

Status (Alarm and Warning)

Servo status



EtherCAT Status Indicator LED

RUN (Green)

This shows an operational status of a servo amplifier.

ERR (Red)

It lights up when an error occurs.

L/A IN (Green) Link/Activity IN

This shows the EtherCAT communication state.

L/A OUT (Green) Link/Activity OUT


This shows the EtherCAT communication state.

Rotary Switch

Setting the EtherCAT node address

Left Switch: Setting the 10th place of node address

Right Switch: Setting the 1st place of node address



Left Switch

Right Switch

Set the node address before turning on the power.


Character table for 7-segment LED display

A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S
8	6	2	8	8	8	0	8	8	0	-	0	0	8	0	8	8	8	9
		0										8	8	0				
T	U	V	W	X	Y	Z	0	1	2	3	4	5	6	7	8	9	+	-
8	0	0	-	-	-	-	0	1	2	3	4	5	6	7	8	9	8	8
8	0																	

1. Setup Panel


2. Functions — 7-segment display

When the control power supply is turned on, the following items are displayed on the 7-segment display.



How to distinguish by lighting a period


You can identify the status displayed by the lighted position of the period segment.



How to display multiple alarms and/or warnings

When multiple alarms (and /or warnings) are generated, the alarm is displayed at one-second intervals. When all alarms are displayed, the lamp goes off for 2 seconds and the alarm is displayed repeatedly.

Example) When alarm No. 2, No. 17 or No. 19 is happening



MEMO

Parameters

1. Introduction	2
2. List of Parameters.	4
1. In the order of S-TUNE II display.	4
2. In the order of parameter No..	9
3. Details of Parameters.	13
1. Basic Parameters	13
Basic Settings.	13
Stop Settings	17
Error Detection Settings	26
2. Position Control Mode.	31
Position Command Input	31
Tuning Parameters	33
Homing.	39
3. Velocity Control Mode	51
Velocity Command Input	51
Tuning Parameters	52
4. Torque Control Mode	54
Torque Command Input.	54
5. Vibration Suppress Filter	55
Position Command Filter	55
Torque Command Filter	61

1. Introduction


Remark

Some of the tuning parameters are dependent on the settings of other parameters, which makes the values of dependent parameters invalid even if they are within the specification range.




Control Mode	Name	No.
Position Control Mode	Control gain 1	115.0
	Control gain 2	116.0
	Gain FF compensation 1	117.0
	Gain FF compensation 2	118.0
	Integral gain	119.0
Velocity Control Mode	Control gain 1	131.0
	Gain FF Compensation 1	132.0
	Integral gain	133.0

Overview of the parameter list




Title Header




Parameter Description


Parameter Number		Parameter Name		Parameter Characteristics	
No. 74.0 (204Ah)	Position command filter 1: Notch frequency	Range	Default	Characteristics	
		10 to 2,000	10 [0.1 Hz]	 --  	
Function Use	Set the notch frequency for Position command filter 1.				
Prerequisite	Position command filter 1: Type (No.66.0) = 2 (Notch filter) or 3 (γ-Notch filter)				
Related To	No.66.0、 No.75.0、 No.76.0、 No.79.0				


Characteristics

 --  

Parameter Attribute Icon

 Group 5 (Dark Blue) Indicates that it can be set by EtherCAT communication

 Group 3 (Yellow) Indicates the type of the settings.

 Group 4 (Green) Indicates that control-power cycle is required.

Characteristics of Parameters

The parameters are categorized into five groups according to their functions, uses, and features. The following icons are used to represent their characteristics.

Group	Icon	Meaning
1 (Red)		Basic Used for all Control Modes
		Position Control Mode Used for Position Control Mode
		Velocity Control Mode Used for Velocity Control Mode
		Torque Control Mode Used for Torque Control Mode
2 (Blue)		Operation Control Used for setting the operation method.
		Stop Setting Used for configuring Stop processes in case of emergency or drive restriction
		Tuning Gain parameters that require Tuning
		Homing Used for positioning operation in Position Control Mode
		Alarm Detection Used for configuring Alarm Detection and Timing of Alarm Detection
		Position Control Internal Command Used for Internal Position Command in Position Control Mode
		Vibration Control Parameters related to Vibration Control
3 (Yellow)		Switch Parameters to enable or disable functions
		Selection Used for selecting conditions from multiple items based on your operational purposes
		Numeric Value Numeric values are set for these parameters, for example, pulse paired ratio or filter setup parameters.
4 (Green)		Control Power Cycle Those parameters need power cycling for their setting changes to take effect.
5 (Dark Blue)		EtherCAT Communication These parameters allow access to the amplifier via EtherCAT communication.
		Object Dictionary These parameters are related to the EtherCAT communication object dictionary.
		Hide These parameters are hidden by S-TUNE II during EtherCAT communication.
		Read Only These parameters cannot be written from S-TUNE II to the amplifier during EtherCAT communication.
































2. Parameters

2. List of Parameters

1. In the order of S-TUNE II display

Basic Parameters



Name		EtherCAT	No.
Basic Settings 	Control mode		2.0
	Command mode		3.0
	Torque command limit	Switch	 144.0
		Torque limit output	 144.1
		Value 1	 147.0
	Torque command offset	 2092h	146.0
	Servo OFF: Delay time	 20EDh	237.0
	Brake release: Delay time	 20EEh	238.0
	Absolute system	 2101h	257.0
	Wraparound	Minimum value	 21CAh
		Maximum value	 21CCh
Stop Settings 	Setup		 2043h
	Drive Restriction Input	Deceleration method	 2043h
		Idling status	 2043h
		Retaining position deviation counter	 2043h
		Torque command limit	
	Upon Servo Off	Method	 20E0h
		DBRK output after stopping	 20E0h
	When alarm is on	Method	 20E9h
		DBRK output after stopping	 20E9h
	Deceleration Stop	Release conditions	 20E0h
		Operating time	 20E2h
		Cancellation speed	 20E3h
		Upon control power failure	Switch
			Operating time
	Brake engagement	Status during free-run	 20E8h
		Timing	 20E8h
		Delay time	 20EAh
		Rotational speed	 20EBh
		Smoothing filter	Switch
			Moving average counter
	Quick Stop	Short brake operation after a stop	 20E8h
		Extension Time	 20ECh
		Deceleration time	 20EFh
 P.17-	Emergency Stop (*)	Warning output	Switch
			Timing

*) This parameter is described in "Error detection setting".

2. Parameters

2. List of Parameters

In the order of S-TUNE II display

Basic Parameters



Name		EtherCAT	No.
Error detection settings 	Warning latch time	200Ch	12.0
	Alarm output timing	200Dh	13.0
	Position deviation	2041h	65.0
	Error detection	6065h	87.0
	Delay time		89.0
	Position deviation	216Bh	363.0
	Warning detection	206Dh	365.0
	Delay time		
	Speed deviation	2041h	65.1
	Error detection	205Ah	90.0
	Delay time	205Bh	91.0
	Emergency stop		
	Warning output	20E1h	225.0
	Timing	20E1h	225.1
	Overheat detection	2103h	259.0
	Value	210Bh	267.0
Encoder	Battery Voltage drop detection	2103h	259.1
	Switch	210Ch	268.0
	Value		
	Motor rotating position at encoder error	2178h	376.0
	Holding method	2179h	377.0
	Holding time		
	Voltage Sag Detection Delay time	2131h	305.0
	EtherCAT communication setting	21DAh	474.0
P.26-	Internal position - Overflow detection		643.0











































This list may be different from the order in which S-TUNEII displays it.

2. List of Parameters

In the order of S-TUNE II display

Position Control Mode



Name			 EtherCAT	No.
Position command input  P.31-	EtherCAT communication	Interpolation	 2020h	32.2
		Pulse ratio	 6091-01h	34.0
		Numerator	 6092-02h	36.0
		Denominator	 2042h	66.3
		Feed forward delay compensation	 2066h	102.0
Tuning Parameters Settings  P.33-	Tuning	Inertia ratio	 2067h	103.0
		Damping ratio	 206Ah	106.0
		Inertia ratio upper bound	 206Eh	110.0
		Mode switch	 206Eh	110.1
		Tuning items	 2078h	120.0
	Gain parameter	Automatic switch	 2078h	120.1
		Control gain set	 2079h	121.0
		Upper bound	 2071h	113.0
		Tuning constant	 2071h	113.1
		Control level	 2072h	114.0
	Gain parameter	Control gain 1	 2073h	115.0
		Control gain 2	 2074h	116.0
		Gain FF compensation 1	 2075h	117.0
		Gain FF compensation 2	 2076h	118.0
		Integral gain	 2077h	119.0
	Current control gain		 20C1h	193.0
Homing  P.39-	Home reference signal selection		 645.0	645.0
	Encoder Z-phase selection		 645.1	645.1
	Re-detection of home position dog		 645.3	645.3
	Direction		 646.0	646.0
	Sensor dog polarity		 646.1	646.1
	Timeout	Switch	 646.2	646.2
		Time	 659.0	659.0
	Torque command limit	Switch	 647.0	647.0
		Value	 656.0	656.0
	Time to detect press stopper		 655.0	655.0
	Creep speed switch		 647.1	647.1
	Rapid speed		 648.0	648.0
	Creep speed		 649.0	649.0
	Acceleration/Deceleration time		 650.0	650.0
	Amount of home position shift		 651.0	651.0
	Home position data		 653.0	653.0
	Z-phase disabled distance		 657.0	657.0

The point table parameters for internal position control are not displayed on the parameter tab screen of S-TUNE II. These parameters are displayed in the Point Table tabbed screen. See page 44 and later for detailed descriptions of the parameters.


















2. Parameters

2. List of Parameters

In the order of S-TUNE II display

Velocity Control Mode









Name		 EtherCAT	No.
Velocity Command Input 	EtherCAT communication	Rotational direction	 203Eh 62.0
	 P.51-		
Tuning Parameters Settings 	Tuning Parameter (*)	Inertia ratio	 2066h 102.0
		Damping ratio	 2067h 103.0
		Inertia ratio upper bound	 206Ah 106.0
		Mode switch	 206Eh 110.0
		Items	 206Eh 110.1
	Gain Parameter	Control gain set	 2081h 129.0
		Control level	 2082h 130.0
		Control gain 1	 2083h 131.0
		Gain FF compensation 1	 2084h 132.0
		Integral gain	 2085h 133.0
	 P.52-	Current control gain	 20C1h 193.0

*) These parameters are common to the position control mode. For details of each parameter, refer to the corresponding page of the position control mode.

Torque Control Mode



Name		 EtherCAT	No.
Torque Command Input   P.54-	EtherCAT communication	Direction of rotation	 212Eh 302.0
		Speed Limit	 6080h  152.0

2. List of Parameters

In the order of S-TUNE II display

Vibration Suppress Filter

































Name			EtherCAT	No.
Position Command Filter (*) 	Filter 1	Selection	2042h	66.0
		Smoothing 1 Moving average counter	2050h	80.0
		Notch frequency	204Ah	74.0
		Notch width	204Bh	75.0
		High frequency gain	204Ch	76.0
		Notch depth	204Fh	79.0
	Filter 2	Selection	2052h	82.0
		Notch frequency	2053h	83.0
		Notch width	2054h	84.0
		High frequency gain	2055h	85.0
		Notch depth	2056h	86.0
	Filter 3	Selection	2052h	82.1
		Notch frequency	2165h	357.0
		Notch width	2166h	358.0
		High frequency gain	2167h	359.0
	Filter 4	Notch depth	2168h	360.0
		Selection	2042h	66.1
Torque Command Filter 	Low-pass filter	Smoothing 2 Moving average counter	2051h	81.0
		Switch	20A0h	160.0
		Auto setting	20A0h	160.2
	Notch filter	Time constant	20A2h	162.0
		Switch	20A0h	160.1
		Frequency	20A8h	168.0
		Width	20A9h	169.0
	Notch filter 2	Depth	20AAh	170.0
		Switch	20A0h	160.3
		Frequency	20ABh	171.0
		Width	20ACh	172.0
		Depth	20ADh	173.0

*) The position command filter is used only in the position control mode.





2. Parameters

2. List of Parameters

2. In the order of parameter No.








































No.	Name	 EtherCAT	
2.0	Control mode		P. 13
3.0	Command mode		 P. 13
12.0	Warning latch time	 200Ch	P. 26
13.0	Timing for alarm output	 200Dh	P. 26
32.2	EtherCAT Communication - Auto interpolations for paired ratio	 2020h	P. 31
34.0	EtherCAT Communication - Paired ratio (Numerator)	 6091h	P. 32
36.0	EtherCAT Communication - Paired ratio (Denominator)	 6091h	P. 32
62.0	EtherCAT Communication Velocity command - Rotational direction	 203Eh	P. 51
65.0	Position deviation excess detection - Switch	 2041h	P. 27
65.1	Speed deviation error detection - Switch	 2041h	P. 27
66.0	Position command filter 1 - Type	 2042h	P. 55
66.1	Position command filter 4 - Selection	 2042h	P. 55
66.3	EtherCAT Communication - Feedforward delay compensation	 2042h	P. 32
67.0	Drive restriction input - Setup	 2043h	P. 17
67.1	Drive restriction input - Deceleration method	 2043h	P. 17
67.2	Drive restriction input - Standstill state	 2043h	P. 17
67.3	Drive restriction input - Keep position deviation counter	 2043h	P. 17
74.0	Position command filter 1 - Notch Frequency	 204Ah	P. 56
75.0	Position command filter 1 - Width	 204Bh	P. 56
76.0	Position command filter 1 - High frequency gain constant	 204Ch	P. 56
79.0	Position command filter 1 - Depth	 204Fh	P. 56
80.0	Position command smoothing filter 1 Moving average order	 2050h	P. 57
81.0	Position command filter 4 - smoothing 2 moving average order	 2051h	P. 57
82.0	Position command filter 2 - Type	 2052h	P. 58
82.1	Position command filter 3 - Type	 2052h	P. 58
83.0	Position command filter 2 - Notch Frequency	 2053h	P. 58
84.0	Position command filter 2 - Width	 2054h	P. 58
85.0	Position command filter 2 - High frequency gain constant	 2055h	P. 59
86.0	Position command filter 2 - Depth	 2056h	P. 59
87.0	Position deviation error detection - Value	 6065h	 P. 27
89.0	Position deviation error detection - Delay time		P. 27
90.0	Speed deviation error detection - Value	 205Ah	P. 28
91.0	Speed deviation error detection - Delay time	 205Bh	P. 28

Icon Description

	EtherCAT Communication	These parameters allow access to the amplifier via EtherCAT communication.
	Object Dictionary	These parameters are related to the EtherCAT communication object dictionary.
	Hide	These parameters are hidden by S-TUNE II during EtherCAT communication.
	Read Only	These parameters cannot be written from S-TUNE II to the amplifier during EtherCAT communication.










































2. List of Parameters

In the order of parameter No.

No.	Name	 EtherCAT	
102.0	Inertia ratio	 2066h	P. 33
103.0	Damping ratio	 2067h	P. 33
106.0	Tuning - Inertia ratio upper limit	 206Ah	P. 33
110.0	Tuning - Mode switch	 206Eh	P. 33
110.1	Tuning - Tuning option	 206Eh	P. 34
113.0	Position control - Control gain set	 2071h	P. 34
113.1	Position control - Inertia condition	 2071h	P. 35
114.0	Position control - Control level	 2072h	P. 35
115.0	Position control - Control gain 1	 2073h	P. 36
116.0	Position control - Control gain 2	 2074h	P. 36
117.0	Position control - Gain FF compensation 1	 2075h	P. 37
118.0	Position control - Gain FF compensation 1	 2076h	P. 37
119.0	Position control - Integral gain	 2077h	P. 37
120.1	Tuning - Control gain set upper limit	 2078h	P. 38
121.0	Tuning - Tuning Constant	 2079h	P. 38
129.0	Speed control - Control gain set	 2081h	P. 52
130.0	Speed control - Control level	 2082h	P. 52
131.0	Speed control - Control gain 1	 2083h	P. 53
132.0	Speed control - Gain FF compensation 1	 2084h	P. 53
133.0	Speed control - Integral gain	 2085h	P. 53
144.0	Torque command limit - Switch		 P. 13
144.1	Torque command limit - Torque limit output		 P. 14
146.0	Torque command offset	 2092h	P. 14
147.0	Torque command limit - Value 1		 P. 14
151.0	Deceleration stop - Torque command limit		P. 18
152.0	EtherCAT Communication Torque command - Speed limit	 6080h	 P. 54
160.0	Torque command filter - Low-pass filter switch	 20A0h	P. 61
160.1	Torque command filter - Notch filter switch	 20A0h	P. 61
160.2	Torque command filter - Auto setting	 20A0h	P. 61
160.3	Torque command filter 2 - Notch filter switch	 20A0h	P. 61
162.0	Torque command filter - Low-pass filter time constant	 20A2h	P. 62
168.0	Torque command filter - Notch filter frequency	 20A8h	P. 62
169.0	Torque command filter - Notch filter width	 20A9h	P. 62
170.0	Torque command filter - Notch filter depth	 20AAh	P. 63
171.0	Torque command filter 2 - Notch filter frequency	 20ABh	P. 63
172.0	Torque command filter 2 - Notch filter width	 20ACh	P. 63
173.0	Torque command filter 2 - Notch filter depth	 20ADh	P. 64





























2. List of Parameters

In the order of parameter No.

No.	Name	 EtherCAT	
193.0	Current Control Gain Switch	 20C1h	P. 38
224.0	Deceleration stop - Method (at Servo Off)	 20E0h	P. 18
224.1	Deceleration stop - Release condition	 20E0h	P. 18
224.2	Deceleration stop - Switch (in case of control power error)	 20E0h	P. 19
224.3	Deceleration stop - DBRK output after deceleration stop (at Servo Off)	 20E0h	P. 19
225.0	Emergency stop - Warning output switch	 20E1h	P. 19
225.1	Emergency stop - Timing for alarm output	 20E1h	P. 19
225.2	Immediate stop - Smoothing filter switch	 20E1h	P. 20
226.0	Deceleration stop - Working time	 20E2h	P. 20
227.0	Deceleration stop - Rotational speed to end deceleration stop	 20E3h	P. 20
228.0	Deceleration stop - Operating time (in case of control power error)	 20E4h	P. 21
229.0	Immediate stop - Moving average counter for speed command smoothing filter	 20E5h	P. 21
232.1	Deceleration stop - Deceleration stop state during free-run	 20E8h	P. 22
232.2	Immediate stop - Short brake after the stop	 20E8h	P. 22
232.3	Deceleration stop - Timing for braking	 20E8h	P. 22
233.0	Deceleration stop - Method (in case of alarm)	 20E9h	P. 23
233.3	Deceleration stop - DBRK output after the stop (in case of alarm)	 20E9h	P. 24
234.0	Deceleration stop - delay time for brake to engage	 20EAh	P. 25
235.0	Deceleration stop - rotational speed to have brake engaged	 20EBh	P. 25
236.0	Immediate stop - Time extension	 20ECh	P. 25
237.0	Delay time for Servo off	 20EDh	P. 15
238.0	Delay time for mechanical brake release	 20EEh	P. 15
239.0	Quick stop - Decelerating time	 20EFh	P. 25
257.0	Absolute system	 2101h	P. 15
259.0	Encoder - Overheat detection output switch	 2103h	P. 28
259.1	Encoder - Low battery voltage detection output switch	 2103h	P. 28
267.0	Encoder - Temperature to detect overheat	 210Bh	P. 29
268.0	Encoder - Voltage to detect low battery voltage	 210Ch	P. 29
302.0	EtherCAT Communication Torque command - Rotation direction	 212Eh	P. 54
305.0	Momentary voltage drop detection - Delay time	 2131h	P. 29
357.0	Position command filter 3 - Notch Frequency	 2165h	P. 60
358.0	Position command filter 3 - Notch width	 2166h	P. 60
359.0	Position command filter 3 - High frequency gain constant	 2167h	P. 60
360.0	Position command filter 3 - Notch depth	 2168h	P. 60
363.0	Position deviation warning detection - Value	 216Bh	P. 29
365.0	Position deviation warning detection - Delay time	 216Dh	P. 29
376.0	Motor rotating position at encoder error - holding method	 2178h	P. 30
377.0	Motor rotating position at encoder error - holding time	 2179h	P. 30
458.0	Wraparound minimum	 21CAh	P. 16
460.0	Wraparound maximum	 21CCh	P. 16
474.0	EtherCAT Communication Setting	21DAh	P. 30





2. List of Parameters

In the order of parameter No.

No.	Name	 EtherCAT	
643.0	Internal position: Overflow detection		P. 45
645.0	Homing - Home base signal selection		P. 39
645.1	Homing - Encoder Z-phase as base signal		P. 39
645.3	Homing - Re-detection of home position dog		P. 39
646.0	Homing - Direction		P. 40
646.1	Homing - Sensor dog polarity		P. 41
646.2	Homing - Timeout switch		P. 41
647.0	Homing - Torque command limit switch		P. 41
647.1	Homing - Creeping switch		P. 42
648.0	Homing - Homing speed		P. 42
649.0	Homing - Creeping speed		P. 43
650.0	Homing - Acceleration/Deceleration time		P. 43
651.0	Homing - Shift-to-home-position quantity		P. 43
653.0	Homing - Home position data		P. 43
655.0	Homing - Detection time after stopper press		P. 43
656.0	Homing - Torque limit value		P. 44
657.0	Homing - Phase Z invalidation distance		P. 44
659.0	Homing - Timeout Time		P. 44
720.0...	Internal Position: Point table Command method		P. 45
720.1...	Internal Position: Point table Operation		P. 46
720.3...	Internal Position: Point table Enable/Disable		P. 47
722.0...	Internal Position: Point table Position		P. 48
724.0...	Internal Position: Point table Rotational speed		P. 48
726.0...	Internal Position: Point table Acceleration time		P. 48
727.0...	Internal Position: Point table Deceleration time		P. 48
728.0...	Internal Position: Point table Dwell time		P. 49
729.0...	Internal Position: Point table Positioning completion		P. 49

The internal position control point table parameters (No.720.0 or later) are not displayed on the parameter tab screen of S-TUNE II. These parameters are displayed in the Point Table tabbed screen. See page 44 and later for detailed descriptions of the parameters.

Icon Description



	EtherCAT Communication	These parameters allow access to the amplifier via EtherCAT communication.
	Object Dictionary	These parameters are related to the EtherCAT communication object dictionary.
	Hide	These parameters are hidden by S-TUNE II during EtherCAT communication.
	Read Only	These parameters cannot be written from S-TUNE II to the amplifier during EtherCAT communication.




2. Parameters



3. Details of Parameters

1. Basic Parameters



No. 2.0	Control mode	Settings	Default	Characteristics
		0, 1, 2	0	— — —  
Function Use	Select <u>Control Mode</u> .			
	Settings	Control Mode		
	0	Position Control Mode		
	1	Velocity Control Mode		
	2	Torque Control Mode		
Related To	No.3.0			

No. 3.0	Command mode	Settings	Default	Characteristics
		3, 10	10	— —   
Function Use	Select <u>Command Mode</u> .			
	Settings	Control Mode (No.2.0)	Position (0)	Velocity (1)
	3: Internal command	Yes	—	—
	10: EtherCAT	Yes	Yes	Yes
Related To	No.2.0			

No. 144.0	Torque command limit: Switch	Settings	Default	Characteristics
		0, 1	0	— —   —
Function Use	Enable/Disable Torque Command Limit			
	Settings	Selection	Error Detection	
	0	Disable	Position deviation: No.65.0 Speed deviation : No.65.1	Error Detection Value: No.87.0, No.90.0 Delay time : No.89.0, No.91.0
	1	Enable	0 (Disable) 1 (Enable)	— Select an appropriate value.
	If you are to select 1 for this parameter, configure the above settings so that Position deviation error (Alarm No.6) and Speed deviation error (Alarm No.5) will be avoided.			
Related To	No.65.0、 No.65.1、 No.87.0、 No.89.0、 No.90.0、 No.91.0			

About Unit Notation

- In this manual, [E-pulse] and [C-pulse] represent the pulse unit that represents the position information of the motor shaft.
 [E-pulse] = [Encoder pulse] :
 This is the value obtained by dividing and multiplying the command pulse of the Host controller by parameter No.34.0 and No.36.0.
 It is used for calculation inside the amplifier.
- [C-pulse] = [Command pulse] :
 The unit of command pulse for the Host controller.
- The unit of each parameter is described in the [initial value] column. Unitless is a dimensionless quantity.

3. Details of Parameters



No. 144.1	Torque command limit: Torque limit output	Settings	Default	Characteristics		
		0, 1, 2	0	— — —		
Function Use	Select one of the condition sets to output that the motor is in a "torque limiting state".					
	T-LIMIT (Pin No.17) of I/O connector will output the torque limiting state, when, in each row in the table below, 1) any of the parameters marked ○ is set with a valid value, or 2) the one marked with △ is not configured.					
	Settings	Torque command limit: Value 1 No.147.0	Torque command limit: Value 2 No.148.0	Motor Max output Torque value	Homing Torque command limit value No.656.0	Speed Limit No.152.0
	0	○	○	○	○	△
	1	○	○	—	—	—
	2	—	○	—	—	—
Prerequisite	Torque command limit switch (No.144.0) = 1 (Enable)					
Related To	No.144.0、No.147.0、No.148.0、No.152.0、No.656.0					

No.146.0 (2092h)	Torque command offset	Settings	Default	Characteristics	
		−1,000 to 1,000	0 [0.1%]	— — —	
Function Use	Adjust this parameter when the constant offset load torque is always applied to the motor by the gravity in the vertical axis. Set Torque command offset as a proportion relative to rated torque.				

No. 147.0	Torque command limit: Value 1	Range	Default	Characteristics	
		0 to 65,535	(See below)	— — —	
Function Use	Set a torque command limit value as % of the rated torque (100%).				
	Two torque command limits can be set with Value 1 and 2.				
	• When TLSEL1 (Pin No.11) of the I/O connector is open, Value 1 (No.147.0) is applied.				
	• When closed, Value 2 (No.148.0) will be applied.				
	• The setting of 3,000 or above indicates 300% of the max rated torque.				
	• If the parameter is set to above 1,000, an overload error will occur in the specified time, depending on the overload characteristic.				
• Under some operating conditions, overcurrent error may occur.					
If this happens, set the upper bound to 2,400.					
■ No.147.0 Default					
Each motor series have their own default values.					
		Motor Capacity	Default		
		50 W, 100 W	3,500 [0.1%]		
		200 W to 2 kW	3,000 [0.1%]		
Prerequisite	Torque command limit switch (No.144.0) = 1 (Enable)				
Related To	No.144.0、No.144.1				

2. Parameters

3. Details of Parameters



No. 237.0 (20EDh)	Servo OFF: Delay time	Range	Default	Characteristics
		0 to 3,125	0 [100μs]	-- --

Function Use

This parameter indicates the delay time the motor excitation off after the Enable Operation (0x6040,3) turns off.
By adjusting the timing to end motor excitation after the brake is engaged, brake-equipped axes such as vertical axis can be prevented from falling off.

■ Default: 0 ms

Related To

No.238.0

No. 238.0 (20EEh)	Bake release: Delay time	Range	Default	Characteristics
		0 to 3,125	40 [100μs]	-- --

Function Use

This item indicates the delay time of brake release signal (MBRK) ON after the motor excitement starts.

By adjusting the timing to release the brake after the motion excitement starts, brake-equipped axes such as vertical axis can be prevented from falling off.

■ Default: 4 ms

Related To

No.237.0

No. 257.0 (2101h)	Absolute system	Settings	Default	Characteristics
		0, 1, 2	0	--

Function Use

Select either Absolute system or Incremental system.

Settings	System	Multi-rotation counter Overflow detection
0	Incremental	—
1	Absolute	Disable
2	Absolute	Enable

Using this parameter in absolute systems

- Setting "2" (this is the usual setting)
Exceeding the encoder absolute value range of -4,294,967,296 to 4,294,967,295 (± 32,767 multi-turn data) will result in Alarm No.11 (encoder multi-turn counter overflow).
If this happens, correct the command such that motions will be kept within the absolute value range.
- Setting "1"
Use this setting when absolute value of single-turn is needed for continuous turns only in one direction. Exceeding the encoder absolute value range will result in a position that is significantly off from the position specified by next command.
Set Pulse Paired Ratio, so that the single-turn angel can be accurately detected with sufficient resolution even outside of the range.



Basic Parameters

Basic Settings



No. 458.0 (21CAh)	Wraparound Minimum value	Range	Default	Characteristics
		-2,147,483,648 to 0	-2,147,483,648	- - -
Function Use	Set the minimum value for wraparound.			
Related To	No.460.0			

No. 460.0 (21CCh)	Wraparound Maximum value	Range	Default	Characteristics
		0 to 2,147,483,648	2,147,483,648	- - -
Function Use	Set the maximum value for wraparound.			
Related To	No.458.0			




No. 67.0 (2043h)	Drive restriction input: Setup	Settings 0 to 3	Default 0	Characteristics
Function Use	By installing sensors at the ends of linear motion, you can restrict the drive beyond the motion range.			
	When "Enable" is selected for this parameter, starting the motor will be blocked by I/O input ON.			
	Settings	CW Drive restriction	CCW Drive restriction	
	0	Disable	Disable	
	1	Enable	Disable	
Related To	No.67.1、 No.67.2、 No.67.3			







No. 67.1 (2043h)	Drive restriction input: Deceleration method	Settings 0, 1, 2	Default 1	Characteristics
No. 67.2 (2043h)	Drive restriction input: Idling status	0, 1	0	
Function Use	Select the <u>deceleration method</u> upon drive restriction input and specify the <u>idling state after the motor stopped its motion</u> .			
	Use one of the following four combinations.			
	Possible Combinations	Deceleration method (No.67.1)	Idling status (No.67.2)	
	1	0: Free Run	0: Free Run	
	2	1: Short Brake	1: Zero Clamp	
Prerequisite	Drive restriction input: Setup (No.67.0) = 1, 2 or 3 (Enable)			
	Related To No.67.0、 No.67.3			



No. 67.3 (2043h)	Drive restriction input: Retaining position deviation counter	Settings 0, 1	Default 0	Characteristics
Function Use	Motor's stopping upon drive restriction input results in position deviation from the input pulse.			
	Use this parameter to select either keep or clear that position deviation.			
	Settings	Position Deviation Counter		
Related To	No.67.0、 No.67.1、 No.67.2			

3. Details of Parameters



No. 151.0	Deceleration stop: Torque command limit	Range	Default	Characteristics
		0 to 65,535	2,400 [0.1%]	— — —  —
Function Use	<p>If [Deceleration stop: Method (when the servo is off) (No.224.0)] = 2 (quick stop), set the value of torque command limit at the time of a quick stop as a ratio to the rated torque (100%).</p> <ul style="list-style-type: none">• The setting of 3,000 or above results in 300% of the max torque of each motor.• If the parameter is set to above 1,000, an overload error will occur in the given time, depending on the overload characteristic.• Under some operating conditions, overcurrent error may occur. If this happens, set the upper bound to the range with 2,400.			
Prerequisite	Deceleration stop: Method (upon servo is off) (No.224.0) = 2 (Quick stop)			
Related To	No.224.0			

No. 224.0 (20E0h)	Deceleration stop: Method (upon Servo Off)	Settings	Default	Characteristics
		0 to 3	3	 — —  —
Function Use	Specify the deceleration stop method in case of servo off while motor is rotating.			
	Settings	Description		
	0	 Free run		
	1	 Short brake		
	2	 Quick stop		
	3	 Dynamic brake		
Related To	No.151.0、 No.224.1、 No.224.3、 No.225.2、 No.226.0、 No.227.0、 No.229.0、 No.232.1、 No.232.2、 No.236.0、 No.239.0			

No. 224.1 (20E0h)	Deceleration stop: Release conditions	Settings	Default	Characteristics
		0, 1	1	 --  --
Function Use	This parameter indicates conditions to cancel a deceleration stop, if an alarm occurs or the Servo ON signal turns OFF.			
	It is used for a motor which is slowing down as specified with Deceleration stop: Method (upon Servo Off) (No.224.0).			
	Settings	Deceleration stop Operating time (No.226.0)	Deceleration stop Rotational speed to cancel (No.227.0)	
	0	○	—	
	1	○	○	
Prerequisite	Deceleration stop Method (upon servo off) (No.224.0) = 1 (Short brake) or 2 (Quick stop)			
Related To	No.224.0、 No.226.0、 No.227.0			

2. Parameters

3. Details of Parameters



No. 224.2 (20E0h)	Deceleration stop: Switch (upon control power failure)	Settings 0, 1	Default 1	Characteristics -- --
Function Use	Enable/Disable deceleration stop when an alarm of voltage drop error in the control power supply occurs.			
	Settings	Deceleration stop		
	0	Disable		
	1	Enable		
Related To	No.228.0			

No. 224.3 (20E0h)	Deceleration stop: DBRK output after stopping (upon Servo Off)	Settings 0, 1	Default 1	Characteristics -- --
Function Use	Select Stop State when the servo is off			
	Settings	Description		
	0	Free run		
	1	Dynamic brake		
Prerequisite	No.224.0、 No.232.1			

No. 225.0 (20E1h)	Emergency stop: Warning output switch	Settings 0, 1	Default 0	Characteristics -- --
Function Use	Set whether a warning to be output or not in case of E-stop input.			
	Settings	Warning output		
	0	Disable		
	1	Enable		

No. 225.1 (20E1h)	Emergency stop: Warning output timing	Settings 0, 1	Default 0	Characteristics -- --
Function Use	Specify when to output warning in case of E-stop input.			
	Settings	Warning output timing		
	0	After the motor makes a deceleration stop		
	1	Immediately after the warning occurs		
Prerequisite	Emergency stop: Warning output switch (No.225.0) = 1 (Output warning)			



No. 225.2 (20E1h)	Quick stop: Smoothing filter - Switch	Settings	Default	Characteristics
		0, 1	0	 — —  —
Function Use	Enable/Disable the Velocity Command smoothing filter at the time of a quick stop.			
	This filter suppresses vibration caused by drastic velocity change.			
	Settings	Velocity Command smoothing filter		
	0	Disable		
	1	Enable		
Prerequisite	No.229.0			

No. 226.0 (20E2h)	Deceleration stop: Operating time	Range	Default	Characteristics
		0 to 16,383	500 [100μs]	 — —  —
Function Use	This parameter indicates <u>deceleration stop operation time</u> in case an alarm occurs or the Servo ON signal turns OFF. It is used for a motor which is slowing down as specified with the deceleration stop method (No.224.0).			
	■ Default: 50 ms (Converted to Time)			
Prerequisite	Deceleration stop Method (upon servo off) (No.224.0) = 1 (Short brake) or 2 (Quick stop)			
Related To	No.224.0、No.224.1、No.227.0			



No. 227.0 (20E3h)	Deceleration stop: Rotational speed to end deceleration stop	Range	Default	Characteristics
		0 to 1,000	50 [r/min]	 — —  —
Function Use	This parameter indicates <u>rotational speed to cancel deceleration-stop</u> in case an alarm occurs or the Servo ON signal turns OFF.			
	It is used for a motor which is slowing down as specified with the deceleration stop method (No.224.0).			
Prerequisite	Deceleration stop: Method (No.224.0) = 1 (Short brake) or 2 (Quick stop) & Deceleration stop: Release conditions (No.224.1) = 1			
Related To	No.224.0、No.224.1、No.226.0			



2. Parameters

3. Details of Parameters

Basic Parameters

Stop Settings

No. 228.0 (20E4h)	Deceleration stop: Operating time (upon control power error)	Range	Default	Characteristics
		0 to 16,383	100 [100μs]	 — —  —
Function Use	Set Deceleration stop time in the event of the alarm output due to a control power error. ■ Default: 10 ms (Converted to Time)			
Prerequisite	Deceleration stop: Switch (upon control power failure) (No.224.2) = 1 (Enable)			
Related To	No.224.2			

No. 229.0 (20E5h)	Quick stop: Smoothing filter - Moving average counter	Range	Default	Characteristics
		1 to 1,000	40 [-]	 — —  —
Function Use	<p>This item indicates moving average count of velocity command smoothing filter while the motor is making a quick stop.</p> <p>The larger the parameter value, the smoother acceleration/deceleration is and the slower the response.</p>			
	<div>Delay Time Calculation Formula</div> <div>100μs × Moving average count = delay time</div>			
	<p>The positioning will take as long as the delay time specified above, set this item within the range acceptable to the equipment.</p>			
Prerequisite	Quick stop: Smoothing filter switch (No.225.2) = 1 (Enable)			
Related To	No.225.2、 No.239.0			

■ Waveforms for each combination of enable/disable Deceleration Stop and Smoothing Filter.

	Deceleration Stop	Disable	Enable	Enable
	Smoothing Filter	Disable	Disable	Enable
Command waveform				



No. 232.1 (20E8h)	Deceleration stop: Status during free-run	Settings	Default	Characteristics
		0, 1	1	-- --

Select on or off for deceleration stop status during free-run.

Function Use	Settings	Deceleration stop status
	0	<u>OFF (not consider as deceleration stop)</u> As soon as the servo status becomes OFF, the brake release (MBRK) becomes open and the brake becomes engaged. With the configuration of No.224.3 (upon servo off) and No.233.3 (upon alarm on), the dynamic brake release signal (DBRK) immediately turns off and the dynamic brake becomes engaged.
	1	<u>ON (consider as deceleration stop)</u> When the servo state becomes OFF, the deceleration stop status becomes ON. MBRK remains closed and the brake remains disengaged until the deceleration stop status becomes OFF. With the configuration of No.224.3 (upon servo off) and No.233.3 (upon alarm on), the dynamic brake release (DBRK) will remain ON and the dynamic braking will remain disengaged until the deceleration stop status becomes OFF.

No. 232.2 (20E8h)	Quick stop: Short brake operation after a stop	Settings	Default	Characteristics
		0, 1	0	-- --

Enable/Disable short braking after a quick stop.

Function Use	Settings	Short braking
	0	Enable
	1	Disable

Prerequisite Deceleration stop: Method (when servo off) (No.224.0) = 2 (Quick stop)

No. 232.3 (20E8h)	Deceleration stop: Brake engagement - Timing	Settings	Default	Characteristics
		0, 1	0	-- --

Set the timing for the brake to be engaged in a brake-equipped motor.

(That is, set the timing to open MBRK (Brake Release))

Function Use	Settings	Brake engagement timing
	0	When the deceleration stop status is off, or the motor rotation speed becomes lower than the setting of Deceleration stop: Cancellation speed (No.227.0)
	1	When the deceleration stop status is off, or the motor rotation speed becomes lower than the setting of Deceleration stop: Brake engagement - Rotation speed (235.0), or the braking time reaches the value of Deceleration stop: Brake engagement - Delay time (No.234.0).

Related To No.234.0、No.235.0



No. 233.0 (20E9h)	Deceleration Stop: Method (when alarm is on)	Settings	Default	Characteristics
		0 to 7	1	-- -- --
Function Use	Select a deceleration stop method in case of alarm while motor is in motion. Each alarm group uses a different stop method. (*1)			
	Settings	Stop method		
		Group ①	Group ② (*2), ③, ④	Group ⑤
	0			
	1			
	2			
	3			
	4			
	5			
	6			
	7			
*1) Alarms are categorized into five groups. *2) When Deceleration stop: Method (No.224.0) = 0 (Disable), the motor will be stopped by the group ① method. After the amount of time specified by Deceleration stop: Operating time (No.228.0) elapses, the motor will be stopped by the group ① method.				

Free run	Quick stop	Short brake	Dynamic brake
----------	------------	-------------	---------------

2. Parameters

3. Details of Parameters





Basic Parameters

Stop Settings




Group	Alarm No.	Alarm Name
①	14	Overvoltage error
	23	Switch circuitry error
	24	Overcurrent error
	25	Inverter error 1
	26	Inverter error 2
	27	Current sensor error
	29	Voltage error (Internal control power DC5V)
②	22	Voltage error (Internal control power DC24V)
	32	Power supply error (Control circuit AC power)
③	16	Encoder error (Received data)
	17	Encoder error (No response)
	18	Encoder error (Hardware)

Group	Alarm No.	Alarm Name
④	0	System error
	1	EEPROM data error
	2	Product code error (Mismatching code)
	7	Overload error
	19	Encoder error (Communication)
	20	Encoder error (Multi-turn data)
	21	Encoder error (Voltage drop)
	34	Product code error (Undefined model code)
	3	EtherCAT communication error
	4	Overspeed error
⑤	5	Velocity deviation error
	6	Position deviation error
	8	Command overspeed error
	10	Positioning command overflow error /Homing failure
	11	Multi-turn counter error
	12	Overheat error
	15	Power supply error (Primary circuit AC power)
	28	Encoder error (Overheat)

No. 233.3 (20E9h)	Deceleration Stop: DBRK output after stopping (when alarm is on)		Settings	Default	Characteristics
			0, 1	1	 --  --
Function Use	Select the type of idling in case of alarm.				
	Settings	Idle State			
	0		Free run		
	1		Dynamic brake		



2. Parameters



3. Details of Parameters



No.	Parameter Name	Range	Default	Characteristics
No. 234.0 (20EAh)	Deceleration Stop: Brake engagement - Delay time	0 to 16,383	0 [100μs]	-- -- --
Function Use	Set the delay time between two events: 1) SVON (servo-on) opens while the motor is in motion or an alarm occurs, and 2) the brake becomes engaged. ■ Default: 0 ms (Converted to Time)			
Prerequisite	Timing of brake engagement (No.232.3) = 1			
No.	Parameter Name	Range	Default	Characteristics
No. 235.0 (20EBh)	Deceleration Stop: Brake engagement - Rotational speed	0 to 1,000	50 [r/min]	-- -- --
Function Use	Set the motor rotational speed to engage the brake when 1) SVON (servo-on) opens while the motor is in motion or 2) an alarm occurs.			
Prerequisite	Timing of brake engagement (No.232.3) = 1			
No.	Parameter Name	Range	Default	Characteristics
No. 236.0 (20ECh)	Quick stop: Extension Time	0 to 3,125	0 [100μs]	-- -- --
Function Use	This item indicates how long the quick stop to be kept after the deceleration stop complete conditions were met. It is used to compensate the brake response time. ■ Default: 0 ms (Converted to Time) This parameter is valid only when the Deceleration Stop Method is "quick stop". This parameter is invalid if the servo turns off while the motor idling. Use Servo OFF: Delay time (No.237.0) to compensate the brake response time when the servo turns off during motor idling.			
Prerequisite	Deceleration stop: Method (No.224.0) = 2 (Quick stop)			
Related To	No.224.0、 No.233.0、 No.237.0			
No.	Parameter Name	Range	Default	Characteristics
No. 239.0 (20EFh)	Quick stop: Deceleration time	0 to 100	0 [ms]	-- -- --
Function Use	This item indicates decelerating time after a quick stop. Set the time-length for speed command to change from 1,000 r/min to 0 r/min.			
Related To	No.224.0、 No.232.2、 No.236.0			



No. 12.0 (200Ch)	Warning latch time	Range	Default	Characteristics
		0 to 200	1 [50ms]	 --  --
Function Use	Specify the length of latch time for warning output.			
	Setting	Description		
	0	No limit		
	1 to 200	Latching Time = Setting Value × 50 ms		
	<p><u>Warning Output time = Warning State time + Warning Latch time</u></p> <p>Warning State OFF ON</p> <p>Warning Output OFF ON Warning Latch State</p> <p>Warning Latch Time</p> <p>Close RESET to release the alarm latch and turn the warning off.</p>			
Related To	No.225.0、 No.225.1			

No. 13.0 (200Dh)	Alarm output timing	Settings	Default	Characteristics
		0, 1	0	 --  --
Function Use	Specify when to output an alarm.			
	Settings	Output timing		
	0	After the motor decelerates to stop		
Remark	1	Immediately after an alarm occurs		
	If Deceleration Stop: Method (when alarm is on) (No.233.0) = 0 (free-run), the alarm signal will be output regardless of this parameter setting.			



2. Parameters



3. Details of Parameters




Basic Parameters


Error Detection Settings



No. 65.0 (2041h)	Position deviation error detection: Switch	Settings 0 to 3	Default 1	Characteristics  --  --
Function Use	Specify what to output when excessive position deviation is detected.			
	Settings	Output selection		
	0	No detect (No output)		
	1	Alarm output		
	2	Warning output		
	3	Alarm and Warning output		
	When using Torque command limit, select 0 (No output) so that an alarm will not occur in a torque limit state.			
Related To	No.87.0、 No.89.0、 No.363.0、 No.365.0			

No. 65.1 (2041h)	Speed deviation error detection: Switch	Settings 0, 1	Default 1	Characteristics  --  --
Function Use	Enable/Disable Speed Deviation Error Detection.			
	Settings	Speed deviation error detection		
	0	Disable		
	1	Enable		
	When using Torque command limit, select "Disable" so that an alarm will not occur during limiting.			
Related To	No.90.0、 No.91.0			

No. 87.0 (6065h)	Position deviation error detection: Value	Range 0 to 10,000	Default 1,500 [0.001rev]	Characteristics  --   --
Function Use	This parameter sets a threshold value for a position deviation error detection.			
	The higher the value, the less likely to detect position deviation error.			
Prerequisite	Position deviation error detection: Switch (No.65.0) = 1 (Enable)			
Related To	No.65.0, No.89.0			

No. 89.0	Position deviation error detection: Delay time	Range 0 to 32,767	Default 400 [100μs]	Characteristics -- -- --  --
Function Use	This parameter sets a delay time for a position deviation error (Alarm No.6) to be output after the position deviation exceeded the setting of [Position deviation error detection value (No.87.0)]			
	The higher the value, the longer it takes for the error to be output.			
	■ Default: 40 ms (Converted to Time)			
Prerequisite	Position deviation error detection: Switch (No.65.0) = 1 (Enable)			
Related To	No.65.0、 No.87.0			

3. Details of Parameters



Basic Parameters

Error Detection Settings



No. 90.0 (205Ah)	Speed deviation error detection: Value	Range 0 to 10,000	Default 1,500 [r/min]	Characteristics -- --
Function Use	This parameter sets a threshold value for a speed deviation error detection. The higher the value, the less likely to detect a speed deviation error.			
Prerequisite	Speed deviation error detection - Switch (No.65.1) = 1 (Enable)			
Related To	No.65.1、 No.91.0			

No. 91.0 (205Bh)	Speed deviation error detection: Delay time	Range 0 to 32,767	Default 400 [100μs]	Characteristics -- --
Function Use	This parameter sets a delay time for a speed deviation error (Alarm No.5) to be detected after the speed deviation exceeded the setting of "Speed deviation error - Detection value"(No.90.0). The higher the value, the longer the error detection time. ■ Default: 40 ms (Converted to Time)			
Prerequisite	Speed deviation error detection - Switch (No.65.1) = 1 (Enable)			
Related To	No.65.1、 No.90.0			

No. 259.0 (2103h)	Encoder: Overheat detection - switch	Settings 0, 1, 2	Default 0	Characteristics -- --								
Function Use	Select what to output when overheat of the encoder is detected. <table><tr><th>Settings</th><th>Output</th></tr><tr><td>0</td><td>No output</td></tr><tr><td>1</td><td>Warning output</td></tr><tr><td>2</td><td>Alarm output</td></tr></table>				Settings	Output	0	No output	1	Warning output	2	Alarm output
Settings	Output											
0	No output											
1	Warning output											
2	Alarm output											

No. 259.1 (2103h)	Encoder: Battery voltage drop detection - switch	Settings 0, 1	Default 0	Characteristics -- --						
Function Use	Select what to output when encoder battery voltage drop is detected. <table><tr><th>Settings</th><th>Output</th></tr><tr><td>0</td><td>No output</td></tr><tr><td>1</td><td>Warning output</td></tr></table>				Settings	Output	0	No output	1	Warning output
Settings	Output									
0	No output									
1	Warning output									

2. Parameters

3. Details of Parameters



Basic Parameters



Error Detection Settings





No.	Encoder:	Range	Default	Characteristics
No. 267.0 (210Bh)	Overheat detection - Value	0 to 127	85 [°C]	-- --
Function Use	Set the value to detect overheat of the encoder. (for reference only)			
Related To	No.259.0			
No.	Encoder:	Range	Default	Characteristics
No. 268.0 (210Ch)	Battery voltage drop detection - Value	0 to 100	24 [0.1V]	-- --
Function Use	Set the value to detect voltage drop of the encoder.			
Related To	No.259.0			
No.	Voltage Drop Detection:	Range	Default	Characteristics
No. 305.0 (2131h)	Delay time	20 to 50,000	80 [ms]	-- --
Function Use	Set the delay time to voltage sag of the primary circuit power supply. (voltage sag=detect a dip in voltage)			
Remark	Detection of a voltage sag will result in Alarm No.15. Set this parameter suitable to your operating conditions.			
No.	Position deviation warning detection:	Range	Default	Characteristics
No. 363.0 (216Bh)	Value	0 to 2,147,483,647	100 [E-pulse]	-- --
Function Use	Set the value to detect position deviation warning. The position deviation warning will be detected when the position deviation exceeds this parameter value.			
Prerequisite	Position deviation error detection: Switch (No.65.0) = 2 (Warning output), or 3 (Alarm and Warning output)			
Related To	No.65.0、 No.365.0			
No.	Position deviation warning detection:	Range	Default	Characteristics
No. 365.0 (216Dh)	Delay time	0 to 65,535	500 [100μs]	-- --
Function Use	Set the delay time to detect the position deviation warning. ■ Default: 50 ms (Converted to Time)			
Prerequisite	Position deviation error detection: Switch (No.65.0) = 2 (Warning output), or 3 (Alarm and Warning output)			
Related To	No.65.0、 No.363.0			



No.376.0 (2178h)	Motor rotating position at encoder error holding method	Range	Default	Characteristics
		0, 2	0	 -- --  --
Function Use	Select method for motor rotating position holding at encoder error.			
	Settings	Methods		
	0	Disable		
	2	Keep torque command value Setting range		
Related To	No.377.0			

No.377.0 (2179h)	Motor rotating position at encoder error holding time	Range	Default	Characteristics
		0 to 200	100 [ms]	 -- --  --
Function Use	Set operation time for motor rotating position holding at encoder error.			
Related To	No.376.0			




No.474.0 (21DAh)	Error detection settings EtherCAT Communication Setting	Range	Default	Characteristics
		0, 1	1	 -- --  --
Function Use	Select whether the amplifier detects alarm No.3 when EtherCAT communication error occurs.			
	Settings	Alarm No.3		
	0	NOT detect		
	1	Detect		

2. Parameters

3. Details of Parameters

2. Position Control Mode






No. 32.2 (2020h)	Pulse train command: Interpolation with pulse ratio	Settings	Default	Characteristics
		0, 1	1	 — —  
Function Use	Enable/Disable the interpolation to smooth a command where C-pulse Ratio is set.			
	Settings	Interpolation with pulse ratio		
	0	Disable		
	1	Enable		
Related To	No.32.0、No.34.0、No.36.0			




2. Parameters

3. Details of Parameters

Position Control Mode

Position Command Input

No. 34.0 (6091-01h)	Pulse train command: Ratio (Numerator)	Range 17bit 1 to 65,535	Default 1,000 [-]	Characteristics  —  
No. 36.0 (6091-02h)	Pulse train command: Ratio (Denominator)	23bit 1 to 8,388,608		
Function Use	Use these two parameters to set the multiplier and divider for the position C-pulse .			
	When the pulse count per rotation of host command is not equal to its counterpart of motor, select one of the following for (Numerator)/(Denominator).			
	$\begin{aligned} (\text{Numerator}) &= (\text{motor pulse count per rotation}) / 4 = 32,768 \\ (\text{Denominator}) &= (\text{host C-pulse count per rotation}) / 4 \end{aligned}$			
	$\frac{34.0}{36.0} = \frac{\text{motor pulse count per rotation}}{\text{host C-pulse count per rotation}} = \frac{\text{motor pulse count per rotation} / 4}{\text{host C-pulse count per rotation} / 4}$			
	■ Setting Example unit: [pulse/rev]			
	A Host Command Pulse count per rotation	B No.34.0	C (= A × 1/4) No.36.0	
	16,384	32,768 = 131,072 (*) ÷ 4	4,096	
	10,000		2,500	
	4,096		1,024	
	4,000		1,000	
	*) 131,072 is the pulse count per rotation of the motor. The default setting values are assumed 131,072 pulses of the host C-pulse number per a rotation.			
Remark	Range of Pulse Ratio (Numerator/Denominator) • Pulse train command: x0.001 to x1,000 • Internal Position Command: x1 to x1,000			

No. 66.3 (2042h)	Pulse train command:	Settings	Default	Characteristics
	Feed forward delay compensation	0, 1	1	 —  
Function Use	Enable/Disable Feed Forward Delay Compensation in <u>Position Control Mode</u> .			
	Settings	Feed forward delay compensation		
	0	Disable		
	1	Enable		
Remark	Usually, set 1 (enable) You can set this item only with S-TUNE II , not with the Setup Panel.			




3. Details of Parameters



No. 102.0 (2066h)	Tuning: Inertia ratio	Range	Default	Characteristics
		100 to 10,000	250 [%]	-- -- --
Function Use	<p>Specify the ratio of the device load inertia to motor rotor inertia (moment of inertia).</p> $\text{Inertia Ratio} = \frac{\text{Load Inertia} + \text{Rotor Inertia}}{\text{Rotor Inertia}} \times 100\%$ <p>Inertia ratio is estimated by auto-tuning. When estimation is difficult (for example, too large an inertia ratio or too large a torque value), you can enter a calculated value of load inertia. If vibration occurs after deceleration or acceleration, increase the inertia ratio.</p>			
Remark	The inertia ratio being too large or too small will cause noise.			





No. 103.0 (2067h)	Tuning: Damping ratio	Range	Default	Characteristics
		10 to 5,000	100 [%]	-- -- --
Function Use	<p>This parameter can be used for tuning to improve poor settling due to viscous friction, or too large an inertia ratio.</p> <p>Increasing (or decreasing) this parameter value in event of overshoot (or undershoot respectively) may make the settling time shorter. The value of this parameter is estimated along with inertia ratio simultaneously if Tuning: Items (No.110.1) = 2 (start).</p>			
Prerequisite	Position Control Mode, Velocity Control Mode			
Related To	No.110.1			



No. 106.0 (206Ah)	Tuning: Inertia ratio upper bound	Range	Default	Characteristics
		100 to 10,000	3,000 [%]	-- -- --
Function Use	Set the upper bound of the inertia ratio automatically adjusted in Quick Tuning.			
Prerequisite	Tuning: Control gain set - Automatic switch (No.120.0): 1 (Enable)			
Related To	No.110.1、 No.120.0			

No. 110.0 (206Eh)	Tuning: Mode switch	Settings	Default	Characteristics
		1, 2	2	 —  —  —
Function Use	Select a tuning condition depending on the direction of load or the presence of unbalanced load.			
	Settings	Mode	Motion direction of the device connected to the motor	
	1	Standard	Horizontal axis force	
	2	Offset Load	Non-horizontal axis force	
	Use Offset Load Mode even for the case of axis force (horizontal motion)			
Prerequisite	Position Control Mode, Velocity Control Mode			

3. Details of Parameters





No. 110.1 (206Eh)	Tuning: Items	Settings	Default	Characteristics
		0, 1, 2	0	 --  --
Function Use	Select Start or Stop for tuning depending on the your willing to estimate items.			
	Settings (Tuning)	Estimate items		 --  --
		Inertia ratio	Damping ratio	
	0 (Stop)	No estimate	No estimate	
	1 (Start)	Estimate		
	2 (Start)		Estimate	
Prerequisite	Position Control Mode, Velocity Control Mode			

No. 113.0 (2071h)	Tuning: Position control mode - Control gain set	Range	Default	Characteristics																				
		5 to 45	15 [-]	 --  --																				
Function Use	Select one control gain set for <u>Position Control Mode</u> .																							
	Control Gain 1 (No.115.0), Control Gain 2 (No.116.0), and Integral Gain (No.119.0) are set to the preset values of pairs.																							
	■ Noise Solutions																							
	① Use Torque command filter: Notch filter (such as No.160.1).																							
	② Decrease the value of Integral Gain (No.119.0).																							
	③ Decrease the value of Control Gain 2 (No.116.0).																							
If the above does not work, lower Control Gain Set.																								
<table><tr><th>Setting</th><th>Command Response</th><th>Rigidity</th><th>Settling Time</th><th>Possibility of Noise</th></tr><tr><td>5</td><td>Slower</td><td>Lower</td><td>Longer</td><td>Lower</td></tr><tr><td>↑</td><td>↑</td><td>↑</td><td>↑</td><td>↑</td></tr><tr><td>45</td><td>Faster</td><td>Higher</td><td>Shorter</td><td>Higher</td></tr></table>					Setting	Command Response	Rigidity	Settling Time	Possibility of Noise	5	Slower	Lower	Longer	Lower	↑	↑	↑	↑	↑	45	Faster	Higher	Shorter	Higher
Setting	Command Response	Rigidity	Settling Time	Possibility of Noise																				
5	Slower	Lower	Longer	Lower																				
↑	↑	↑	↑	↑																				
45	Faster	Higher	Shorter	Higher																				
Prerequisite	Position Control Mode																							
Remark	<ul style="list-style-type: none">• Too large a value of this item may cause noise.• The default value varies depending on the setting of Position Control Mode - Inertia conditions (No.113.1).• If Torque command filter: Low-pass filter - Auto setting (No.160.2) = 1 (auto setting ON), then Torque command filter: Low-pass filter - Time constant (No.162.0) will be included in the gain set.																							
Related To	No.113.1、 No.114.0、 No.115.0、 No.116.0、 No.117.0、 No.118.0、 No.119.0、 No.162.0																							

2. Parameters

3. Details of Parameters



No. 113.1 (2071h)	Tuning:	Settings	Default	Characteristics
	Position control mode - Inertia conditions	1, 2, 3	2	 --  --
Function Use	Set the inertia conditions for <u>Position Control Mode</u> .			
	This parameter is used to determine the ratio of Control Gain 1 (No.115.0) to Control Gain 2 (No.116.0), which would be appropriate to equipment characteristics.			
	Settings	Description		
	1	Heavy-load equipment or equipment with substantial load fluctuation Equipment with low rigidity, robot arms, and so on		
	2	(medium setting) For example, general transport machines		
	3	Light-load equipment Equipment that demands high-speed operation or requires settling		
Prerequisite	Position Control Mode			
Related To	No.113.0、 No.115.0、 No.116.0			

No. 114.0 (2072h)	Tuning: Position control mode - Control level	Range	Default	Characteristics
		5 to 45	15 [-]	-- --
Function Use	Set the <u>Control Level of Position Control Mode</u> .			
	With this parameter, both Control Gain 1 (No.115.0) and Control Gain 2 (No.116.0) can be set to the preset values of pairs.			
	■ Noise Solutions ① Use Torque command filter: Notch filter - Switch (such as No.160.1). ② Decrease Position control mode - Integral gain (No.119.0). ③ Decrease Position control mode - Control gain 2 (No.116.0).			
	If any of the above does not work, decrease the Control Gain Set value.			
	Setting	Command Response	Rigidity	Settling Time
	5	Slower	Lower	Longer
	↑	↑	↑	↑
	45	Faster	Higher	Shorter
Prerequisite	Position Control Mode			
Remark	• Setting Control Level will invalidate the setting of Control gain set (No.113.0). • The specified values of Control Gain 1 (No.115.0) and Control Gain 2 (No.116.0) vary depending on Inertia conditions (No.113.1).			
Related To	No.113.0、 No.113.1、 No.115.0、 No.116.0			

3. Details of Parameters



No. 115.0 (2073h)	Tuning: Position control mode - Control gain 1	Range	Default	Characteristics
		5 to 1,000	50 [rad/s]	— —
Function Use	Set Control Gain 1 for <u>Position Control Mode</u> .			
	Increasing this parameter value reduces position deviations after the command becomes zero. Increase it when the position deviation convergence at the time of settling is not good. Set a value smaller than the value of Control Gain 2 (No.116.0).			
Prerequisite	Position Control Mode			
Remark	<ul style="list-style-type: none"> • Making a change to any of the following will also change other tuning parameters (such as Control Gain 2) to the prearranged parameter set all at once. <ul style="list-style-type: none"> - Control Gain Set (No.113.0) - Inertia conditions (No.113.1) - Control Level (No.114.0) • To reduce the position deviation of the command being input, raise Control Gain 2 (No.116.0). 			
Related To	No.113.0、 No.113.1、 No.114.0、 No.116.0、 No.117.0			

No. 116.0 (2074h)	Tuning: Position control mode - Control gain 2	Range	Default	Characteristics
		80 to 5,000	200 [rad/s]	—
Function Use	Set Control Gain 2 for <u>Position Control Mode</u> .			
	<p>Increasing this parameter value decreases the position deviation during command input. Increasing the parameter value provides faster command response; however, too large a value may result in noise. Set a value larger than the value of Control Gain 1 (No.115.0).</p> <p>■ Noise Solutions</p> <ol style="list-style-type: none"> ① Use Torque command filter: Notch filter (such as No.160.1) ② Lower Integral Gain (No.119.0) <p>If the above does not work, decrease the Control Gain 2.</p>			
Prerequisite	Position Control Mode			
Remark	<ul style="list-style-type: none"> • Making a change to any of the following will also change other tuning parameters (such as Control Gain 1) to the prearranged parameter set all at once. <ul style="list-style-type: none"> - Control Gain Set (No.113.0) - Inertia conditions (No.113.1) - Control Level (No.114.0) • To reduce position deviations after the command becomes zero, increase the value of Control Gain 1 (No.115.0). 			
Related To	No.113.0、 No.113.1、 No.114.0、 No.115.0、 No.118.0			

2. Parameters



3. Details of Parameters



2
Parameters




No.	Tuning:	Range	Default	Characteristics
No. 117.0 (2075h)	Position control mode - Gain FF compensation 1	0 to 15,000	10,000 [0.01%]	-- -- --
Function Use	<p>Set the Field Forward Compensation Rate (speed) with respect to Control Gain 1 (No.115.0) for <u>Position Control Mode</u>. Using this parameter is effective to shorten the settling time.</p> <p>Adjust this item after setting the following: Inertia ratio (No.102.0), Control gain set (No.113.0), Control level (No.114.0), Control gain 1 (No.115.0), Control gain 2 (No.116.0) Too high a value of this parameter will result in overshooting, and too low in undershooting. Set relatively a moderate value.</p>			
Prerequisite	Position Control Mode			
Related To	No.113.0、 No.115.0、 No.118.0			
No.	Tuning:	Range	Default	Characteristics
No. 118.0 (2076h)	Position control mode - Gain FF compensation 2	0 to 15,000	0 [0.01%]	-- -- --
Function Use	<p>Set Field Forward Compensation Rate (Torque) with respect to [Control Gain 2 (No.116.0)] for <u>Position Control Mode</u>. Using this item will reduce position deviations during operation.</p> <p>Setting this item to around 10,000 will make the position deviations during operation almost zero. Raise the value of this item only after reducing the position deviation, by using Gain FF Compensation 1 (No.117.0) at settling.</p> <p>■ Noise Solutions Adjusting Filter 4: Smoothing 2- Moving average counter (No.81.0) may reduce the noise.</p>			
Prerequisite	Position Control Mode			
Related To	No.113.0、 No.116.0、 No.117.0			
No.	Tuning:	Range	Default	Characteristics
No. 119.0 (2077h)	Position control mode - Integral gain	45 to 5,000	160 [rad/s]	-- -- --
Function Use	<p>Set the Integral Gain for <u>Position Control mode</u>.</p> <p>Increasing the value of Integral Gain will improve the convergence (interfered by friction or load fluctuation) at the time of settling, and reduce position deviations. This will result in rigid and sensitive motions.</p> <p>■ Noise Solutions ① Use Torque command filter: Notch filter (such as No.160.1). ② Decrease the value of Integral Gain</p>			
Prerequisite	Position Control Mode			
Remark	This parameter will reset to the default if Inertia conditions (No.113.1) or Control Gain Set (No.113.0) is changed.			
Related To	No.113.0			

3. Details of Parameters



No. 120.1 (2078h)	Tuning: Control gain set - Upper bound	Range	Default	Characteristics
		5 to 45	15 [-]	 — —  —
Function Use	Set the upper bound of Control Gain Set in Auto Tuning of Control Gain Set.			
Prerequisite	Position Control Mode			
Related To	No.106.0、 No.120.0			

No. 121.0 (2079h)	Tuning: Control gain set - Tuning constant	Range	Default	Characteristics
		1 to 200	24 [-]	 — —  —
Function Use	This parameter is used for Quick Tuning. Usually the default value is used.			
	It is a constant of proportionality to calculate (Control Gain 1 + Control Gain 2) based on the Inertia ratio setting value in their inverse proportionality. Set it to a small value only if Quick Tuning has caused vibration in an extremely poor rigidity equipment.			
Prerequisite	Position Control Mode Tuning: Control gain set - Automatic switch (No.120.0): 1 (Enable)			
Remark	This parameter is not displayed on the Setup Panel.			
Related To	No.120.0			

No. 193.0 (20C1h)	Tuning: Current control gain	Settings	Default	Characteristics
		0, 1	0	 — —  
Function Use	This parameter is used to adjust the gain level of the current control component.			
	Select 1 to reduce noise generated at the time of servo-on stop.			
	Settings	Level	Noise	Response
	0	Standard	More	Faster
	1	Low	Less	Slower
	Remark	• If you changed the setting, perform tuning again. • Selecting 1 hurts response; Adjust within the acceptable range.		



No. 645.0	Homing: Home reference signal selection	Settings	Default	Characteristics
		0, 1	0	— — —

Select the signal that the home position will be referenced to.

Settings	Reference Signal 1
0	Any user specified position
1	Stopper

No. 645.1	Homing: Encoder Z-phase selection	Settings	Default	Characteristics
		0, 1	0	— — —


To add encoder Z-phase as the reference position after the Home Reference Signal is detected, set this parameter to 1.

Settings	Encoder Z-phase Signal
0	Disable
1	Enable

No. 645.3	Homing: Re-detection of home position dog	Settings	Default	Characteristics
		0, 1	0	— — —







Use this parameter, after detecting dog-front-end, to re-detect the dog-front-end at a speed specified with the homing creep speed parameter.

Settings	Re-detecting motion
0	Disable
1	Enable



Prerequisite Homing: Home reference signal selection (No.645.0): 2(home dog-front-end)







No. 646.0	Homing: Direction	Settings	Default	Characteristics						
		0, 1	0	—  —  —						
Function Use	Specify the homing direction.									
	<table><tr><th>Settings</th><th>Direction of rotation</th></tr><tr><td>0</td><td>CCW</td></tr><tr><td>1</td><td>CW</td></tr></table>				Settings	Direction of rotation	0	CCW	1	CW
	Settings	Direction of rotation								
	0	CCW								
	1	CW								
	■ When Homing Home Reference Signal selection (No.645.0) = 0 (Any user specified position)									
	<div><div>Homing direction</div><div>Direction of Z-phase detection</div><div>Encoder Z-phase</div><div>Homing direction is the same direction as Z-phase detection.</div></div> 									
	<div><div>Direction of Creep motion</div><div>Creep Motion</div><div>Offset from home position</div><div>Position</div><div>Homing direction is the same direction as Careful Approach.</div></div> 									
	■ When Homing Home Reference Signal selection (No.645.0) = 1 (Stopper)									
	<div><div>Homing direction</div><div>Encoder Z-phase</div><div>Stopper</div><div>Homing direction and Z-phase detection direction are opposite direction.</div></div> 									
<div><div>Direction of Creep motion</div><div>Creep Motion</div><div>Offset from home position</div><div>Position</div><div>Homing direction is opposite of the Creep Motion direction.</div></div> 										
Related To	No.645.0、No.645.1、No.645.3									



2. Parameters



3. Details of Parameters

2
Parameters

3. Details of Parameters

No. 646.1	Homing: Sensor dog polarity	Settings 0, 1	Default 0	Characteristics —  —  —
Function Use	Select the polarity for the home sensor signal input ORG (Pin No.11) of C5 to detect the dog-front-end.			
	Settings	Detection Polarity		
	0	Detect where ORG = OFF 		
Function Use	1	Detect where ORG = ON 		

No. 646.2	Homing: Timeout switch	Settings 0, 1	Default 1	Characteristics —  —  —
Function Use	Enable/Disable Homing Timeout. This item is a safety measure against collisions.			
	Settings	Timeout		
	0	Disable		
Function Use	1	Enable		
	When the time since homing started exceeds the setting of Timeout Time (No.659.0), Alarm No.10 (internal position command overflow fault / homing failure) is output leading to servo off.			

No. 647.0	Homing: Torque command limit switch	Settings 0, 1	Default 0	Characteristics —  —  —
Function Use	Enable/Disable torque command limit during Homing. This item is a safety measure against collisions during Homing.			
	Settings	Torque Command Limit		
	0	Disable		
Function Use	1	Enable		
Remark	For Homing by using stopper, this parameter setting does not matter. The torque limit used for press detection will be always the setting of Homing torque command limit value (No.656.0) regardless of this parameter setting.			
Related To	No.656.0			





No. 647.1	Homing: Creep speed switch	Settings	Default	Characteristics
		0, 1	0	—  —  —



Enable/Disable homing motion after home reference signal detection.

Set to 0 to only detect the home reference signal.

Set to 1 if any motions are intended after the reference signal detection.


Function
Use

Settings	Motion afterwards
0	<p>None</p> <p>After home reference signal is detected, the motor decelerates to stop and homing completes.</p> 
1	<p>Move</p> <p>After home reference signal is detected and then the motor decelerates to stop, motion to carefully approach to the home position follows according to the parameter setting.</p> 

No. 648.0	Homing: Rapid speed	Range	Default	Characteristics
		0 to 6,300	500 [r/min]	—  —  —

Specify the speed value for rough approach motion before the home reference signal is detected.

Function
Use



2. Parameters

3. Details of Parameters



Position Control Mode
Homing







No.	Parameter Name	Range	Default	Characteristics
No. 649.0	Homing: Creep speed	0 to 6,300	10 [r/min]	— — —
Function Use	Specify the speed for careful approach after the home signal is detected. To improve accuracy to detect the home reference signal, select a lower speed.			
Prerequisite	Homing: Creep speed switch (No.647.1): 1 (Move)			
Related To	No.645.0、 No.647.1、 No.648.0			
No.	Parameter Name	Range	Default	Characteristics
No. 650.0	Homing: Acceleration/Deceleration time	0 to 5,000	30 [ms]	— — —
Function Use	Set Acceleration/Deceleration Time for homing. This item indicates time amount for a speed to change 1,000 r/min. Applies to Rapid Speed (No.648.0) and Creep Speed (No.649.0)			
Remark	If the load is more than 10 times of inertia ratio, set this parameter to a value larger than the default. Otherwise, vibration may occur.			
No.	Parameter Name	Range	Default	Characteristics
No. 651.0	Homing: Amount of home position shift	0 to 1,000,000,000	0 [C-pulse]	— — —
Function Use	Use this parameter to set shift amount from home signal or encoder Z-phase to home.			
Related To	No.646.0			
No.	Parameter Name	Range	Default	Characteristics
No. 653.0	Homing: Home position data	−1,000,000,000 to 1,000,000,000	0 [C-pulse]	— — —
Function Use	This parameter value overwrites the home coordinate (ABS position feedback value) upon Homing complete.			
No.	Parameter Name	Range	Default	Characteristics
No. 655.0	Homing: Time to detect press stopper	5 to 1,000	100 [ms]	— — —
Function Use	This parameter indicates the torque command limiting time, which is a time amount for home to be detected after the stopper was pressed.			
Related To	No.645.0、 No.647.0			

3. Details of Parameters



No. 656.0	Homing: Torque command limit value	Range	Default	Characteristics
		10 to 3,000	500 [0.1%]	—  —  —
Function Use	<p>This parameter indicates a ratio of torque command limit value (during homing) to the rated torque.</p> <p>The parameter is used as a safety measure against collisions during Homing. It is a torque command limit value in Homing by using stopper.</p>			
Prerequisite	Homing: Home Reference Signal selection (No.645.0) = 1 (Stopper) or Torque command limit switch (No.647.0) = 1 (Enable)			
Related To	No.645.0、 No.647.0			


No. 657.0	Homing: Z-phase disabled distance	Range	Default	Characteristics
		0 to 1,000,000,000	0 [C-pulse]	—  —  —
Function Use	Set the shift amount between a detection position of home signal and a starting position of z-phase detection.			


No. 659.0	Homing: Timeout time	Range	Default	Characteristics
		0 to 60,000	60,000 [10ms]	—  —  —
Function Use	<p>Set the timeout time for homing.</p> <p>This is a safety measure in case of fault during homing.</p>			
Prerequisite	Timeout Switch (No.646.2) = 1 (Disable)			
Related To	No.646.2			

2. Parameters

3. Details of Parameters



No. 643.0	Internal position: Overflow detection	Settings 0, 1	Default 1	Characteristics — — —  —					
Function Use	Enable/Disable the multi-turn encoder counter overflow detection function for Positioner Drive using ABS value. This function is a protective measure against absolute position loss of the encoder.								
	If Internal Position Command exceeds the absolute value range (± 1,073,741,823), or shift amount per one command exceeds the range (± 2,147,487,647), overflow will be detected, resulting in Alarm No.10.								
	<table><tr><th>Settings</th><th>Overflow Detection</th></tr><tr><td>0</td><td>Disable (*1)</td></tr><tr><td>1</td><td>Enable (*2)</td></tr></table>	Settings	Overflow Detection	0	Disable (*1)	1	Enable (*2)		
Settings	Overflow Detection								
0	Disable (*1)								
1	Enable (*2)								
	<p>*1) For repeating rotations only in one direction, when you need absolute value of single-turn angle, set Absolute system (No.257.0) = 1 (Multi-turn counter overflow detection disabled)</p> <p>*2) When you set Absolute system (No.257.0) = 2 (Multi-rotation counter overflow detection enabled), Alarm No.11 occurs if multi-turn data exceeds the rated range (± 32,767). Select a value for internal position command not larger than the rated value.</p>								
Remark	<ul style="list-style-type: none">• "Absolute Value" Operation using Positioner, and Testing. Set this parameter to "0" and the command method for point table to "relative value". Setting "absolute value" will result in Alarm No.10.• When the setting was changed from "0" to "1", perform homing.								
Related To	No.257.0								

No. 720.0 No. 740.0 ... No. 1020.0	Internal Position: Point table Command method (*)	Settings	Default	Characteristics
		0, 1	0	— — —  —
Function Use	Select the <u>command method</u> for point table.			
	Settings	Command Method	Position to be set	
	0	Absolute value	Target position	
	1	Relative value	Shift amount from the current position to the target position	

The internal position control point table parameters (No.720.0 or later) are not displayed on the parameter tab screen of S-TUNE II. These parameters are displayed in the Point Table tabbed screen. See page 44 and later for detailed descriptions of the parameters.

*) See the Point Table Parameter List to look up a point number and its corresponding parameter numbers.

 Page 62



No. 720.1 No. 740.1 ... No. 1020.1	Internal Position: Point table Operation (*)	Settings	Default	Characteristics
		0, 1	0	--- ---

Select the Running Motion of Point Table.

SettingsRunning Motion

0

Single:
After the motion commanded by this point number is complete, the subsequent point numbers will not be executed.
Example: Point No.1 and 2 are set to "Single".

Description	Signal Name	Chart
Select Point No.	PCSEL1...4 Input	
Start	PCSTART1 Input	
Motor Rotational Speed	—	

Continuous:
The subsequent point number(s) will be executed one after another.

Example-1: The dwell time is set to 1 or above (for example, 3 ms).
Then positioning will be executed according to each point. After the positioning is determined to be completed, the next motion will not start until the dwell time elapses.

Description	Signal Name	Chart
Select Point No.	PCSEL1...4 Input	
Start	PCSTART1 Input	
Motor Rotational Speed	—	
Position Deviation	—	

Example-2: The dwell time is set to 0.
The motor will keep rotating and the rotational speed will continuously change.

Description	Signal Name	Chart
Select Point No.	PCSEL1...4 Input	
Start	PCSTART1 Input	
Motor Rotational Speed	—	

Function Use

1

The internal position control point table parameters (No.720.0 or later) are not displayed on the parameter tab screen of S-TUNE II. These parameters are displayed in the Point Table tabbed screen. See page 44 and later for detailed descriptions of the parameters.

*) See the Point Table Parameter List to look up a point number and its corresponding parameter numbers.

2. Parameters

3. Details of Parameters



No. 720.3 No. 740.3 ... No. 1020.3	Internal Position: Point table Enable/Disable (*)	Settings	Default	Characteristics
		0, 1	0	--- ---

Enable/Disable Point Table.

Settings	Enable/Disable
0	Disable The point number assigned "disable" is not executed and any subsequent point numbers assigned "enable" are executed.
1	Enable The point number assigned "enable" is executed

If the point number with the "disable" setting is specified,
among the subsequent point numbers, the first one with "enable" will be executed.


If there is a "disabled" point number during a series of "continuous" motions,
that "disabled" point number will not be executed and the first "enabled" subsequent point
number will be executed.

If point number with "continuous" motion and "0" dwell time,
motions before and after that point number will be executed one after the other and the speed
will change continuously.

Example:

If Point No.1 is specified and Start signal is input were the following Point number settings are as follows, Point No.2 will not be executed and Point No.1 and No.3 will be executed continuously.

Point No.	Motion	Dwell time	Enable/Disable
1	Continuous	0	Enable
2	Continuous	(any value)	Disable
3	Single	(any value)	Enable



■ TIP

For the last point number set to "enable" (i.e. last to be executed), **set its Running Motion to "single"**. If you set "continuous" to the last enabled point number, Operation Complete output (MEND) will remain off and the next motion will be not be started. If that happens, perform the following.

User I/O operation

Turn the servo off or input Clear Deviation Counter.

S-TUNE II operation

Turn the servo off or click the STOP button.


Function
Use

3. Details of Parameters


Position Control Mode

Internal Position Command




No. 722.0 No. 742.0 ... No. 1022.0	Internal Position: Point table Position (*)	Range	Default	Characteristics
		-1,073,741,823 to +1,073,741,823	0 [E-pulse]	- - -  -

Function Use	<p>Set the target position in Point Table.</p> <ul style="list-style-type: none"> ■ If Relative Value is selected as the Command method, position data will determine the shift amount. Enter a positive value for CCW rotation or a negative value for CW rotation. ■ If Absolute Value is selected as the Command method, position data will determine the target position. This value corresponds to ABS Position Command value (Status No.74). 			
Related To	No.643.0			

No. 724.0 No. 744.0 ... No. 1024.0	Internal Position: Point table Rotational speed (*)	Range	Default	Characteristics
		0 to 6,300	0 [r/min]	- - -  -

Function Use	<p>Set the motor rotational speed for the Point Table.</p> <p>Set this to a speed no higher than the max rotational speed of the motor.</p>			
--------------	---	--	--	--

No. 726.0 No. 746.0 ... No. 1026.0	Internal Position: Point table Acceleration time (*)	Range	Default	Characteristics
		0 to 5,000	30 [ms]	- - -  -

Function Use	<p>Set the acceleration time for the Point table.</p> <p>This item indicates the amount of time for a speed command to change from 0 r/min to 1,000 r/min. In the default setting, it takes 90 ms for the rotational speed to change from 0 r/min to 3,000 r/min.</p>			
--------------	---	--	--	--

No. 727.0 No. 747.0 ... No. 1027.0	Internal Position: Point table Deceleration time (*)	Range	Default	Characteristics
		0 to 5,000	30 [ms]	- - -  -

Function Use	<p>Set the deceleration time for the Point Table.</p> <p>This item indicates the amount of time for a speed command to change from 0 r/min to 1,000 r/min. In the default setting, it takes 90 ms for the rotational speed to change from 3,000 r/min to 0 r/min.</p>			
--------------	---	--	--	--

The internal position control point table parameters (No.720.0 or later) are not displayed on the parameter tab screen of S-TUNE II. These parameters are displayed in the Point Table tabbed screen. See page 44 and later for detailed descriptions of the parameters.

*) See the Point Table Parameter List to look up a point number and its corresponding parameter numbers.


2. Parameters

3. Details of Parameters

Position Control Mode

Internal Position Command



No. 728.0 No. 748.0 ... No. 1028.0	Internal Position: Point table Dwell time (*)	Range 0 to 20,000	Default 1 [ms]	Characteristics - - -  -
---	---	----------------------	------------------------	--

Function
Use

Set the dwell time for the Point Table.


Dwell time is the wait time for the next Point-Table motion to be executed after a Point-Table motion is complete.

■ Motion after the dwell time elapses:

Single motion: MEND will be ON.

Continuous motions: the motion commanded by the next point number will start.

If Running Motion is "Continuous" and the dwell time is set to 0, the motion will be according to the speed assigned by point numbers -one after another continuously. If the dwell time is set to 0, the acceleration/deceleration setting in the first point number selected upon CW start PCSTART1 ON will be applied, and the settings of subsequent point numbers will be discarded.

No. 729.0 No. 749.0 ... No. 1029.0	Internal Position: Point table Positioning completion (*)	Range 0 to 32,767	Default 20 [E-pulse]	Characteristics - - -  -
---	---	----------------------	------------------------------	--


Function
Use

Set the range for positioning complete by the Point table.

Set a position deviation threshold to determine whether or not positioning is complete.

After the motion specified by the point number has been complete, when the position deviation falls in the range set by this item and then the Dwell time elapses, the MEND (motion end) signal turns ON.

■ Timing Diagram of Positioning Complete and Dwell Time





Position Control Mode

Internal Position Command



Point Table Parameter List

Point No.	Position [C-pulse]	Rotational speed [r/min]	Acceleration time [ms]	Deceleration time [ms]	Command method [-]	Dwell time [ms]	Operation [-]	Positioning completion [E-pulse]	Enable /Disable [-]
0	No. 722.0	No. 724.0	No. 726.0	No. 727.0	No. 720.0	No. 728.0	No. 720.1	No. 729.0	No. 720.3
1	No. 742.0	No. 744.0	No. 746.0	No. 747.0	No. 740.0	No. 748.0	No. 740.1	No. 749.0	No. 740.3
2	No. 762.0	No. 764.0	No. 766.0	No. 767.0	No. 760.0	No. 768.0	No. 760.1	No. 769.0	No. 760.3
3	No. 782.0	No. 784.0	No. 786.0	No. 787.0	No. 780.0	No. 788.0	No. 780.1	No. 789.0	No. 780.3
4	No. 802.0	No. 804.0	No. 806.0	No. 807.0	No. 800.0	No. 808.0	No. 800.1	No. 809.0	No. 800.3
5	No. 822.0	No. 824.0	No. 826.0	No. 827.0	No. 820.0	No. 828.0	No. 820.1	No. 829.0	No. 820.3
6	No. 842.0	No. 844.0	No. 846.0	No. 847.0	No. 840.0	No. 848.0	No. 840.1	No. 849.0	No. 840.3
7	No. 862.0	No. 864.0	No. 866.0	No. 867.0	No. 860.0	No. 868.0	No. 860.1	No. 869.0	No. 860.3
8	No. 882.0	No. 884.0	No. 886.0	No. 887.0	No. 880.0	No. 888.0	No. 880.1	No. 889.0	No. 880.3
9	No. 902.0	No. 904.0	No. 906.0	No. 907.0	No. 900.0	No. 908.0	No. 900.1	No. 909.0	No. 900.3
10	No. 922.0	No. 924.0	No. 926.0	No. 927.0	No. 920.0	No. 928.0	No. 920.1	No. 929.0	No. 920.3
11	No. 942.0	No. 944.0	No. 946.0	No. 947.0	No. 940.0	No. 948.0	No. 940.1	No. 949.0	No. 940.3
12	No. 962.0	No. 964.0	No. 966.0	No. 967.0	No. 960.0	No. 968.0	No. 960.1	No. 969.0	No. 960.3
13	No. 982.0	No. 984.0	No. 986.0	No. 987.0	No. 980.0	No. 988.0	No. 980.1	No. 989.0	No. 980.3
14	No. 1002.0	No. 1004.0	No. 1006.0	No. 1007.0	No. 1000.0	No. 1008.0	No. 1000.1	No. 1009.0	No. 1000.3
15	No. 1022.0	No. 1024.0	No. 1026.0	No. 1027.0	No. 1020.0	No. 1028.0	No. 1020.1	No. 1029.0	No. 1020.3

The internal position control point table parameters (No.720.0 or later) are not displayed on the parameter tab screen of S-TUNE II. These parameters are displayed in the Point Table tabbed screen. See page 44 and later for detailed descriptions of the parameters.

2. Parameters




3. Details of Parameters

3. Velocity Control Mode

Velocity Control Mode

Velocity Command Input





No. 62.0 (203Eh)	EtherCAT Communication Velocity command: Rotational direction	Settings	Default	Characteristics
		0, 1	1	 —  
Function Use	Select the rotational direction of EtherCAT Communication velocity command input.			
	Settings	Negative Voltage Input	Positive Voltage Input	
	0	CCW Rotation	CW Rotation	
	1	CW Rotation	CCW Rotation	



3. Details of Parameters


Velocity Control Mode


Tuning Parameters




No. 129.0 (2081h)	Tuning: Velocity control mode - Control gain set	Range	Default	Characteristics																			
		1 to 46	15 [-]	 - -  -																			
Function Use	Set the Control Gain Set for <u>Velocity Control Mode</u> . With this, Control gain 1 (No.131.0) and Integral gain (No.133.0) will be set to the default together.																						
	■ Noise Solutions ① Use Torque command filter: Notch filter (such as No.160.1) ② Decrease Integral gain (No.133.0)																						
	If the above does not work, lower the Control Grain Set.																						
	<table border="1"> <thead> <tr> <th>Setting</th><th>Command Response</th><th>Rigidity</th><th>Settling Time</th><th>Possibility of Noise</th></tr> </thead> <tbody> <tr> <td>1</td><td>Slower</td><td>Lower</td><td>Longer</td><td>Lower</td></tr> <tr> <td>↑</td><td>↑</td><td>↑</td><td>↑</td><td>↑</td></tr> <tr> <td>46</td><td>Faster</td><td>Higher</td><td>Shorter</td><td>Higher</td></tr> </tbody> </table>				Setting	Command Response	Rigidity	Settling Time	Possibility of Noise	1	Slower	Lower	Longer	Lower	↑	↑	↑	↑	↑	46	Faster	Higher	Shorter
Setting	Command Response	Rigidity	Settling Time	Possibility of Noise																			
1	Slower	Lower	Longer	Lower																			
↑	↑	↑	↑	↑																			
46	Faster	Higher	Shorter	Higher																			
Prerequisite	Velocity Control Mode																						
Remark	<ul style="list-style-type: none"> Too large a value may result in noise. If Torque command filter: Low-pass filter constant (No.162.0) is set to 1 (auto setting ON), Torque command filter: Low-pass filter auto setting (No.160.2) will be included in the gain set. 																						
Related To	No.131.0、 No.132.0、 No.133.0、 No.162.0																						

No. 130.0 (2082h)	Tuning: Velocity control mode - Control level	Range	Default	Characteristics																			
		1 to 46	15 [-]	 - -  -																			
Function Use	Specify the Control Level for <u>Velocity Control Mode</u> . Set Control Gain 1 (No.131.0) to the preset value which was prepared every established each control level.																						
	■ Noise Solutions ① Use Torque command filter: Notch filter (such as No.160.1). ② Decrease Integral Gain (No.133.0).																						
	If any of the above does not work, then lower the Control Level .																						
	<table border="1"> <thead> <tr> <th>Setting</th><th>Command Response</th><th>Rigidity</th><th>Settling Time</th><th>Possibility of Noise</th></tr> </thead> <tbody> <tr> <td>1</td><td>Slower</td><td>Lower</td><td>Longer</td><td>Lower</td></tr> <tr> <td>↑</td><td>↑</td><td>↑</td><td>↑</td><td>↑</td></tr> <tr> <td>46</td><td>Faster</td><td>Higher</td><td>Shorter</td><td>Higher</td></tr> </tbody> </table>				Setting	Command Response	Rigidity	Settling Time	Possibility of Noise	1	Slower	Lower	Longer	Lower	↑	↑	↑	↑	↑	46	Faster	Higher	Shorter
Setting	Command Response	Rigidity	Settling Time	Possibility of Noise																			
1	Slower	Lower	Longer	Lower																			
↑	↑	↑	↑	↑																			
46	Faster	Higher	Shorter	Higher																			
Prerequisite	Velocity Control Mode																						
Remark	Setting Control Level will invalidate the setting of Control gain set (No.129.0).																						
Related To	No.129.0、 No.131.0、 No.133.0、 No.162.0																						

The following common parameters are described in "position control tuning parameter".

No.102.0, No.103.0, No.106.0, No.110.0, No.110.1






No.	Tuning:	Range	Default	Characteristics
No. 131.0 (2083h)	Velocity control mode - Control gain 1	100 to 6,000	399 [rad/s]	-- --
Function Use	<p>Set Control Gain 1 for <u>Velocity Control Mode</u>.</p> <p>The larger this parameter is, the smaller the speed deviation of the command being input becomes. Increasing this parameter value provides faster command response; however, too large a value may result in noise.</p> <p>■ Noise Solutions</p> <p>① Use Torque command filter: Notch filter (such as No.160.1). ② Decrease Integral Gain (No.133.0).</p> <p>If any of the above does not work, lower the Control Gain 1.</p>			
Prerequisite	Velocity Control Mode			
Remark	<p>Making a change to any of the following will also change other tuning parameters (such as Gain FF Compensation 1) to the prearranged parameter set all at once.</p> <ul style="list-style-type: none"> • Control gain set (No.129.0) • Control level (No.130.0) 			
Related To	No.129.0、 No.130.0、 No.132.0			
No.	Tuning:	Range	Default	Characteristics
No. 132.0 (2084h)	Velocity control mode - Gain FF compensation 1	0 to 15,000	0 [0.01%]	-- --
Function Use	<p>Set Field Forward Compensation Rate with respect to Control Gain 1 for <u>Velocity Control Mode</u>.</p> <p>Increase the value of this parameter to provide faster command response. In the event of noise, decrease the setting value a little.</p>			
Prerequisite	Velocity Control Mode			
Related To	No.129.0、 No.130.0、 No.131.0、 No.133.0、 No.162.0			
No.	Tuning:	Range	Default	Characteristics
No. 133.0 (2085h)	Velocity control mode - Integral gain	45 to 5,000	300 [rad/s]	-- --
Function Use	<p>Set the Integral Gain for <u>Velocity Control Mode</u>.</p> <p>Increase the value of Integral Gain to improve the convergence (interfered by friction or load fluctuation) at the time of settling, and reduce position deviations. This will result in rigid and sensitive motions.</p> <p>■ Noise Solutions</p> <p>① Use Torque command filter: Notch filter (such as No.160.1). ② Decrease the value of Integral Gain.</p>			
Prerequisite	Velocity Control Mode			
Remark	This parameter will reset to the prearranged value if Inertia conditions or Control Gain Set is changed.			
Related To	No.129.0、 No.130.0、 No.131.0、 No.132.0、 No.162.0			



2. Parameters

3. Details of Parameters

4. Torque Control Mode

 ... Torque Control Mode
 ... Torque Command Input

No. 152.0 (6080h)	EtherCAT Communication Torque command: Speed Limit	Range	Default	Characteristics
		0 to 10,000	Max. motor speed [r/min]	 –   –
Function Use	Set the speed limit for <u>Torque Control Mode</u> .			
Prerequisite	Torque Control Mode			





No. 302.0 (212Eh)	EtherCAT Communication Torque command: Direction of rotation	Settings	Default	Characteristics
		0, 1	1	 — —  —
Function Use	Specify the rotational direction of EtherCAT Communication torque command input.			
	Settings	Negative Voltage Input	Positive Voltage Input	
	0	CCW Rotation	CW Rotation	
	1	CW Rotation	CCW Rotation	



2. Parameters

3. Details of Parameters

5. Vibration Suppress Filter







No. 66.0 (2042h)	Position command filter 1: Selection	Settings	Default	Characteristics
		0 to 3	0	 --   
Function Use	Select no filter or one of the three filters:			
	Settings	Filter Type		
	0	No filter		
	1	Smoothing Filter 1		
	2	Notch filter		
	3	γ -Notch Filter		
Remark	If you are to use Smoothing Filter 1, try Filter 4 (Smoothing Filter 2) first.			
Related To	No.80.0、 No.74.0、 No.75.0、 No.76.0、 No.79.0			





No. 66.1	Position command filter 4: Selection	Settings	Default	Characteristics
		0, 1	1	— — —  
Function Use	Enable/Disable Position command Smoothing Filter 2 for Filter 4.			
	Settings	Filter		
	0	Disable		
	1	Enable		
Remark	If you are to use Smoothing Filter 1, try Filter 4 (Smoothing Filter 2) first.			
Related To	No.81.0			




3. Details of Parameters



No. 74.0 (204Ah)	Position command filter 1: Notch frequency	Range	Default	Characteristics
		10 to 2,000	10 [0.1Hz]	—
Function Use	Set the notch frequency for Position command filter 1.			
Prerequisite	Position command filter 1: Type (No.66.0) = 2 (Notch filter) or 3 (γ-Notch filter)			
Related To	No.66.0、No.75.0、No.76.0、No.79.0			

No. 75.0 (204Bh)	Position command filter 1:	Range	Default	Characteristics
	Notch width	128 to 2,048	512 [-]	 —   
Function Use	Set the width of notch of Position Command Filter 1.			
	Setting	Notch Width		
	Smaller	Narrower		
	Larger	Wider		
Prerequisite	Position command filter 1: Type (No.66.0) = 2 (Notch filter)			
Related To	No.66.0、No.74.0、No.79.0			


No. 76.0 (204Ch)	Position command filter 1: High frequency gain	Range	Default	Characteristics								
		50 to 200	100 [-]	 --   								
Function Use	Set the high frequency gain of Position Command Filter1.											
	<table><tr><th>Setting</th><th>Effect</th></tr><tr><td>50</td><td>x0.25</td></tr><tr><td>100</td><td>x1</td></tr><tr><td>200</td><td>x4</td></tr></table>				Setting	Effect	50	x0.25	100	x1	200	x4
	Setting	Effect										
	50	x0.25										
	100	x1										
200	x4											
Smaller setting value gives better vibration suppression. Larger setting value gives faster motion.												
Prerequisite	Position command filter 1: Type (No.66.0) = 3 (γ -Notch filter).											
Related To	No.66.0、 No.74.0、 No.79.0											

No. 79.0 (204Fh)	Position command filter 1: Notch depth	Range	Default	Characteristics
		0 to 100	0 [-]	 —  
Function Use	Set the notch depth of Position command filter 1.			
	Setting	Notch Depth		
	0	Complete shutoff of notch frequency input		
	100	100% pass-through		
	Smaller setting value gives deeper filter. Larger setting value gives shallower filter.			
Prerequisite	Position command filter 1: Type (No.66.0) = 2 (Notch filter) or 3 (γ -Notch filter)			
Related To	No.66.0、No.74.0、No.75.0、No.76.0			

2. Parameters





3. Details of Parameters







No.	Position command filter 1:	Range	Default	Characteristics
No. 80.0 (2050h)	Smoothing 1 - Moving average counter	1 to 6,250	40 [-]	
No. 81.0 (2051h)	Position command filter 4: Smoothing 2 - Moving average counter	1 to 1,250	16 [-]	
Function Use	<p>These items are used to smooth the speed changes in high deceleration/acceleration, and can be used to suppress vibrations at settling time as well.</p> <p><u>Use Filter 4 (Smoothing Filter 2) first.</u> To increase the smoothing effect further, use Filter 1 (Smoothing filter 1).</p> <p>A larger value makes acceleration and deceleration smoother, but the response will become slower. See the table below for the delay time calculation formula. Filter 4 (Smoothing Filter 2) suppress the vibrations caused by the Gain FF compensation 2.</p> <div>Delay time Calculation Formula</div> <div>100 μs × Moving average count = Delay time</div>			
	<p>■ Setup of Vibration Suppression</p> <p>Positioning will take longer as much as the delay time specified above. Set this item within the range acceptable to the equipment.</p> <p>① Check the vibration interval in waveforms of position deviation and torque command at settling time. ② Calculate the moving average count as described below. ③ Using Filter 4 may reduce the resonant vibrations. ④ If suppression of the vibrations is not effective enough, recalculate the moving average count based on the vibration interval, and set it to Filter 1.</p> <div>Moving average count and Vibration interval to compress</div> <div>10,000 × Vibration interval [s] = Moving average count</div>			
	Prerequisite			
	Remark			
Related To				




3. Details of Parameters



No. 82.0 (2052h)	Position command filter 2:	Settings	Default	Characteristics
	Selection	0 to 3	0	 —   
Function Use	Set the Position Command Filter 2.			
	Settings	Filter Type		
	0	No filter		
	1	Reserved (Do not use)		
	2	Notch filter		
	3	γ -Notch Filter		
Related To	No.83.0、No.84.0、No.85.0、No.86.0			

No. 82.1 (2052h)	Position command filter 3: Selection	Settings	Default	Characteristics
		0 to 3	0	 —   
Function Use	Set Position Command Filter 3.			
	Settings	Filter Type		
	0	No filter		
	1	Reserved (Do not use)		
	2	Notch filter		
	3	γ-Notch Filter		
Related To	No.357.0、No.358.0、No.359.0、No.360.0			





No. 83.0 (2053h)	Position command filter 2: Notch frequency	Range	Default	Characteristics
		10 to 2,000	10 [0.1Hz]	—
Function Use	Set the notch frequency for Position command filter 2.			
Prerequisite	Position command filter 2: Select (No.82.0) = 2 (Notch filter) or 3 (γ -Notch filter)			
Related To	No.82.0、No.84.0、No.85.0、No.86.0			





No. 84.0 (2054h)	Position command filter 2: Notch width		Range	Default	Characteristics
			128 to 2,048	512 [-]	 —  
Function Use	Set the notch width of Position Command Filter 2.				
	Setting		Notch Width		
	Smaller		Narrower		
	Larger		Wider		
Prerequisite	Position command filter 2: Select (No.82.0) = 2 (Notch filter)				
Related To	No.82.0、No.83.0、No.85.0、No.86.0				

2. Parameters

3. Details of Parameters







No. 85.0 (2055h)	Position command filter 2: High frequency gain	Range	Default	Characteristics
		50 to 200	100 [-]	 —   
Function Use	Set the high frequency gain for Position Command Filter 2.			
	Setting	Effect		
	50	x0.25		
	100	x1		
	200	x4		
	Smaller setting value gives better vibration suppression. Larger setting value gives faster motion.			
Prerequisite	Position command filter 2: Type (No.82.0) = 3 (γ -Notch Filter)			
Related To	No.82.0、 No.83.0、 No.86.0			



No. 86.0 (2056h)	Position command filter 2: Notch depth	Range	Default	Characteristics
		0 to 100	0 [-]	 —   
Function Use	Specify the notch depth of Position Command Filter2.			
	Setting	Effect		
	0	Complete shutoff of notch frequency input		
	100	100% pass-through		
	Smaller setting value gives deeper filter. Larger setting value gives shallower filter.			
Prerequisite	Position command filter 2: Select (No.82.0) = 2 (Notch filter) or 3 (γ -Notch filter)			
Related To	No.82.0、 No.83.0、 No.84.0、 No.85.0			




3. Details of Parameters





No. 357.0 (2165h)	Position command filter 3: Notch frequency	Range	Default	Characteristics
		10 to 2,000	10 [0.1Hz]	 —   
Function Use	Set the notch frequency for Position Command Filter 3.			
Prerequisite	Position command filter 3: Type (No.82.1) = 2 (Notch filter) or 3 (γ -Notch Filter)			
Related To	No.82.1、 No.358.0、 No.359.0、 No.360.0			



No. 358.0 (2166h)	Position command filter 3: Notch width	Range	Default	Characteristics
		128 to 2,048	512 [-]	 —   
Set the width of notch of Position Command Filter3.				
Function Use				
	Setting	Notch Width		
	Smaller	Narrower		
	Larger	Wider		
Prerequisite	Position command filter 3: Type (No.82.1) = 2 (Notch filter)			
Related To	No.82.1、 No.357.0、 No.360.0			



No. 359.0 (2167h)	Position command filter 3: High frequency gain	Range	Default	Characteristics
		50 to 200	100 [-]	 —   
Set the high frequency gain for Position Command Filter3.				
Function Use				
	Setting	Effect		
	50	x0.25		
	100	x1		
	200	x4		
Smaller setting value gives better vibration suppression. Larger setting value gives faster motion.				
Prerequisite	Position command filter 3: Type (No.82.1) = 3 (γ -Notch Filter)			
Related To	No.82.1、 No.357.0、 No.360.0			



No. 360.0 (2168h)	Position command filter 3: Notch depth	Range	Default	Characteristics
		0 to 100	0 [-]	 —   
Set the depth for Position Command Filter 3.				
Function Use				
	Setting	Notch Depth		
	0	Complete shutoff of notch frequency input		
	100	100% pass-through		
Smaller setting value gives deeper filter. Larger setting value gives shallower filter.				
Prerequisite	Position command filter 3: Type (No.82.1) = 2 (Notch filter) or 3 (γ -Notch Filter)			
Related To	No.82.1、 No.357.0、 No.358.0、 No.359.0			



No. 160.0 (20A0h)	Torque command filter: Low-pass filter - Switch	Settings	Default	Characteristics
		0, 1	1	 -- --  --
Function Use	Enable/Disable Low-pass filter.			
	This filter is a first-order IIR filter.			
	Settings	First-order IIR filter		
	0	Disable		
	1	Enable		
Related To	No.113.0、No.160.2、No.162.0			




No. 160.1 (20A0h)	Torque command filter: Notch filter - Switch	Settings	Default	Characteristics
		0, 1	0	 -- --  --
Function Use	Enable/Disable Notch filter.			
	Settings	Notch filter		
	0	Disable		
	1	Enable		
Related To	No.168.0、No.169.0、No.170.0			

No. 160.2 (20A0h)	Torque command filter: Low-pass filter - Auto setting	Settings	Default	Characteristics
		0, 1	0	 -- --  --
Function Use	Enable/Disable the automatic configuration of [Torque command filter: Low-pass filter time constant (No.162.0)] according to the settings of the control gain sets; Position Control Mode (No.113.0) and Velocity Control Mode (No.129.0).			
	Settings	Auto setting		
	0	Auto setting OFF		
	1	Auto setting ON		
Prerequisite	Torque command filter: Low-pass filter switch (No.160.0) = 1 (Enable)			
Related To	No.113.0、No.129.0、No.160.0、No.162.0			



No. 160.3 (20A0h)	Torque command filter: Notch filter 2 - Switch	Settings	Default	Characteristics
		0, 1	0	 -- --  --
Function Use	Enable/Disable Torque command Notch filter 2			
	Settings	Torque command- Notch filter 2		
	0	Disable		
	1	Enable		
Related To	No.171.0、No.172.0、No.173.0			

3. Details of Parameters







No. 162.0 (20A2h)	Torque command filter: Low-pass filter - Time constant	Range	Default	Characteristics						
		0 to 65,535	(See below) [0.01 ms]	 —  —  —						
Function Use	Set the primary IIR filter time constant of [Torque command filter: Low-pass filter switch (No.160.0)] = 1 (Enable)									
	Condition for Time Constant: <div>$\frac{(0.1 \text{ to } 0.2)}{\max((\omega_1 + \omega_2), \omega_q)}$</div> [s] or below									
	■ Default Each motor series have their own default values.									
	<table><tr><th>Motor Capacity</th><th>Default [0.01 ms]</th></tr><tr><td>50 W to 750 W</td><td>0</td></tr><tr><td>1 kW to 2 kW</td><td>10</td></tr></table>				Motor Capacity	Default [0.01 ms]	50 W to 750 W	0	1 kW to 2 kW	10
	Motor Capacity	Default [0.01 ms]								
50 W to 750 W	0									
1 kW to 2 kW	10									
Prerequisite	Torque command filter: Low-pass filter switch (No.160.0) = 1 (Enable)									
Remark	Example: Calculating in time unit and converting to frequency 20 [0.01 ms/rad] → 5,000 rad/s (equivalent to 796 Hz)									
Related To	No.113.0、 No.160.0、 No.160.2									



No. 168.0 (20A8h)	Torque command filter: Notch filter - Frequency	Range	Default	Characteristics
		0 to 2,500	2,500 [Hz]	-- -- --
Function Use	Set the notch frequency for the Torque command filter - notch filter.			
	This item is measured with S-TUNE II .			
Prerequisite	Torque command filter: Notch filter switch (No.160.1) = 1 (Enable)			
Related To	No.160.1、 No.169.0、 No.170.0			

No. 169.0 (20A9h)	Torque command filter: Notch filter - Width	Range	Default	Characteristics
		1 to 16	8	 — —  —
Function Use	Set the notch width of torque command notch filter.			
	In the default setting of this parameter, notch width=notch frequency (a factor of x1). The larger this item is, the larger the notch width is.			
	In the case of multiple notch frequencies, this item increases the notch width.			
	Setting	Factor	Notch Width	
	16	x2	Large ↑ ↓ Small	
	12	x1.5		
8	x1			
	4	x0.5		
Prerequisite	Torque command filter: Notch filter switch (No.160.1) = 1 (Enable)			
Related To	No.160.1、 No.168.0、 No.170.0			





No. 170.0 (20AAh)	Torque command filter: Notch filter - Depth	Range	Default	Characteristics
		0 to 256	0 [-]	 --  --
Function Use	Set the depth at the notch frequency of Torque command Notch filter.			
	Setting	Notch Depth		
	0	Complete shutoff of notch frequency input		
	↑ ↓	↑ ↓		
	256	100% pass-through		
	<div>• The larger this item is, the shallower the notch depth is.</div> <div>• If the noise cannot be eliminated by setting a notch filter, increase the setting gradually (e.g., 50, 100, 150 and so on), which decreases the notch depth.</div>			
Prerequisite	Torque command filter: Notch filter switch (No.160.1) = 1 (Enable)			
Related To	No.160.1 No.168.0 No.169.0			

No. 171.0 (20ABh)	Torque command filter: Notch filter 2 - Frequency	Range	Default	Characteristics
		0 to 2,500	2,500 [Hz]	 --  --
Function Use	Set the notch frequency of torque command notch filter 2.			
Prerequisite	Torque command filter: Notch filter 2 switch (No.160.3) = 1 (Enable)			
Related To	No.160.3、 No.172.0、 No.173.0			

No. 172.0 (20ACh)	Torque command filter: Notch filter 2 - Width	Range	Default	Characteristics
		1 to 16	8	 --  --
Function Use	Set the notch width of torque command notch filter 2.			
	In the default setting of this parameter, notch width=notch frequency (a factor of x1). The larger this item is, the larger the notch width is. In the case of multiple notch frequencies, this item increases the notch width.			
	Setting	Factor	Notch Width	
	16	x2	↑ ↓	
	12	x1.5		
	8	x1		
	4	x0.5		
		Small		
Prerequisite	Torque command filter: Notch filter 2 switch (No.160.3) = 1 (Enable)			
Related To	No.160.3、 No.171.0、 No.173.0			



No. 173.0 (20ADh)	Torque command filter: Notch filter 2 - Depth	Range	Default	Characteristics								
		0 to 256	0 [-]	 — — 								
Function Use	Set the depth at the notch frequency of Torque command Notch filter 2.											
	<table><tr><th>Setting</th><th>Notch Depth</th></tr><tr><td>0</td><td>0% pass-through</td></tr><tr><td>↑ ↓</td><td>↑ ↓</td></tr><tr><td>256</td><td>100% pass-through</td></tr></table>				Setting	Notch Depth	0	0% pass-through	↑ ↓	↑ ↓	256	100% pass-through
	Setting	Notch Depth										
	0	0% pass-through										
	↑ ↓	↑ ↓										
256	100% pass-through											
<ul style="list-style-type: none">• The larger this item is, the shallower the notch depth is.• If the noise cannot be eliminated by setting a notch filter, increase the setting gradually (e.g., 50, 100, 150 and so on), which decreases the notch depth.												
Prerequisite	Torque command filter: Notch filter switch (No.160.1) = 1 (Enable)											
Related To	No.160.3、 No.171.0、 No.172.0											

Tuning

1. Introduction	2
1. Control Block Diagram	4
2. Tuning Procedure	10
1. Position Control Mode	12
Quick Tuning on S-TUNE II	12
Final Tuning: Position Control Mode	15
2. Velocity Control Mode	17
Auto Tuning on S-TUNE II	17
Final Tuning: Velocity Control Mode	20
3. Tuning Parameters	23
1. Tuning	23
Inertia Condition	23
Control Gain Set	24
Mode Switch	25
Tuning Items	25
2. Final Tuning	26
Inertia Ratio	26
Position Control Mode: Control Gain 1	27
Position Control Mode: Control Gain 2	28
Velocity Control Mode: Control Gain 1	29
Position Control Mode: Gain FF Compensation 1	30
Position Control Mode: Gain FF Compensation 2	31
Integral Gain	32
3. Position Command Filter	33
Position Command Smoothing Filters 1 and 2	35
Position Command Notch Filter	36
Position Command γ -Notch Filter	37
4. Torque Command Filter	38
Torque Command Filter: Notch Filter	39
Torque Command Low-Pass Filter	40
4. Using S-TUNE II to Measure Vibration Frequency (FFT)	41

3. Tuning


1. Introduction

The goal of amplifier tuning is having a good control over the motor and optimizing equipment performance in responding to commands from the host controller.

The position control method employs two degrees of freedom with the model-matching control. This method enables you to adjust command response and turbulence response independently without compromising the stability of your equipment.

S-FLAG II is a servo system that does not let overshooting and undershooting happen when the equipment inertia ratio is set appropriately.

S-FLAG II features response models with two cutoff frequencies: $\omega 1$ (Control Gain 1) and $\omega 2$ (Control Gain 2)



Response model for position control and two cutoff frequencies

Code	EFFECT
$\omega 1$ Control Gain 1	Responsiveness at settling Increasing this item will reduce the position deviation at settling (after command ends).
$\omega 2$ Control Gain 2	Responsiveness during operation Increasing this item will reduce the position deviation during operation (while command being input).
FF1 FF Compensation 1	Command compensation for $\omega 1$ Increasing this item will improve the $\omega 1$ response.
FF2 FF Compensation 2	Command compensation for $\omega 2$ Increasing this item will improve the $\omega 2$ response.

The relation between cutoff frequencies and control gain parameters.


- Position loop gain (*1) : $\frac{\omega 1 \omega 2}{\omega 1 + \omega 2}$
- Velocity loop gain (*2) : $\omega 1 + \omega 2$

*1) Position loop gain It is equivalent to the "Kp" in a P-PI control.
*2) Velocity loop gain It is equivalent to the "Kv" in a P-PI control.

Control Gain Set

The following prearranged sets of parameters for each control mode enable you to perform tuning easily. ^(*)

^(*) If the [Torque command filter: Low-pass filter auto setting (No.160.2)] is set to 1(auto setting ON), "Torque command filter: Low-pass filter" will be included in the gain set.


Control Mode	Parameter Set
Position Control Mode 	Control Gain 1, Control Gain 2, Integral Gain
Velocity Control Mode 	Control Gain 1, Integral Gain

Inertia Condition

S-FLAG II features three response models to support a variety of equipment.

Three models are different in ratios of Control Gain 1 ($\omega 1$) and Control Gain 2 ($\omega 2$) and you can select the one suitable to the stability and convergence of your equipment.

Inertia Condition



Equipment Example

Higher stability


Good for applications of large load fluctuation
• Robot

Higher convergence

Micro vibration/
disturbance-resistant
Not easily vibrate
• Automatic machines
• Surface mounters

1. Introduction


1. Control Block Diagram




3. Tuning

1. Introduction

Position Control Mode (Related parameter)









Velocity Control Mode (Related parameter)

3. Tuning


1. Introduction









Torque Control Mode




Torque Control Mode (Related parameter)



2. Tuning Procedure

	Before getting started with tuning, be sure to implement safety measures such as hazard prevention, quick stop and impact mitigation measures.	 
	When operating the servo motor for tuning, start with acceleration/ deceleration speeds slower than your target speed. Ensure safety first, then gradually increase the speed and perform tuning each time.	 

For optimal performance of amplifier functions and features, you need set the parameters to the amplifier. Wrong parameter settings will cause unexpected behaviors or troubles to the motor. Please read the Instruction Manuals very carefully to figure out the settings that will best suit to your operational conditions.

Step	Operation
1	Verify that all wiring has been performed properly.
2	Turn on the control power to the amplifier.
3	Turn on the primary circuit power to the amplifier.
4	Input the Enable Operation (0x6040,3) signal to turn the servo ON.
5	Input the EtherCAT command from the host controller and operate the motor at low speed.
6	 Use the setup support software S-TUNE II . Install it on a user-supplied computer.

Any of the following may interrupt proper performance of Quick Tuning or Auto Tuning.

The inertia ratio is less than 3 or above 20. (*1)

The load inertia is fluctuating.

Machine rigidity is extremely low.

Non-linear characteristics such as backlash exist.

The speed is low (800 r/min or lower). (*2)

The acceleration or deceleration speed is moderate (around 2,000 r/min/s).

The torque is extremely large or small.

In those situations, set the inertia ratio manually based on calculated values.

*1) When a too big load inertia is connected, the estimated inertia ratio value will be restricted by the upper limit value settled by the upper limit value of the inertia ratio (No.106.0).

*2) Proper tuning may not be possible in the case of 300 r/min or below.

Position Control Mode

Stage 1

Quick Tuning

Setting the Inertia ratio and Optimizing Control Gain Set

The inertia ratio value is presumed automatically.

The control gain set will be automatically adjusted according to the auto estimate of inertia ratio.

This method does not generate noise caused by disagreement between the inertia ratio and the gain set.

 Page 12 Quick Tuning on S-TUNE II

Stage 2

Final Tuning

Optimizing the settling time
and deviation Suppressing vibration and noise

After Quick Tuning was performed, you might need further adjustments for some of the parameters individually.

Final Tuning will improve responsiveness, settling time, and degree of freedom to achieve optimal performance of equipment.

 Page 15 Final Tuning: position control mode

Velocity Control Mode

Stage 1

Auto Tuning

Setting the Inertia ratio and Optimizing Control Gain Set

The inertia ratio value is presumed automatically.

You can select one of the control gain sets according to your equipment.

Auto estimated inertia ratio will be applied.

 Page 17 Auto Tuning on S-TUNE II

Stage 2

Final Tuning

Optimizing the settling time
and deviation Suppressing vibration and noise

After Auto Tuning was performed, you might need further adjustments for some of the parameters individually.

Final Tuning will improve responsiveness, settling time, and degree of freedom to achieve optimal performance of equipment.

 Page 20 Final Tuning: Velocity control mode


2. Tuning Procedure

1. Position Control Mode


Quick Tuning on S-TUNE II



Stage 1 Setting the Inertia ratio and Optimizing Control Gain Set




Quick Tuning on S-TUNE II : Operation 1A





Quick Tuning on S-TUNE II : Operation 1B



*) Extremely large load may cause vibration. In such a case, decrease the parameter setting of Tuning: Control gain set - Tuning constant (No.121.0).




Make sure to click on **Stop to finish Quick Tuning.**

Starting Final Tuning Mode while Quick Tuning is still in process will make the tuning difficult because of inertia ratio changes.

Final Tuning: Position Control Mode




Stage 2 Optimizing the settling time and deviation Suppressing vibration and noise





Final Tuning



3. Tuning


2. Tuning Procedure

2. Velocity Control Mode

Auto Tuning on S-TUNE II




Stage 1 Setting the Inertia ratio and Optimizing Control Gain Set




*) Starting tuning with a low setting of the controller gain set will enable successful tuning with no vibrations accompanied by noise.

Auto Tuning on S-TUNE II : Operation 1A



Auto Tuning on S-TUNE II : Operation 1B




Make sure to click on **Stop** to finish Auto Tuning.

Starting Final Tuning Mode while Auto Tuning is still in process will make the tuning difficult because of inertia ratio changes.


Final Tuning: Velocity Control Mode



Stage 2 Optimizing the settling time and deviation Suppressing vibration and noise



Final Tuning





Confirm



Check the machine motion

Check the motor motions in test operation or by external command input.
Repeat the previous steps from the beginning.

Confirm

Select the Tuning tab

Waveform monitor tab

Select items to measure.


State Item tab

Select measurement conditions.

Waveform Record tab

Start Measuring

Click Capture waveform



3. Tuning

3. Tuning Parameters


1. Tuning

Inertia Condition



Function	To make the tuning operation easier, select the inertia condition suitable to your equipment. The inertia conditions that you select will determine the Control Gain 1-2 combination and their ratio.
Parameter No.113.1	Position Control Mode: Inertia conditions
Tuning Tip	Prioritize either stability or convergence according to the load and rigidity of your equipment. Be aware of the trade-off between stability and convergence.

Settings	Intended Use	Effect
1	heavy-load, high fluctuation equipment low-rigid equipment robot arms etc.	
2 (Default)	(moderate setting) general transport machines	
3	light-load equipment equipment that demands high-speed operation or settling-required	




Difference in convergence characteristics depending on the inertia condition settings

Control Gain Set



Function	With this parameter, a set of the tuning parameters can be set to their defaults all at once. ^(*1) Increasing the value of this parameter will improve the command response, position deviation during motion, settling time, and control rigidity.		
Parameter Set	No.113.0 (Position Control Mode)	Control level	No.114.0
		Control Gain 1	No.115.0
		Control Gain 2	No.116.0
		Integral gain	No.119.0
		Torque command filter: Low-pass filter time constant ⁽⁺²⁾	No.162.0
	No.129.0 (Velocity Control Mode)	Control level	No.130.0
Remark		Control Gain 1	No.131.0
		Integral gain	No.133.0
		Torque command filter: Low-pass filter time constant ⁽⁺²⁾	No.162.0
Remark	Too high a setting will cause noise. When increasing the value, check the resulting operation to avoid oscillation or vibration.		
Tuning Tip	• Set the value to 5 first to fix the inertia ratio. • Gradually increase the setting value while watching the motion. If noise occurs, use a notch filter or decrease the low-pass filter setting. <div style="display: flex; justify-content: flex-end; align-items: center;"> <div style="margin-right: 10px;"> </div> <div> Page 39 Torque Command Filter: Notch filter Page 40 Torque Command Low-Pass Filter </div> </div>		

*1) In the S-TUNE II parameters grouped in the control gain set are highlighted in green.



*2) This is when Low-pass filter auto Setting (No.160.2) = 1 (auto setting ON)

Control gain set settings	Command Responsiveness	Rigidity	Settling Time	Noise
5	Slow	Low	Long	Unlikely
10	↑ ↓	↑ ↓	↑ ↓	↑ ↓
15 (Default)				
20				
30	Quick	High	Short	Likely

Under the Auto Tuning tab, tick the detail setup box, and then select from 1-46 one by one.

3. Tuning

3. Tuning Parameters

Mode Switch



Function	Change the mode based on the direction of the load inertia and whether offset load is present or not.		
Parameter No.110.0	Settings	Mode	Balanced load or unbalanced load
	1	Standard Mode	Balanced load (horizontal motion)
	2 (Default)	Unbalanced Load Mode	Unbalanced load such as gravity is present
Remark	Use the Unbalanced Load Mode even for the case of balanced load (horizontal-axis motion).		
Prerequisite	Position Control Mode, Velocity Control Mode		

Tuning Items



Function	Setting the item(s) to be estimated during tuning.		
Parameter No.110.1	Settings (Tuning)	Estimate items	
		Inertia ratio	Damping ratio
	0 (Tuning Stop) (Default)	Do not estimate	Do not estimate
	1 (Tuning Start)	Estimate	
2 (Tuning Start)	Estimate		
Prerequisite	Position Control Mode, Velocity Control Mode		

2. Final Tuning

Inertia Ratio




Function	<p>Set the ratio of the load inertia to the rotor inertia of the motor. This item represents the ratio of the motor axis moment of inertia to the load moment of inertia. The inertia ratio used in S-FLAG II includes the motor rotor inertia (=100%).</p> <p>Example: inertia ratio 200% = motor rotor inertia 100% + output axis load 100% inertia ratio 1100% = motor rotor inertia 100% + output axis load 1000%</p> $\text{Inertia ratio} = \frac{(\text{load inertia}) + (\text{Rotor inertia})}{(\text{Rotor inertia})} \times 100 [\%]$
Parameter No.102.0	<p>Default: 250 [%]</p> <p>Setting range: 100 to 10,000</p>
Remark	Settings that are not right for the equipment will cause noise or vibration.
Tuning Tip	<p>Start with setting a right inertia ratio which will make your tuning easier.</p> <p>The auto estimate of inertia ratio during Quick Tuning will be capped by the upper bound limit (No.106.0). If the estimate value of the inertia ratio is higher than the upper limit, manually enter the estimated value after suppressing the vibration and noise with a notch filter first.</p> <p>Select the best inertia condition and set the control gain set (No.113.0, No.129.0) to "5" to perform the quick-tuning and auto-tuning. In case of vibrations at settling, perform damping adjustment and perform tuning again. Because this tuning must be performed under the condition where the inertia can be estimated, we recommend that you obtain the ratio estimate in test operation.</p>

3. Tuning Parameters

Position Control Mode: Control Gain 1



Function	Increasing this parameter value will reduce the position deviation after the command becomes zero. Increase when the convergence of the position deviation at settling is not good.
Parameter No.115.0	Default: 50 [rad/s] Setting range: 5 to 1,000
Remark	<p>Select a value no higher than Position Control Mode: Control Gain 2 (No.116.0). Set a value smaller than the value of Control Gain 2 (No.116.0). Making a change to any of the following will also change other tuning parameters (such as Control Gain 2) to the prearranged parameter set all at once.</p> <ul style="list-style-type: none"> • Control Gain Set (No.113.0) • Inertia conditions (No.113.1) • Control Level (No.114.0)
Tuning Tip	Increasing this parameter setting will improve the settling time in cases when increasing the control gain set or control level does not resolve poor convergence of position deviation, or noise is too much that the control gain set or control level should not be increased.




Position Control Mode: Control Gain 2



Function	<p>Increasing this parameter value will reduce the position deviation during command input.</p> <p>Increasing the parameter value provides faster command response; however, too large a value may result in noise.</p>
Parameter No.116.0	<p>Default: 200 [rad/s]</p> <p>Setting range: 80 to 5,000</p>
Remark	<p>Set a value larger than the value of Control Gain 1 (No.115.0). To reduce position deviations after the command becomes zero, increase the value of Control Gain 1 (No.115.0).</p> <p>The tuning parameters such as the Control gain 1 will be changed to the group of the preset value depending on changing the following parameters.</p> <ul style="list-style-type: none"> • Control gain set (No.113.0) • Inertia conditions (No.113.1) • Control level (No.114.0)
Tuning Tip	<p>Use this parameter when the load inertia or the load fluctuation is large. The responsiveness will be improved and the movement will be smoother.</p> <p>Noise Solutions</p> <ol style="list-style-type: none"> ① Use Torque command filter: Notch filter (such as No.160.1). ② Lower Torque command filter: Low-pass filter constant (No.162.0). ③ Lower Integral gain (No.119.0). <p>When no improvement have been seen if these ①, ②, and ③ method had been performed, please decrease the No.116.0 value.</p>

Position deviation




Differences in Position Deviation Convergence

3. Tuning Parameters

Velocity Control Mode: Control Gain 1



Function	Increasing this parameter value will reduce the velocity deviation during the acceleration/deceleration. Increasing the parameter value provides faster command response; however, too large a value may result in noise.
Parameter No.131.0	Default: 399 [rad/s] Setting range: 100 to 6,000
Remark	Making a change to any of the following will also change other tuning parameters (such as Gain FF Compensation 1) to the prearranged parameter set all at once. <ul style="list-style-type: none"> • Control gain set (No.129.0) • Control level (No.130.0)
Tuning Tip	Use this parameter when the load inertia or the load fluctuation is large. The responsiveness will be improved and the movement will be smoother. <u>Noise Solutions</u> <ol style="list-style-type: none"> ① Use Torque command filter: Notch filter (such as No.160.1). ② Lower Torque command filter: Low-pass filter constant (No.162.0). ③ Lower Integral gain (No.133.0) When no improvement have been seen if these ①, ②, and ③ method had been performed, please decrease the No.131.0 value.




Differences in Velocity Deviation Convergence

Position Control Mode: Gain FF Compensation 1



Function	This parameter will improve the responsiveness at a low gains setting. Set the Field Forward Compensation Rate (velocity) with respect to Control Gain 1 (No.115.0) for Position Control Mode. Using this parameter is effective to shorten the settling time.
Parameter No.117.0	Default: 10,000 [0.01%] Setting range: 0 to 15,000
Remark	<u>Guideline for Tuning</u> If the inertia ratio is right, setting this parameter to 10,000 will not cause overshooting nor undershooting.
Tuning Tip	<ul style="list-style-type: none"> Set the following before adjusting this parameter: Inertia ratio (No.102.0), Control gain set (No.113.0), Control Gain 1 (No.115.0), and Control Gain 2 (No.116.0) Setting this parameter too low will result in undershooting, too high in overshooting. Target the value which would make the settling time shorter. Too high a value of this parameter will result in overshooting, and too low in undershooting. Set relatively a moderate value. <u>Inertia condition Coarse tuning amount</u> <ol style="list-style-type: none"> 1: increment by 10 2: increment by 100




3. Tuning Parameters

Position Control Mode: Gain FF Compensation 2



Function	Increasing this parameter value will reduce the position deviation of the motor running at a constant speed. Raise the value of this item only after reducing the position deviation, by using Gain FF Compensation 1 (No.117.0) at settling.
Parameter No.118.0	Default: 0 [0.01%] Setting range: 0 to 15,000
Remark	If this parameter value is above 10,000, the position deviation will start appearing in a negative range. When the command resolution is low, increasing this parameter value will result in louder running sound.
Tuning Tip	With a right inertia ratio setting, setting this parameter to 10,000 minimizes the position deviation. Noise Solutions Adjusting Filter 4: Smoothing 2- Moving average counter (No.81.0) may reduce the noise.



Differences in Position Deviation Convergence


Integral Gain




Function	Set the Integral Gain. Increasing the integral gain will improve poor convergence due to friction and load fluctuation at settling and reduce the position deviations. This will result in rigid and sensitive motions.		
Parameter No.119.0	Position Control Mode	Default :	160 [rad/s]
		Setting range :	45 to 5,000
Parameter No.133.0	Velocity Control Mode	Default :	300 [rad/s]
		Setting range :	45 to 5,000
Remark	This parameter will reset to the default if the Control Gain Set is changed.		
	Too high an integral gain will cause noise. Adjust the value within the range of no noise to achieve your desired responsiveness.		
Tuning Tip	Adjust the integral gain after setting the control level (or adjust Control Gain 1 and 2 each) and FF compensation.		
	<u>Noise Solutions</u> ① Use Torque command filter: Notch filter (such as No.160.1) ② Decrease the value of Integral Gain. If noise occurs, decrease the setting of this parameter or apply a torque command notch filter.		

Page 39 Torque Command Notch Filter

Overshooting Case



Undershooting Case



Differences in Position Deviation Convergence

3. Tuning Parameters


3. Position Command Filter

Optimizing the settling time and deviation Suppressing vibration and noise





Check the following before using Position command filter


- The command from the host controller is correct.
- The equipment is installed firmly and properly.
- The gain parameters such as inertia ratio are correctly set.
- The command smoothing filters 2 (and 1) are set.
- Vibration is now unlikely to occur thanks to the decreased integral gain.

Filter	Overview	Refer to
 Smoothing	Position Command Smoothing Filter Effective in smoothing the position command and suppressing vibration at the time of positioning.	P. 35


Apply the following notch filters if the machine end point is still vibrating after sufficient tuning was performed and the smoothing filter was set.

Filter	Overview	Refer to
 Notch	Position Command Notch filter Effective in suppressing vibration of mechanical systems where the vibration does not appear in the torque output waveform. When compared to the command smoothing filter, the position command filter is more effective in reducing the absolute position deviation (Status No.80).	P. 34 P. 36
 γ-Notch	Position Command γ-Notch Filter Effective in suppressing vibration of mechanical systems where the vibration does not appear in the torque output waveform. This filter has flexibility of changing the gain setting in the range higher than notch frequencies. This item will reduce the position deviation impacted by use of notch filter.	P. 34 P. 37

Up to four levels of Position command filter are available.



Block Diagram of Position Command Filter (Details)



3. Tuning Parameters




Position Command Smoothing Filters 1 and 2



Function	The smoothing filters smooth the position command and suppress vibrations.		
Parameter	Position command filter 1: Type Select	No.66.0	Default: 0 Setting range: 0 to 3
	Position command filter 4: Switch Select	No.66.1	Default: 1 Setting range: 0, 1
	Position command filter 1: Smoothing 1 -Moving average counter	No.80.0	Default: 40 Setting range: 1 to 6,250
	Position command filter 4: Smoothing 2 -Moving average counter	No.81.0	Default: 16 Setting range: 1 to 1,250
Remark	Before setting any of the parameters, wait for at least 3 secs after the motor stops and then set it while the command pulse is not being input. Changing the parameter setting during pulse input or with presence of pulse residue could cause shift in position. The larger setting will result in longer command time delay.		
Tuning Tip	<p>① Measure the vibration period from the position deviation of setting and the vibration waveform of the torque command value.</p> <p>② Use the following formula to calculate the moving average:.</p> <p>③ Setting filter 4 may suppress resonance.</p> <p>④ If the damping effect is small, calculate the moving average frequency from the vibration period again and set it to Filter 1.Calculation formula:</p> <p>Moving Average Count Derived from Vibration Frequency</p> <p>$10,000 \times \text{vibration frequency[s]} = \text{parameter value}$</p> <p>In the example below, when the vibration frequency is 39 ms, the average count = $10,000 \times 0.039 = 390$; the delay time will be 39 ms.</p>		

C- 2 Parameters






Position Command Notch Filter



Function	Apply this filter if the machine end point is still vibrating after sufficient tuning was performed and the smoothing filter was applied. Has vibration suppression effect on mechanical systems where the vibrations don't appear in the torque output waveform. When compared to the command smoothing filter, the position command filter is more effective in reducing the absolute position deviation (Status No.80).				
Parameter	Notch Filter		Filter 1	Filter 2	Filter 3
	Frequency	Default: 10 [0.1 Hz] Setting range: 10 to 2,000	No.74.0	No.83.0	No.357.0
	Width	Default: 512 Setting range: 128 to 2,048	No.75.0	No.84.0	No.358.0
	Depth	Default: 0 Setting range: 0 to 100	No.79.0	No.86.0	No.360.0
Remark	Increasing the notch width will make the position deviation large. Too large a notch width or setting the second level notch filter will result in better vibration suppression; however, the position deviation will be larger. Set this filter within the acceptable range of position deviation.				
Tuning Tip	Check the following before applying the filter <ul style="list-style-type: none"> • The command from the host controller is reasonable • The equipment is installed firmly and properly. • The gain parameters such as inertia ratio are properly set. • The command smoothing filters 2 (and 1) are set. • The integral gain has been decreased and vibrations are unlikely to occur. Start the equipment operation and apply the vibration frequency (measured at the equipment end) to the notch frequency. If the vibration cannot be suppressed, increase the notch width (by 800 as a rough standard). To reduce the position deviation during operation, increase the notch depth of a smaller vibration frequency.				


C-2 Parameters





3. Tuning Parameters


Position Command γ -Notch Filter

Function	<p>Use this filter, if the machine end point is still vibrating even after applying a notch filter in addition to sufficient tuning and a smoothing filter.</p> <p>This filter has vibration suppression effect on mechanical systems where the vibrations don't appear in the torque output waveform. It has flexibility of changing the gain setting in a range higher than notch frequency.</p> <p>Use this filter when it's expected that using a notch filter will reduce the position deviation.</p>
Remark	<p>Increasing the high frequency gain too much may result in noise.</p> <p>Decreasing the high frequency gain too much will tend to cause position deviation error.</p> <p>Set this filter within the acceptable range.</p>
Tuning Tip	<p>Check the following before applying the filter</p> <ul style="list-style-type: none"> • The command from the host controller is reasonable • The equipment is installed firmly and properly. • The gain parameters such as inertia ratio are properly set. • The command smoothing filter 2 and 1 are set. • The integral gain has been decreased and vibrations are unlikely to occur. <p>Start the equipment operation and apply the vibration frequency (measured at the equipment end) to the notch frequency. To reduce the position deviation, gradually increase the high frequency gain setting.</p> <p>To reduce the position deviation during operation, increase the depth selection parameter with of a smaller vibration frequency.</p> <p style="text-align: right;"> C-2 Parameters</p>





Filter	Overview	Refer to
 Notch	Torque Command Filter: Notch Filter This filter is effective in removing vibration elements from torque command and suppressing noise and vibration.	P. 39
 Low-pass	Torque Command Low-Pass Filter This filter is effective in smoothing the position command and <u>suppressing vibration at the time of positioning.</u>	P. 40



Block Diagram of Torque Command Filter with Details




Torque Command Filter: Notch Filter



Function	This filter is effective in suppressing noise and vibrations by removing vibration factors from the torque command.		
Parameter	Notch filter	Filter	Filter 2
	Switch	Default: 0 Settings: 0, 1	No.160.1 No.160.3
	Frequency	Default: 2,500 Hz Setting range: 0 to 2,500	No.168.0 No.171.0
	Width	Default: 8 Setting range: 1 to 16	No.169.0 No.172.0
	Depth	Default: 0 Setting range: 0 to 256	No.170.0 No.173.0
Remark	Set this item only after the machinery is installed properly. Unless the equipment is installed correctly, the filter performance will be suboptimal.		
Tuning Tip	<p>Set Notch filter switch (No.160.1) =1(enable) and set the value of Notch filter frequency (No.168.0) to be a vibration frequency. Calculate the vibration frequency using the waveform of, for example, the torque command when vibration is occurring.</p> <p>In the case of multiple vibration frequencies, set the second level notch filter.</p> <p>Alternatively, use this filter together with the low-pass filter (No.160.0, No.160.2, No.162.0) or increase Notch filter - Width (No.169.0). If applying the notch filter cannot stop resonant vibrations due to considerable machinery rattles, increase Notch filter- Depth (No.170.0) to 50,100,150 and so on, so that the actual notch depth will be shallower.</p>		

C- 2 Parameters




3. Tuning Parameters



Torque Command Low-Pass Filter



Function	Setting relatively a large value may suppress vibrations.																						
Parameter	Low-Pass Filter																						
	Switch	Default:	1	No.160.0																			
		Settings:	0, 1																				
	Auto setting	Default:	0	No.160.2																			
		Settings:	0, 1																				
	Time constant	Default:	0 [0.01 ms/rad](less than 100 W) 10 [0.01 ms/rad](over 200 W)	No.162.0																			
Setting range:		0 to 65,535																					
Remark	Setting a larger value means getting closer to the control range of the response model: another type of vibration will occur.																						
Tuning Tip	Set Torque command filter: Notch filter switch (No.160.1) =1 (enable). A rough estimate of possible max value for the filter can be obtained as follows.																						
	$\frac{(0.1 \text{ to } 0.2)}{\max((\omega_1 + \omega_2), \omega_q)} \text{ [s] or below}$																						
	<table><tr><td></td><td colspan="2">Position Control Mode</td><td colspan="2">Velocity Control Mode</td></tr><tr><td>ω_1</td><td>Control Gain 1</td><td>No.115.0</td><td>Control Gain 1</td><td>No.131.0</td></tr><tr><td>ω_2</td><td>Control Gain 2</td><td>No.116.0</td><td>—</td><td>—</td></tr><tr><td>ω_q</td><td>Integral Gain</td><td>No.119.0</td><td>Integral Gain</td><td>No.133.0</td></tr></table>					Position Control Mode		Velocity Control Mode		ω_1	Control Gain 1	No.115.0	Control Gain 1	No.131.0	ω_2	Control Gain 2	No.116.0	—	—	ω_q	Integral Gain	No.119.0	Integral Gain
	Position Control Mode		Velocity Control Mode																				
ω_1	Control Gain 1	No.115.0	Control Gain 1	No.131.0																			
ω_2	Control Gain 2	No.116.0	—	—																			
ω_q	Integral Gain	No.119.0	Integral Gain	No.133.0																			

 C- 2 Parameters

C- 2 Parameters


3. Tuning

4. Using S-TUNE II to Measure Vibration Frequency (FFT)


3
Tuning

4. Using S-TUNE II to Measure Vibration Frequency (FFT)

- 1 Load the waveforms measured or waveform data saved to display.
(The example shown on the right is saved waveform data.)
- 2 Select a parameter of which the vibration frequency is to be investigated.
Mark the check box to display the waveform.




- 3 Select **Position Command Filter** or **Torque Command Filter**
- 4 Select a range to investigate vibration frequency.
If the position command filter or torque command filter is selected, the second cursor location of the chart will be determined based on the 1st cursor location such that the display range will contain 2^n sample points.
- 5 Click **Frequency display**.
The x-axis unit will be changed from time [ms] to frequency [Hz]. The display unit of the graph in the range between the 1st and 2nd cursors will be converted to frequency.




When the x-axis unit on the graph is switched to frequency, the cursor colors will change. The table will show the frequency in red on column A and blue on column B.

- 6 Read the peak value by using the cursor.
- 7 Click on **Position Command Filter Adjustment** or **Torque Command Filter Adjustment**.
This will take you to the filter setup window under the tuning tab where a filter can be set.




4. Using S-TUNE II to Measure Vibration Frequency (FFT)

- 8 Click on the icon for the filter that you want to set. Up to four levels of the position command filters are and three levels of torque command filters are available.
- 9 Set the filter parameters. For the notch filter, enter the vibration frequency measured.
- 10 Click on **Waveform monitor** to return to the waveform monitor.



The filter that you just set will be shown on the list.

- 11 Unchecking the check box will switch ON/OFF of the filter. Switch on to verify the filter effect. Switching off will not lose the filter parameter.



Tip for Notch Filter Setup

When you are setting a notch filter, use the initial value for the notch width and check the effect first. After setting the notch filter, start the equipment, verify the filter effect, and lower the notch frequency gradually. Measure the waveforms to find the best filter conditions such as frequency, width, and depth. The notch frequency varies depending on the equipment

S-FLAG II Instruction Manual
- Standard model-
- EtherCAT communication model -

A large, white, stylized letter 'D' is centered on a dark gray background. The 'D' is composed of a thick vertical bar and a curved top and bottom. Behind the 'D' is a faint, light gray rectangular shape that also has a curved top and bottom, creating a layered effect.

SOFTWARE

1. About S-TUNE II

2. Operations

AMO-NP-35475-11












SF2-P/E-D

DEC. 2019

About S-TUNE II

1. Cautions for Proper Use	2
2. System Requirements for S-TUNE II	3
3. Installing S-TUNE II	4

1. Cautions for Proper Use

 DANGER		
Sign	Precautionary Measures	If Not Observed
Connections and Operations		
	Do not make drastic changes to parameters during tuning. If this precaution is not followed, the motor motion will become unstable.	 
	Before making parameter changes, carefully review the S-FLAG II Instruction Manual and technical data.	  
	Before operating the motor for test run or homing, ensure the safety of its surrounding area.	 
	Please study this manual first and use the product properly and safety.	

- Nidec Sankyo shall not be liable for any injuries or damages caused by any parameters or programs set by non-Sankyo personnel, or by malfunctions or failures of S-TUNE II .
- S-TUNE II , the Instruction Manual, and any documentations related to S-TUNE II , including the trademarks, logos and copyrights in them, are all attributed to Nidec Sankyo Corporation, regardless of whether they are registered or not.
- The law prohibits copying S-TUNE II or the Instruction Manual, in whole or in part, to a hard drive, CD-R, DVD or other media, or distributing them to the network without our permission.
- Nidec Sankyo prohibits unauthorized reproduction or resale, such as lending, leasing, selling or distributing to the network, of this product.
- Nidec Sankyo strictly prohibits reverse engineering, decompiling, disassembling or any similar act on our product by users.

1. About S-TUNE II

2. System Requirements for S-TUNE II

Product Overview

S-TUNE II is a dedicated setup software to be installed on a user-supplied Computer connecting to a S-FLAG II servo amplifier with a USB cable. It enables you to perform the following operations easily.

Features:

- setting, saving, and writing amplifier parameters
- measuring, saving, and comparing data, by using a graphical waveform monitor
- monitoring the state of amplifier, alarm, and input/output
- gain tuning and setting filters
- point-table operation, test operation and homing

System Requirements for S-TUNE II

Computer	OS	Windows® 7 (32-bit, 64-bit) Windows® 10 (64-bit)	Windows® 8 (64-bit)
	Language	Japanese, Chinese (Simplified), Chinese (Traditional), Korean, and English	
	CPU	1 GHz or higher (32-bit or 64-bit)	
	RAM	1 GB or more (32-bit) 2 GB or more (64-bit)	
	Hard Disk	Free space of 512 MB or more	
	Serial Communications	USB port	
	Monitor	1024 × 768 Pixel or more Resolution 24-bit color (True Color) or higher	
Cable	USB A - USB mini B	For certain noise environment, a signal noise filter cable is recommended.	

Microsoft., Windows is registered trademark of Microsoft Corporation in the United States and other countries.

Other company's names, product's names and so on are each company's registered marks.


When S-TUNE II is used with other programs at the same time, S-TUNE II operation may become unstable.

Use S-TUNE II alone.

Connecting Amplifier and Computer


Install S-TUNE II on your Computer.

Connect a USB cable to **C3** at the front of the amplifier.



3. Installing S-TUNE II

Installing

Step	Operation				
Step 1	Turn on your computer to start Windows. <ul style="list-style-type: none"> • Close any applications if they are opened. • If your amplifier is connected to the computer, disconnect it before turning on the computer. 				
Step 2	Unzip the S-TUNE2 installer zip file on your desktop. <ul style="list-style-type: none"> • S-TUNE II cannot be installed on network drives. • The computer must have .NET Framework installed. If not, Microsoft .NET Framework 4.0 installer will start when you try to install S-TUNE II. <table border="1"> <tr> <td>For the first time installation :</td><td> S-TUNE2-FULL_Ver- “Version No.” .zip Included ".NET Framework" </td></tr> <tr> <td>For upgrading :</td><td> S-TUNE2_Ver- “Version No.” .zip Does not included ".NET Framework" </td></tr> </table>	For the first time installation :	S-TUNE2-FULL_Ver- “Version No.” .zip Included ".NET Framework"	For upgrading :	S-TUNE2_Ver- “Version No.” .zip Does not included ".NET Framework"
For the first time installation :	S-TUNE2-FULL_Ver- “Version No.” .zip Included ".NET Framework"				
For upgrading :	S-TUNE2_Ver- “Version No.” .zip Does not included ".NET Framework"				
Step 3	Double-click on setup.exe in the unzipped folder. Do not turn off the computer until installation finishes. Do not start other programs during installation.				
Step 4	When installation finishes, a desktop shortcut icon will be created. 				
Step 5	S-TUNE II will be installed in the following folder. C:\Program Files \NIDEC-SANKYO CORP\S-TUNE2 C:\Program Files (x86)\NIDEC-SANKYO CORP\S-TUNE2 (in 64-bit version)				

What to Do If Installation Is Cancelled

To communicate with the amplifier, S-TUNE II uses Windows system files (see below).
 S-TUNE II installer automatically cancels installation if it cannot find those system files in your computer.
 If the installation is cancelled, be sure that the system files reside in the exact locations shown below.

C:\WINDOWS\system32\drivers\usbser.sys
 C:\WINDOWS\inf\mdmcpq.inf

Uninstalling S-TUNE II

Go to Control Panel → Programs.
 Click on Uninstall a program. Select S-TUNE2 and click Uninstall.



Operations

1. Overview.....	2
2. Using Tabs in S-TUNE II.....	6
1. Communications Setup.....	8
2. Parameters.....	9
3. Waveform Monitor.....	12
4. Waveform Comparison.....	22
5. Status Monitor.....	24
6. Alarm.....	25
7. Tuning.....	26
8. Point Table.....	30
9. Test Run.....	32
10. Auxiliary Functions.....	34





2. Operations

1. Overview

Start S-TUNE II

Step	Operation
Step 1	Turn on the control power to the amplifier and plug in the USB cable to C3 firmly.
Step 2	Double-click on the desktop icon of S-TUNE II . 
Step 3	S-TUNE II starts and the window under the communications setup tab opens. 

Close S-TUNE II

Step	Operation
Step 1	Click on Disconnect on the Quick Access Tool bar at the top or click on Disconnect in the Communication Settings view. 
Step 2	In the S-TUNE II view menu, select File -> End (X). (Or click  on the S-TUNE II title bar.)  

2. Operations

1. Overview

Using Keyboard

The following table explains key notations used in this document.

Key/Symbol	Explanation
[↑] [↓] [←] [→]	Up, Down, Left, and Right Arrow keys. Use these to toggle menu items. Selected items will be highlighted.
Numbers (0 to 9)	Number keys. Use them to type in a number.
[ESC]	Escape key (ESC or Esc). Press to redo an entry.
[ENTER]	Enter key (ENTER, Enter, RETURN, or Return). Use this key to execute the item you selected under a menu, or to finish entering a number.

Selecting Menu Items

Using the mouse, move the cursor to the menu item or the button you want, and left click to execute. Alternatively, you can use arrow keys to navigate to the menu you want and press Enter key to an item.

Entering Numbers

Type in using number keys.







Numeric data such as parameter values are decimal. Enter a number in a decimal format. Binary and hexadecimal numbers are not acceptable.

To cancel a number that you are typing, press the ESC key.

1. Overview

Common Buttons

The following are the common buttons you can use under S-TUNE II tabs.

Button	Function
	Read information from the amplifier RAM
	Write the parameters to the amplifier RAM
	Write the parameters to the amplifier EEPROM
	Read a file* saved in your Computer and display on the screen *For example, a parameter file or point table file
	Save the current settings to your Computer Use this button, for example, when you want to copy the same information to another amplifier.
	Jump to the Waveform monitor tab


Files Used in S-TUNE II





S-TUNE II allows you to save the following data files in your Computer.
Use these files to analyze motor motions or copy the same settings to another amplifier.

File	Default File Name	Extension	Tab to use
Parameters	parameter_YYMMDD_hhmmss	.xml	• Parameters
Waveforms	waveformYYMMDD_hhmmss	.csv	• Waveform Monitor • Waveform Comparison
Status variable log	statevalueog_YYMMDD_hhmmss	.csv	• Status Monitor
Point table parameters	pointtable_YYMMDD_hhmmss	.xml	• Point Table
I/O pinouts	IoSetting_YYMMDD_hhmmss	.xml	• Auxiliary Functions

Do not edit any saved files or change their extension. If you do, S-TUNE II will not be able to read the file.
The default file names include time stamps (YYMMDD_hhmmss).

Parameter Data Flow



Tracer Arrow	Execution Timing	Operation
(A)	Turning on the control power	Read the parameters from the amplifier EEPROM to its RAM.
(B)	Completing communications connection between S-TUNE II and the amplifier	Obtain the parameter data from the amplifier RAM to the computer and display on the screen.
(C)	Entering parameter values	Enter parameter values in the input fields on the screen and prepare to set them to the amplifier.
(D)	Clicking 	Set the parameters to the amplifier RAM.
(E)	Clicking 	Write the parameters to the amplifier EEPROM.
(F)	Clicking 	Save the parameter settings to the file.
(G)	Clicking 	Read the parameters from the file and display on the screen.

2. Using Tabs in S-TUNE II

This section describes functions of the tabs in S-TUNE II. For details, refer to the pages listed below.

Communication Settings


Parameter

 Page 8


- Connecting or disconnecting communications with the amplifier
- Obtaining the model information and the serial number from the amplifier and displaying on the screen

Parameter


Waveform monitor

 Page 9


- Setting all parameters included in the parameter list and checking them
- Saving parameter values in a file, or reading them from the file

Waveform monitor

Waveform Comparison

 Page 12


- Displaying waveforms of status variables
- Checking positioning time and vibration status, tuning parameters, and optimizing
- Saving waveform data in a file or reading it from the file
- Setting filters

Waveform Comparison


Status monitor

 Page 22


- Displaying waveforms of status data obtained under the [Waveform monitor] tab, and comparing them on two windows

Status monitor

Alarm


 Page 24


- Monitoring status data of the amplifier
- Saving the status data in a file

2. Operations


2. Using Tabs in S-TUNE II

Alarm Tuning

 Page 26



- Displaying alarm status of the amplifier
- Checking cause and remedy of the alarm
- Checking how to reset the alarm signal of the amplifier
- Checking the information on the amplifier life expectancy
- Checking the alarm history

Tuning Point Table

 Page 27


- Automatically adjusting the tuning parameters
- Setting filters

Point Table Test run

 Page 31



- Setting motions by Positioner function
- Saving the point table data in a file, or reading it from the file

Test run Auxiliary functions

 Page 33


- Without connecting to the host controller, performing simulation of motor's repetitive motions for tuning


Test run Auxiliary functions

 Page 35


- Clearing multi-turn data after checking alarm status
- Setting or changing I/O settings for each control mode or command mode

2. Using Tabs in S-TUNE II

1. Communications Setup




No.	Button/Function	Explanation
1	Get	Click to obtain information about the amplifier.
2	Connect	Click to open the serial port to interface with the amplifier. When the connection is complete, 4 turns blue and 5 changes to Online .
3	Disconnect	Click to close the serial port and disconnect communications from the amplifier. When the communications are closed, 4 turns blue and 5 changes to Offline .
4	Connection confirmation 1	The checkbox (in the Select column) of the selected port is ticked. When the serial port becomes open, the color of checkbox cell changes from blue to green.
5	Connection confirmation 2	This box can be seen under any tabs and lets you check the connection status anytime. Offline : Not connected Online : Connected

2. Operations


2. Using Tabs in S-TUNE II

2. Parameters



No.	Button/Function	Explanation
1	List of Parameter Groups	In this list, related parameters are grouped together according to their usages. Select a group to display the parameters of the group in 2.
2	Parameter Table	Parameters are displayed in ascending order of the parameter numbers. Select the parameter number and double-click the value to edit. An asterisk appears on the rightmost cell when you make a value change or read a file. Click Set ; the asterisk disappears. If the Restart the servo amplifier column shows "necessary", you need cycle power for changes that you made to parameter settings to take effect. Click Write and cycle the control power of the amplifier.
3	Parameter Description	This box displays explanation for the parameter selected in 2.
4	Servo amplifier	Get : Pull the values of selected parameters from the amplifier RAM. Set : Write new parameter settings to the amplifier RAM. Write : Write the new parameter settings to the amplifier EEPROM.
5	File	Read : Read the data you created before and display. Save : Save the parameter values you edited to a file. Use this to copy the same settings to another amplifier.
6	Compare	Compare : Jump to the parameter comparison screen. Comparing the parameter value in the RAM of the amplifier with the parameter value editing on the S-TUNE II. Execute compare : Compare the edited parameters with the data saved in EEPROM or a file. Edit : Return to the parameter table 2.
7	Clear	Delete the parameter data in EEPROM. Use this for factory reset or when replacing the motor. Parameter settings of the motor model that you connect next will be automatically set. We recommend data backup before you start operations.
8	File Name	Name of the parameter data file that S-TUNE II read. <input type="text" value="parameter_YYMMDD.xml"/>

Comparing Parameter Values



No.	Button/Function	Explanation										
1	What data to compare	Select which data you want to compare with the data in RAM. Select EEPROM or File.										
2	Execute compare	At first, click on the <div>Set</div> button. (The parameter(s) is/are written in at the RAM of the amplifier.) <div>Execute compare</div> Executes Compare and shows the result in the data display area. If two sets of data are completely matching, the table will be blank.										
3	File Name	Name of the parameter data file you selected for comparison. <div>parameter_YYMMDD.xml</div>										
4	Parameter settings comparison table	<table><tr><td>No.</td><td>: Parameter number</td></tr><tr><td>Name</td><td>: Parameter name</td></tr><tr><td>Servo amplifier value</td><td>: Parameter value residing in the amplifier RAM.</td></tr><tr><td>Compare value</td><td>: Value to compare with (in EEPROM or the file that you selected)</td></tr><tr><td>Difference</td><td>: The difference between the value in RAM and the value compared.</td></tr></table>	No.	: Parameter number	Name	: Parameter name	Servo amplifier value	: Parameter value residing in the amplifier RAM.	Compare value	: Value to compare with (in EEPROM or the file that you selected)	Difference	: The difference between the value in RAM and the value compared.
No.	: Parameter number											
Name	: Parameter name											
Servo amplifier value	: Parameter value residing in the amplifier RAM.											
Compare value	: Value to compare with (in EEPROM or the file that you selected)											
Difference	: The difference between the value in RAM and the value compared.											
5	Edit	Jump to the parameter edit window.										

2. Operations

2. Using Tabs in S-TUNE II

2
Operations

2. Using Tabs in S-TUNE II





Replacing with a Different Type of Motor



Use a right pair of motor and amplifier.
If a wrong pair has been set accidentally, clear the parameter data in the amplifier EEPROM first, then use a right pair.



Procedure for Parameter Clear

Step	Description
Step 1	Connect the amplifier and the computer. Turn on the control power. (You don't need to turn on the primary circuit power.)
Step 2	Click on Clear under the Parameter tab.
Step 3	<div>   </div> <p>Click OK : to clear parameter data, Click Cancel : to cancel. If Parameter Clear failed, repeat this procedure from the beginning.</p>
	<p>After clearing the parameter data in EEPROM, be sure to do the control power cycling according the following procedures.</p> 

Automatically Identifying Motor Model and Output Rating

Step	Description
Step 1	Clear the parameters.
Step 2	Disconnect the primary circuit power supply and the control power supply.
Step 3	Replace the motor and connect the encoder cable.
Step 4	Reapply the control power to the amplifier. The default parameter values for the new motor will be automatically set to EEPROM.
Step 5	Verify that the alarm statuses are all normal.



DANGER



Do not use an inappropriate value for any parameter.


Or the motor will become uncontrolled. Secure safety for the work area before gain tuning.







Secure safety in surrounding areas and take safety measures such as emergency stop.



To optimize gain tuning, observe not only waveforms, but also noise and vibrations, jerky or smooth movements in the motor and the equipment.



2. Using Tabs in S-TUNE II

No.	Button/Function	Explanation
1	Chart Display Area	<p>You can use the mouse in this area.</p> <ul style="list-style-type: none"> • Drag to zoom a rectangle area that you select. • Right-click to capture the waveform. • Wheel button <p>Use the Scroll wheel to change the max value to be included in the chart while the waveform is selected.</p> <p>This can be done in the x-axis or y-axis zoom %, or y-axis range cell where the cursor is blinking. Scrolling without specifying the area moves the left green cursor on the chart.</p>
2	Cursor icons	<p>Move the cursor icons horizontally to display the time values in 7 .</p> <p>Cursor 1 (green) for T1, Cursor 2 (blue) for T2.</p>
3		Click to fit the waveform chart to the chart display area such that the max value.
		<p>This icon adjusts the selected waveform display range such that the average of the max and min y-values of the data is centered in the chart display window. When y-value fluctuations are relatively small, the waveform you want to see might appear only at the upper side or lower side of the display window. Selective Fit can fix this problem.</p> <p>To select a variable for which you want to change the waveform display range, click on the variable label (i.e. a status name) in the chart area.</p> <p>The status variable selected will be shown with a black border (e.g., Speed command [r/min]).</p>
		<p>Click Return to see the previous display view of the waveform. You can go back up to the fifth one.</p> <p>Click  to clear the history of display changes.</p>
4	X-axis scale	Enter a zoom percentage for x-axis.
	Y-axis scale	Enter a zoom percentage for y-axis.
	Y-axis range	Specify the display range for y-axis.
5	Scroll bars	<p>Use the horizontal bar to change the x-axis display range.</p> <p>Use the vertical bar to change the y-axis display range.</p>


2. Using Tabs in S-TUNE II

No.	Button/Function	Explanation
6	State Item	Select up to four state items (i.e. status variables), from the pull-down menu, that you want to display in waveform. Those four items you selected will be saved in a file. In the case of 4-byte status data, only the lower 2-byte is displayed.
	I/O Item	The I/O items are also displayed in waveform. Four I/O items selected here will be saved to a file.
7	Time	Time measured at the location of the cursor positions. T1 : time at the green cursor T2 : time at the blue cursor ΔT : difference between T1 and T2
8	Parameters Window	Displays parameters that can be set in the Waveform monitor tab and display-only parameters. The rows highlighted in green are parameters grouped together in the control gain set. Parameters with grayed out Value cells are display-only.
9	Servo amplifier Click <input type="button" value="Get"/>	: to read the parameters from the amplifier.
	Click <input type="button" value="Set"/>	: to set the parameters to the amplifier RAM.
	Click <input type="button" value="Write"/>	: to save the parameter to the amplifier EEPROM.

2. Using Tabs in S-TUNE II

Waveform Record

Set the waveform measurement conditions here.
Save the obtained waveforms and tuning parameters to a file.

Button/Function	Explanation											
Sampling cycle	Default : 2.00 [ms] Set in increments of: 0.05 [ms] Sampling cycle = (Range of motor moving time) ÷ (Sampling Points)											
Sampling Points	Enter the number of sampling points per measurement. Initial value: 1,000 points, Range: 1 to 4,096 points											
Trigger method	<div>Select the trigger method to obtain waveform data. At first, select rising edge to measure the series of motions from start to finish.</div> <table><tr><th>Setting</th><th>Preferred when</th><th>Recording starts when</th><th>Recording ends when</th></tr><tr><td>Rising above the threshold (i.e. Rising edge)</td><td><ul style="list-style-type: none">Checking statuses immediately after a motion starts.Trying to get a general idea on the whole movement.</td><td>The value of Valid trigger source has exceeded the Trigger Level setting.</td><td rowspan="2">The number of points sampled has exceeded the Sampling points setting.</td></tr><tr><td>Force trigger</td><td><ul style="list-style-type: none">Actual motion is too slow for the rising edge trigger to get to work.Checking a specific part of consecutive operations.</td><td><div>Capture waveform</div> has been clicked.</td></tr></table> <div>Note: "Falling edge" option is not available.</div>	Setting	Preferred when	Recording starts when	Recording ends when	Rising above the threshold (i.e. Rising edge)	<ul style="list-style-type: none">Checking statuses immediately after a motion starts.Trying to get a general idea on the whole movement.	The value of Valid trigger source has exceeded the Trigger Level setting.	The number of points sampled has exceeded the Sampling points setting.	Force trigger	<ul style="list-style-type: none">Actual motion is too slow for the rising edge trigger to get to work.Checking a specific part of consecutive operations.	<div>Capture waveform</div> has been clicked.
Setting	Preferred when	Recording starts when	Recording ends when									
Rising above the threshold (i.e. Rising edge)	<ul style="list-style-type: none">Checking statuses immediately after a motion starts.Trying to get a general idea on the whole movement.	The value of Valid trigger source has exceeded the Trigger Level setting.	The number of points sampled has exceeded the Sampling points setting.									
Force trigger	<ul style="list-style-type: none">Actual motion is too slow for the rising edge trigger to get to work.Checking a specific part of consecutive operations.	<div>Capture waveform</div> has been clicked.										
Valid trigger source	Select a state variable that will work as the trigger to start recording waveform data (state variables).											
Trigger level	Set the threshold value to start recording waveform data. When the selected variable exceeds the threshold, recording will start. Range: 0 to 32,767											
Trigger position	<div>Set the trigger position. You can select up to eight positions starting from the left. 0 : Left end of the chart, 1/8 : Leftmost solid line, 7/8 : Rightmost solid line</div> 											
Sampling method	Single acquisition: to obtain data only once for the specified number of sampling points. Successive acquisition: "Single acquisition" is repeated and waveform chart continues to update until <div>Stop sampling</div> is clicked.											
<div>Capture waveform</div>	Start obtaining waveform data.											
<div>Stop sampling</div>	Stop obtaining waveform data.											
<div>Save waveform(s)</div>	Save the obtained waveform data and the tuning parameter settings in a CSV file.											
<div>Tuning</div>	Jump to the Quick Tuning tab under the Tuning tab.											

2. Using Tabs in S-TUNE II

Waveform Comparison

Use this tab to display and compare waveforms of the data read from the waveform file and waveforms of sampled data.

Button/Function	Explanation
State Item (i.e. Status variables)	Select items that you want to display in waveforms. Eight waveforms including those from the sampled items ⑥ can be displayed. Y-axis units are displayed for four items from the top selected in ⑥.
I/O Item	I/O data from another waveform file. Displays up to four when Parallel I/O Status is selected as status item.
Parameters	Parameter values of waveform that have been read from waveform file.
Time	T1 and T2 are time figures indicated by the cursor positions. (*)
Compare waveforms	Read the saved data.
waveformYYMMDD_hhmmss.csv	Name of the file that has been read from the computer.

Cursor

Enables numeric comparison of the waveforms displayed in the chart area. Up to eight waveforms can be displayed - your measured waveforms at the top and waveforms-read by the waveform comparison tab from the file- on the bottom.
Value 1 at Cursor 1 (green), Value 2 at Cursor 2 (blue)

Button/Function	Explanation
State items (i.e. Status variables) I/O items	Y values (at the cursors) of the items you selected are displayed.

2. Using Tabs in S-TUNE II

Position Command Filter

Torque Command Filter


Use these tabs to check fluctuating position deviation values and torque command values in waveform chart and select the filters that you want to set. (*)


Button/Function	Explanation
Frequency display	<p>This item changes the chart units from time [ms] to frequency [Hz]. When the display mode is changed to frequency, the cursor colors change to red and blue. Column A and Column B show frequencies at the red and blue cursors respectively.</p> <p>In frequency charts, Cursor 2 position is determined to be at 2ⁿ sampling point starting from the Cursor 1 position.</p> <p>Read the peak value; use Position Command Filter Adjustment or Torque Command Filter Adjustment to jump to the Tuning tab to set filters. You can set to four levels of filters.</p> <p>After setting filters, you can check the settings under Position Command Filter tab and the Torque Command Filter tab.</p>
Time View	<p>Click to switch the chart units from frequency [Hz] to time [ms].</p> <p>In the time unit mode, the cursor colors are green and light blue, and Columns A and B are blank.</p>
Position Command Filter Adjustment	Click to jump to Position Command Filter Adjustment under the Tuning tab.
Torque Command Filter Adjustment	Click to jump to Torque Command Filter Adjustment under the Tuning tab.
Get	Read filter parameters from the amplifier.
Set	Write the filter parameters to the amplifier RAM.
<input checked="" type="checkbox"/> (Checkbox)	<p>You can enable or disable the filter that you set by checking or unchecking the checkbox. Unchecking the checkbox does not erase the filter setting.</p>

*) Under these tabs, the second cursor in the time unit mode is positioned at the 2ⁿ sampling point starting from the first cursor position. Conversion to frequency is applied to the range between the 1st and 2nd cursors

2. Using Tabs in S-TUNE II

Procedure 1 Waveform Display



Step	Description
Step 1	Select status items that you want to obtain waveforms for.
Step 2	Set measurement conditions.
Step 3	<p>Click on Capture waveform</p>  <ul style="list-style-type: none"> • The popup dialog "Waiting for trigger" does not change to "Recording" until the enabled trigger source reaches the trigger specified level. In case that the dialog "Waiting for trigger" remains unchanged, select the "Force trigger" method instead or decrease the trigger level. • If you click Abort in the middle of the process, the data will have been captured up to the point of abort.
Step 4	Adjust the parameters. 👉 C-3 Tuning
Step 5	Click Set to write the parameters to the amplifier RAM.
Step 6	Click Capture waveform to see the waveforms.
Step 7	Continue adjusting the parameters until you obtain desired waveforms.
Step 8	Click Write to write the parameters to EEPROM of the amplifier.


2. Operations

2. Using Tabs in S-TUNE II

2
Operations

2. Using Tabs in S-TUNE II

Procedure 2 Saving waveform data




Step	Description
Step 1	Click on Save waveform(s) under the Waveform Record tab.
Step 2	A dialog box will prompt you to select a waveform file name.
Step 3	Select the name of a waveform file you want to save the waveform data to and click Save .

Use the saved file when you want to use the same measurement conditions next time.

File content	Data of waveforms displayed and parameters
Default directory to save waveform files	C:\Users*****\Documents\NIDEC-SANKYO\S-TUNE2\Waves
Default file name	waveformYYMMDD_hhmmss.csv

Procedure 3 Reading waveform data



Step	Description
Step 1	Click Compare waveforms under the Waveform Comparison tab.
Step 2	A dialog box will prompt you to select a waveform file.
Step 3	Select a file and click Open . (The file name that you selected appears in the box below the Compare waveform button. For example, <code>waveformYYMMDD_hhmmss.csv</code>)

NOTE

- The color of the waveform matches the color shown on the display check mark, not the one used when you saved the data.
- The data read from the file is displayed in the Value1 column.
- Under the Waveform monitor tab, waveforms of most recent data and data read from the file are both displayed in one chart.
The **Waveform Comparison** tab lets you compare waveform charts of two data sources side by side vertically.

2. Using Tabs in S-TUNE II

Procedure 4 Reading Waveform File

S-TUNE2 WAVEFORM DATA		amplifier version	S-TUNE2 version				
Data Format Version		2	X.XXX				
--- Condition ---							
1	Date	Sampling Period[msec]					
	YYYY/MM/DD	hh:mm:ss					
--- Gain Parameters ---							
	Name	Item	Main No.	Sub No.	Unit	Value	
	MP_RPP1_GRATE	Inertia ratio	102		0 [%]	250	
	MP_RPP1_DRATE	Damping ratio	103		0 [%]	100	
	PCL_RPP1_CONTROL_LEVEL_ALL	Control gain set	113		0 [-]	15	
	PCL_RPP1_CONTROL_LEVEL_ALL	Inertia condition	113		0 [-]	2	
	PCL_RPP1_W1	Control gain 1	115		0 [rad/s]	50	
	PCL_RPP1_W2	Control gain 2	116		0 [rad/s]	200	
	PCL_RPP1_FF1	Gain FF compensation 1	117		0 [0.01%]	10000	
	PCL_RPP1_WQ	Integral gain	119		0 [rad/s]	160	
	PVCC_POS_FILTER_FIR_DIM_1	Position command smoothing filter 1 Moving average order	80		0 [-]	25	
	PVCC_POS_FILTER_FIR_DIM_2	smoothig 2 moving average order	81		0 [-]	10	
--- Waveform Data ---							
Channel No.			CH0	CH1	CH2	CH3	
Unit			[pulse]	[pulse]	[0.1%]	[r/min]	
State Value Name		Sampling Number	EIO_ENC_MA	PCL_POS_ERROR	TCC_TORQUE_COMMAND	VCCL_SPEED_FEEDBACK	
State Value Item		Sampling Number	Encoder mechanical angle (1 rotation)	Position deviation	Torque command	Speed feedback	
		0	297	0	0	0	75
		1	693	0	0	0	84
		2	1128	0	0	0	90
		3	1596	0	0	0	97
		4	2083	0	0	0	100
--- I/O Bit Assign ---							
Bit Name List		SVON	RESET/PCLR	PCSTART1	PCSEL1	PCSEL2	PCSEL3
I/O State Value		4097	6937	7452	5406		0
Select Bit Name		SVON	RESET/PCLR	PCSTART1	PCSEL1		3081
--- Parameters ---							
	Name	Item	Main No.	Sub No.	Unit	Value	
	SC_CONTROL_MODE	Control mode		2	0 [-]	0	
	SC_COMMAND_MODE	Command mode		3	0 [-]	3	
	PSCL_PRESCALER	Pulse train command - Paired ratio (Numerator)		34	0 [-]	1000	
	PSCL_PRESCALER_DIV	Pulse train command - Paired ratio (Denominator)		36	0 [-]	1000	
	PVCC_POS_IR_NOTCH_1_FREQ	Position command filter 1 - Notch Frequency		74	0 [0.1Hz]	10	
	PVCC_POS_IR_NOTCH_1_WIDTH	Position command filter 1 - Width		75	0 [-]	512	
	PVCC_POS_IR_NOTCH_1_HF_GAIN	Position command filter 1 - High frequency gain constant		76	0 [-]	100	
	PVCC_SPEED_FILTER_FIR_DIM_1	Moving average time for Speed command smoothing filter		78	0 [ms]	100	
	PVCC_POS_IR_NOTCH_1_DEPTH	Position command filter 1 - Depth		79	0 [-]	0	

--- Condition ---

1	Date	Data timestamp for saving a file
2	Sampling Period [msec]	Sampling cycle

--- Gain Parameters ---

3	Item	Tuning parameter names
4	Unit	Tuning parameter units
5	Value	Tuning parameter values

--- Waveform Data---

6	Unit	Measurement units of status items
7	State Value Item	Amplifier status variable names
8	Status data	Time series data of status variables

---I/O Bit Assign---

9	I/O data	
---	----------	--


---I/O Bit Assign---

10	Information of related parameters	
----	-----------------------------------	--

MEMO






2. Using Tabs in S-TUNE II


4. Waveform Comparison



2. Using Tabs in S-TUNE II

Displaying Waveforms

No.	Button/Function	Explanation
1	Scroll bars	Use the horizontal bar to scroll sideways. Use the vertical bar to scroll up and down.
2	Cursor	Move the cursor horizontally to display the x coordinate in 10 (Time [ms]).
3		Click to read the data created earlier.
4		The name of the file that the data was read from.
5		Click to fit the waveform chart to the chart display area such that the max value of the selected waveform will be the max y-coordinate..
6		Click to go back to the previous waveform display (i.e. undo Fit.). You can go back up to the fifth one. Click  to reset the history.
7	x-axis zoom %	Enter a zoom percentage for x-axis.
	y-axis zoom %	Enter a zoom percentage for y-axis.
	y-axis range	Specify the display range of y-axis.
8	Chart Display Area	You can use the mouse in the Chart area. Drag to specify a rectangle area to zoom in. Right-click to copy the waveform. Use the scroll wheel in any input cell of x-axis zoom %, y-axis zoom %, or y-axis range where the cursor is blinking, to change the max value of the selected item to be included in the chart. Click on the cursor button 2 and then use the scroll wheel to move the green cursor.
9	State Item	Click the checkbox of the item that you want to see its waveform for. You can select up to four items.
10	Time	The measured value at the x-axis cursor position.
11	Parameter	Displays the parameter values at the time when waveform data was obtained.




No.	Button/Function	Explanation
1	State variable	Select up to ten status variables that you want to monitor. The data is displayed at the same time. Display example: [0000 0000 0000 0000(2)] where (2) indicates binary.
2	Status Logging	Lets you obtain status log.
3	Sampling cycle	Range: 500 to 100,000 [ms] Set in increments of: 500 [ms]
4	<div>Stop recording</div> <div>Start recording</div>	Click <div>Start recording</div> after setting the sampling cycle. Click <div>Stop recording</div> to stop logging. The data will be saved to a csv file. Default file name: statevalueelog_YYMMDD_hhmmss.csv
5	Monitor Operation	Clicking the [Status monitor] tab starts monitoring. Use <div>Stop monitoring</div> or <div>Restart</div> to stop or resume monitoring.
6	I/O status	When an input or output signal turns on, its signal name cell turns green.

2. Operations

2. Using Tabs in S-TUNE II

6. Alarm




No.	Button/Function	Explanation
1	Alarm Clear	Click to clear amplifier alarms. Clearing alarms 1. Remove the cause of the alarm(s). 2. Under the Parameters tab, set Operation Mode (No.9.0) to 1 (communication). 3. Click Alarm Clear .
2	Current alarm	Displays a list of current alarms.
3	Alarm history	Displays up to ten most recent alarms.
4	Cause for alarm and what to do	Shows possible causes of the alarm selected in 2 and troubleshooting.
5	Life expectancy information	Shows guidelines for regular maintenance and product life. Cumulative Run Time: This item indicates the total amplifier runtime (in [hh:mm:ss.ss]) since the control power was supplied to it for the first time. Cumulative counts of control power ON: This item indicates how many times the control power was turned on to the amplifier since the first time

Z-1 Troubleshooting

7. Tuning

Quick tuning


Position control mode only



No.	Procedure/Button	Explanation
1	Operating Procedure	This is a guidance of the "Quick Tuning".
2	Conditions	Set a load related parameter of the motor.
	Step 1	Set the appropriate inertia condition : Choose a inertia condition to machine system connecting to your motor.
	Step 2	Setting of the load related parameters : <input checked="" type="checkbox"/> Quick Tuning If you check "Quick Tuning", the inertia ratio value is estimated automatically, and then the value is set to the amplifier RAM one by one. Uncheck the check box if you need the inertia ratio estimation only. Click Start : to start a Quick Tuning Click Stop : to stop a Quick Tuning Inertia ratio upper bound If you try to enter the inertia ratio by manually, enter a value in the "Set value" cell. Set : Write the new parameter settings to the amplifier RAM.
	Step 3	Get : Pull the values of the parameters from the amplifier RAM Write : Write the new parameter settings to the amplifier EEPROM.
	Waveform Monitor	Jump to the Wave Monitor window.
3	Tuning status indicator	This indicator shows a tuning condition.

Auto tuning


Velocity Control Mode only











No.	Button/Function	Explanation									
1	Step of Auto Tuning Procedure	Auto Tuning Operation									
2	Conditions	Adjust load characteristic parameters. Setting rigidity (Control Gain Set): Start with the lowest value 5, then gradually increase the value. <table><tr><td></td><td>Range</td><td>Increment by</td></tr><tr><td><input type="checkbox"/> Detail setting</td><td>5 to 30</td><td>5</td></tr><tr><td><input checked="" type="checkbox"/> Detail setting</td><td>1 to 46</td><td>1</td></tr></table> Inertia ratio upper bound If you try to enter the inertia ratio by manually, enter a value in the "Set value" cell. <div>Set</div> : Write the new parameter settings to the amplifier RAM.		Range	Increment by	<input type="checkbox"/> Detail setting	5 to 30	5	<input checked="" type="checkbox"/> Detail setting	1 to 46	1
		Range	Increment by								
	<input type="checkbox"/> Detail setting	5 to 30	5								
	<input checked="" type="checkbox"/> Detail setting	1 to 46	1								
Step 2	Estimating the inertia ratio automatically: Click <div>Start</div> : to start Auto-tuning Click <div>Stop</div> : to end Auto-tuning <input checked="" type="checkbox"/> : Automatic parameter update The parameter value will be estimated and set to the amplifier RAM. Manually enter the inertia ratio: Enter a value in the "Set Value" column. <div>Set</div> : to set data to the amplifier RAM.										
Step 3	Click <div>Get</div> : to read data from the amplifier RAM. Click <div>Write</div> : to write data to the amplifier EEPROM.										
<div>Waveform Monitor</div>	Click this button to jump to the Waveform tab.										
3	Status display	Tuning status is displayed here.									


2. Using Tabs in S-TUNE II









Adjusting Position command filter




No.	Button/Function	Explanation
	Position Command Filter 1-4	For each filter, select whether use it or not. If selected, a pop-up box opens. Enter the specific value you want. The selected icon turns blue.
	Filter Off	Select this if you are not setting up any filters. Click the icon to toggle between disable  (no filter) and enable  (use filter).
	Smoothing Filter	Set the moving average count. Click on the icon to toggle between enable  and disable  .
4	Notch Filter	Set frequency [0.1 Hz], width, and depth. Click on the icon to toggle between enable  and disable  .
	γ -Notch filter	Set frequency [0.1 Hz], gain, and depth. Click on the icon to toggle between enable  and disable  .
5	Waveform monitor	Click to jump to the Waveform Monitor tab.

Adjusting Torque Command Filter



No.	Button/Function	Explanation
6	Torque Command Filter 1-3	For each filter, select whether use it or not. If selected, a dialog box opens. Enter the specific value you want. The selected icon turns blue.
	Filter Off	Select this if you are not setting up any filters. Click the icon to toggle between disable  (no filter) or enable  (use filter).
	Low Pass Filter 	Set the time constant [0.01ms]. Click on the icon to toggle between enable  and disable  .
	Notch Filter 	Set frequency [Hz], width, and depth. Click on the icon to toggle between enable  and disable  .
7	Waveform monitor	Click this button to jump to the Waveform Monitor tab.

 C- 3 Tuning




2. Operations

2. Using Tabs in S-TUNE II

2
Operations

2. Using Tabs in S-TUNE II

No.	Button/Function	Explanation
1	Point Table	Enter point table data for up to 16-point numbers.
2	Instructions	Writes the current position to the cell in the [Position] column of the selected Point No.
3	Comparison All	Click to compare the following two versions for all point numbers. a) data currently being edited in the table b) data from the EEPROM or File that you select. Wherever two versions are not identical, the cell in the table will turn red. Click Complete to return to the main window.
4	Comparison Individual	Click to compare the two versions (a and b above) for the selected point numbers. Click Edit to return to the main window.
5	Point Table Operation	Operate test-run according to the point table. Point table No. <input type="text"/> : Enter the point number you want to start with. <input checked="" type="checkbox"/> : Start <input type="checkbox"/> : Pause <input type="checkbox"/> : Stop
6	Servo Amplifier	Click Get to read data from the amplifier RAM. Click Set to write data to the amplifier RAM. Click Write to write data to the amplifier EEPROM.
7	File name	Name of the file read by <input type="text" value="pointtable_YYMMDD_hhmmss.xml"/> .
8	File	Click Read to open the point table parameter file created earlier. Click Save to save the point table parameters to a file.
9	Inching	Fine tuning with specified parameter values. You can set three motion patterns (No.1 to 3). Range Travel distance (amount of movement): 0 to 1,073,741,823 [E-pulse] Rotational speed: 0 to maximum rotational speed of motor [r/min] Acceleration/deceleration time: 0 to 5,000 [ms] Counterclockwise rotation (CCW) Clockwise rotation (CW) : One clicking per one pattern motion 
10	Return to home position	Start : The lamp to the left will turn green when homing is complete; the box below Current Position will show the post-homing position. Click Stop to stop homing

Procedure

Step

Description

Step 1

Set the following under the **Parameter** tab.

Parameter Name	No.	Setting	Description	Standard	EtherCAT
Control Mode	2.0	0 :	Position Control Mode	Yes	Yes
Command Mode	3.0	3 :	Internal Command	Yes	Yes
Internal Position-Operation Mode	642.0	0 :	Point Table	Yes	—

Step 2

Create a point table; set and write it to the amplifier.

F-1 Operations

Step 3

Work with the point table operation buttons (5).

Additional ; Inching (**9**) and Homing (**10**) can be done under the **Point Table** tab.


9. Test Run

**DANGER**

Testing operation involves actual motor motion and could be dangerous. Secure safety in surrounding areas and take safety measures such as emergency stop.



Test run is a motion control feature of S-TUNE II that you can use without the host controller. Use this feature to check motor motions or perform tuning.



No.	Button/Function	Explanation
1	Operation conditions Travel distance :	Range: 0 to 1,073,741,823 [E-pulse]
	Motor rotation speed :	Range: 1 to Maximum rotational speed [r/min]
	Acceleration time :	Time for the rotational speed to change from 0 to 1,000 rpm. Range: 0 to 5,000 [ms]
	Deceleration time :	Time for the rotational speed to change from 1,000 to 0 rpm. Range: 0 to 5,000 [ms]
	Motion pattern :	Click <input type="button" value="CCW rotation"/> for a CCW motion only. Click <input type="button" value="CCW rotation -> CW rotation"/> for a CCW motion and then a CW motion. Click <input type="button" value="CW rotation -> CCW rotation"/> for a CW motion and then a CCW motion. Click <input type="button" value="CW rotation"/> for a CW motion only.
	Dwell time :	Wait time between rotations. The wait time setting may not work when other applications are running on your computer.
	Repeat count :	Set how many times the specified motion pattern should be repeated. Range: 1 to 1,000 times

2. Using Tabs in S-TUNE II

No.	Button/Function	Explanation
2	<input checked="" type="checkbox"/> Aging function	Check the checkbox to disable the repeat count setting so that the motor will keep running. Click to pause, and to stop.
3	Test run operation	: Start : Pause : Stop
4	Repeat count	Displays how many times the specified motion was repeated.
5	Inching	<p>Fine tuning with specified parameter values. You can set three motion patterns (No.1 to 3).</p> <div> </div> <p>Range Travel amount: 0 to 1,073,741,823 [E-pulse] Rotational speed: 0 to Maximum rotational speed [r/min] Acceleration/deceleration time: 0 to 5,000 [ms]</p> <p>Counterclockwise rotation (CCW) Clockwise rotation (CW) : one clicking per one pattern motion</p>
6	Return to home position	When Homing finishes, the indicator to the left of button will turn green and Current position cell will show the current position resulting from homing. Click to stop homing

Procedure

Step	Operation																				
Step 1	Set the following under the Parameter tab.																				
	<table><tr><th>Parameter Name</th><th>No.</th><th>Setting</th><th>Standard</th><th>EtherCAT</th></tr><tr><td>Control Mode</td><td>2.0</td><td>0 : Position Control Mode</td><td>Yes</td><td>Yes</td></tr><tr><td>Command Mode</td><td>3.0</td><td>3 : Internal Command</td><td>Yes</td><td>Yes</td></tr><tr><td>Internal Position -Operation Mode</td><td>642.0</td><td>1 : Communication motion</td><td>Yes</td><td>—</td></tr></table>	Parameter Name	No.	Setting	Standard	EtherCAT	Control Mode	2.0	0 : Position Control Mode	Yes	Yes	Command Mode	3.0	3 : Internal Command	Yes	Yes	Internal Position -Operation Mode	642.0	1 : Communication motion	Yes	—
	Parameter Name	No.	Setting	Standard	EtherCAT																
	Control Mode	2.0	0 : Position Control Mode	Yes	Yes																
	Command Mode	3.0	3 : Internal Command	Yes	Yes																
Internal Position -Operation Mode	642.0	1 : Communication motion	Yes	—																	
Step 2	Set the Operating conditions in the Test run area.																				
Step 3	Click on the Start button below Test run operation.																				

- Additional
- Inching (5) and Homing (6) can be performed as well.
 - Under the following operating conditions, an alarm will occur and test run will stop when the number of repetitions exceeds the Repeat count setting.
 The **Motion pattern** setting is or and the aging function checkbox (☒) is check-marked.
 If you want non-stop test runs, set the following in addition to the above parameters.
 Internal Position: Overflow detection (No.643.0) = 0 (disable)
 - If the communication with the amplifier becomes disconnected, the test run will stop.
 To resume, reconnect to the amplifier and restart the test run.



DANGER



To prevent fire and injuries in case of earthquake, ensure secure installation.
 After earthquake, be sure to confirm safety before resuming operation.



10. Auxiliary Functions


Encoder tab



CAUTION



Use the Encoder tab only in a Servo OFF state.



No.	Button/Function	Explanation
1	Get encoder state	Click this to obtain encoder status and display in the 2.
2	Encoder conditions	This area displays encoder status. If there is any abnormality (i.e. the Value column shows "abnormal"), fix the problem and clear the alarm.
3	Clear encoder	This clears encoder alarms and multi-turn data all at once. Click this button only after clicking on one of the box <input checked="" type="checkbox"/> in 2 or 4.
4	Angle data	This area displays current encoder angle data. Click on <u>Clear encoder</u> to clear encoder multi-turn data.

2. Operations


2. Using Tabs in S-TUNE II




2
Operations

2. Using Tabs in S-TUNE II

I/O Setting tab

Select from the **Preset** pull down menu.



No.	Button/Function	Explanation
5	Preset	Check the box under Control/Command Mode . Select from the Preset pull down menu.
6	Pinout - Input signals	Verify I/O input settings. When the presetting is changed, a changed signal name will be green indication.
7	Pinout - Output signals	Verify I/O output settings. When the presetting is changed, a changed signal name will be green indication.
8		Click to write the parameters to the amplifier EEPROM
9	File	 : Click to read and display the saved I/O pinout data.  : Click to save I/O pinout data in the XML format.

 **B-2** Mounting and Wiring

Note) Only Standard model servo amplifier can change I/O pin assignment.

MEMO



OPERATION

1. Operation
2. Connection
with Master Controller
3. Timing Diagrams

Operation

1. Overview.	2
1. Control mode setting.	3
2. Drive profile (CiA402)	5
3. PDS (Power Drive System).	7
2. Cyclic synchronous position mode (CSP)	9
3. Cyclic synchronous velocity mode (CSV)	12
4. Cyclic synchronous torque mode (CST)	15
5. Homing Mode (HM)	18

Operation modes supported by the this product

The product supports the CiA 402 drive profile. The available operation modes are as follows. The operation mode is set with the 6060 h (Modes of operation) object. Some bits of the Control word and Status word differ for each mode of operation. See the description of each operation mode for the different bits for each operation mode.

Operation modes	6060h value
Cyclic synchronous position mode (CSP)	8
Cyclic synchronous velocity mode (CSV)	9
Cyclic synchronous torque mode (CST)	10
Homing Mode (HM)	6

1. Operation

1. Overview

1. Control mode setting

6502h Supported drive modes

6052 h indicates the control mode supported by this product.

6502h	Supported drive modes		
Sub-index:	00h	-	
Access:	RW	Data Type:	U32
Unit:	-		
Default:	-	Range:	0 to 4,294,967,295
Description:	Indicates the supported control modes.		
	bit	Control mode	Abbreviation
	0	Profile Position control mode	pp
	1	Velocity control mode	vl
	2	Profile Velocity control mode	pv
	3	Profile Torque control mode	tq
	4	Rsv.	-
	5	Homing mode	hm
	6	Interpolated Position mode	ip
	7	Cyclic synchronous position mode	csp
	8	Cyclic synchronous velocity mode	csv
	9	Cyclic synchronous torque mode	cst
	10-31	Rsv.	-
*) The supported modes depend on the software version.			

6060h Modes of operation

6060 h sets the servo amplifier control mode.

6060h	Modes of operation		
Sub-index:	00h	–	
Access:	RW	Data Type:	I8
Unit:	–		
Default:	–	Range:	– 128 to 127
Description:	Sets the control mode of the servo amplifier.		
	value	Mode of operation	Abbreviation
	–128 to –1	Rsv.	–
	0	Mode not changed/Mode not set	–
	1	Profile position control mode	pp
	2	Velocity control mode	vl
	3	Profile Velocity control mode	pv
	4	Profile Torque control mode	tq
	5	Rsv.	–
	6	Homing mode	hm
	7	Interpolated Position mode	ip
	8	Cyclic synchronous position mode	csp
	9	Cyclic synchronous velocity mode	csv
	10	Cyclic synchronous torque mode	cst
	11-127	Rsv.	–
*) The supported modes depend on the software version.			

6061h Modes of operation display

6061 h indicates the servo amplifier control mode.

6061h	Modes of operation display		
Sub-index:	00h	–	
Access:	RO	Data Type:	I8
Unit:	–		
Default:	–	Range:	– 128 to 127
Description:	Indicates the current control mode of the servo amplifier.		
	value	Mode of operation	Abbreviation
	–128 to –1	Rsv.	–
	0	Mode not changed/Mode not set	–
	1	Profile position control mode	pp
	2	Velocity control mode	vl
	3	Profile Velocity control mode	pv
	4	Profile Torque control mode	tq
	5	Rsv.	–
	6	Homing mode	hm
	7	Interpolated Position mode	ip
	8	Cyclic synchronous position mode	csp
	9	Cyclic synchronous velocity mode	csv
	10	Cyclic synchronous torque mode	cst
	11-127	Rsv.	–
*) The supported modes depend on the software version.			

1. Operation

1. Overview


2. Drive profile (CiA402)

6040h Controlword

6040 h is a command to control slave devices such as PDS state transition.

6040h	Controlword				
Sub-index:	00h	–			
Access:	RW	Data Type:	U16	Unit:	–
Default:	–			Range:	0 to 65,535
Description:	Sets control commands to the servo amplifier such as PDS state transition.				
	bit	Descriptions			
	0	Switch on			
	1	Enable voltage			
	2	Quick stop			
	3	Enable operation			
	4				
	5	Operation mode specific			
	6				
	7	Fault reset			
	8	halt			
	9	Operation mode specific			
	10				
	11				
	12	Rsv.			
	13				
	14				
	15				

Command coding

Command	Bits of the controlword					PDS Transitions
	bit 7 Fault reset	bit 3 Enable operation	bit 2 Quick stop	bit 1 Enable voltage	bit 0 Switch on	
Shutdown	0	X	1	1	0	2, 6, 8
Switch on	0	0	1	1	1	3
Switch on + Enable operation	0	1	1	1	1	3+4 (*1)
Disable voltage	0	X	X	0	X	7, 9, 10, 12
Quick stop	0	X	0 (*2)	1	X	7, 10, 11
Disable operation	0	0	1	1	1	5
Enable operation	0	1	1	1	1	4, 16
Fault reset		X	X	X	X	15

*1) Execute "Enable operation" command after "Switch on" command.

*2) "Quick stop" command is enabled with a value of "0". This is the opposite of other bit logic.

6041h Statusword

6041 h indicates the status of the slave device.

6041h	Statusword			
Sub-index:	00h	–		
Access:	RW	Data Type:	U16	Unit: –
Default:	–	Range:	0 to 65,535	
Description:	Indicates the status of the servo amplifier.			
	bit	Descriptions		
	0	Ready to Switch on		
	1	Switch on		
	2	Operation enable		
	3	Fault		
	4	Voltage enable		
	5	Quick stop		
	6	Switch on disabled		
	7	Warning		
	8	Rsv.		
	9	Remote		
	10	Operation mode specific		
	11	Internal limit active		
	12			
	13	Operation mode specific		
14				
15				

The PDS state is indicated by Bit 6,5,3-0.

Statusword	PDS state	
xxxx xxxx x0xx 0000 (b)	Not ready to switch on	Initialization not complete
xxxx xxxx x1xx 0000 (b)	Switch on disabled	Initialization complete
xxxx xxxx x01x 0001 (b)	Ready to switch on	Main circuit power OFF
xxxx xxxx x01x 0011 (b)	Switched on	Servo Off/Servo Ready
xxxx xxxx x01x 0111 (b)	Operation enabled	Servo On
xxxx xxxx x00x 0111 (b)	Quick stop active	Quick stop
xxxx xxxx x0xx 1111 (b)	Fault reaction active	Error determination
xxxx xxxx x0xx 1000 (b)	Fault	Error state

bit 4 (Voltage enable):

1: The main circuit power supply voltage is applied to the PDS.

bit 5 (Quick stop):


0: PDS receives "Quick stop" command.

"Quick stop" command is enabled with a value of "0". This is the opposite of other bit logic.

bit 7 (Warning):

1: A warning has occurred. The PDS state does not change when a warning occurs.

(The motor continues to operate.)



n is the PDS Transition number. (n: 0-16)

The FSA State

State	Descriptions
Not Ready to Switch on	Control power is supplied to the slave device and control power is established. The slave device is initializing or performing a self-test.
Switch on Disabled	The slave device is initialized and ready to set parameters. The main circuit power supply should not be turned on.
Ready to Switch on	The main circuit power supply is permitted to be turned on. The parameter is configurable, but the function is disabled.
Switched on	The main circuit power is supplied and ready to accept "Operation Enabled". The slave device can set parameters. This amplifier can perform a state transition even when the main power supply is OFF.
Operation Enabled	The drive function is enabled and the motor is energized. No alarms. The slave device can set parameters.
Quick Stop Active	"Quick stop" is executing. The drive function is enabled and the motor is energized.
Fault Reaction Active	An alarm has occurred on the slave device then "Quick stop" is executing. The motor is energized.
Fault	An alarm has been occurred on the slave device then "Fault reaction" is completed. The drive function is disabled. The main circuit power supply is turned on or off by an application.

1. Operation

2. Cyclic synchronous position mode (CSP)



In Cyclic synchronous position mode, the command position is generated by the master controller. The slave device operates by receiving the command position every interpolation period.

To use cyclic synchronization position mode, set the 6060 h (Modes of operation) object to "8".

Objects Used in Cyclic Synchronous Position Mode

Index	Sub-Index	Name	Units	Type	Access	PdoMapping
603Fh	00h	Error code	–	U16	RO	TxPDO
6040h	00h	Controlword	–	U16	RW	RxPDO
6041h	00h	Statusword	–	U16	RO	TxPDO
6062h	00h	Position demand value	pulse	I32	RO	TxPDO
6064h	00h	Position actual value	pulse	I32	RO	TxPDO
6065h	00h	Following error window	pulse	U32	RW	No
6072h	00h	Max torque	0.1%	U16	RW	RxPDO
6077h	00h	Torque actual value	0.1%	I16	RO	TxPDO
607Ah	00h	Target position	pulse	I32	RW	RxPDO
6080h	00h	Max motor speed	r/min	U32	RW	RxPDO
60B0h	00h	Position offset	pulse	I32	RW	RxPDO
60B1h	00h	Velocity offset	pluse/s	I32	RW	RxPDO
60B2h	00h	Torque offset	0.1%	I16	RW	RxPDO
60F4h	00h	Following error actual value	pulse	I32	RO	TxPDO
60FDh	00h	Digital inputs	–	U32	RO	TxPDO



6040h Controlword on Cyclic synchronous position mode

6040 h is a command to control slave devices such as PDS state transition.

6040h	Controlword			
Sub-index:	00h	-		
Access:	RW	Data Type:	U16	Unit: -
Default:	-	Range:		0 to 65,535
Description:	Sets control commands to the servo amplifier such as PDS state transition.			
	bit	Descriptions		
	0	Sensor on		
	1	Enable voltage		
	2	Quick stop		
	3	Enable operation		
	4			
	5	Rsv.		
	6			
	7	Fault reset		
	8	Halt		
	9			
	10			
	11			
	12	Rsv.		
	13			
14				
15				

bit 8 (Halt):

0: Permits the cyclic synchronous position function.

1: Motor stop by 605Dh (Halt option code)

1. Operation

2. Cyclic synchronous position mode (CSP)



6041h Statusword on Cyclic synchronous position mode

6041 h indicates the status of the slave device.

6041h	Statusword			
Sub-index:	00h	–		
Access:	RW	Data Type:	U16	Unit: –
Default:	–	Range:	0 to 65,535	
Description:	Indicates the status of the servo amplifier.			
	bit	Descriptions		
	0	Ready to switch on		
	1	Switch on		
	2	Operation enable		
	3	Fault		
	4	Voltage enable		
	5	Quick stop		
	6	Switch on disabled		
	7	Warning		
	8	Rsv.		
	9	Remote		
	10	Rsv.		
	11	Internal limit active		
	12	Drive follows command value		
	13	Following error		
14	Rsv.			
15				

bit 12 (Drive follows command value):

- 0: Not following the command position
- 1: Following the command position

bit 13 (Following error):

If the value of 60F4h (Following error actual value) has exceeded the setting range of 6065h(Following error window) for a certain period of time, the 6041h value becomes "1".

- 0: No excessive position deviation
- 1: Position deviation excess alarm

3. Cyclic synchronous velocity mode (CSV)



In Cyclic synchronous velocity mode, the command velocity is generated by the master controller. The slave device operates by receiving the command velocity every interpolation period.

To use cyclic synchronization position mode, set the 6060 h (Modes of operation) object to "9".

Objects Used in Cyclic Synchronous Velocity Mode

Index	Sub-Index	Name	Units	Type	Access	PdoMapping
603Fh	00h	Error code	–	U16	RO	TxPDO
6040h	00h	Controlword	–	U16	RW	RxPDO
6041h	00h	Statusword	–	U16	RO	TxPDO
6072h	00h	Max torque	0.1%	U16	RW	RxPDO
6080h	00h	Max motor speed	r/min	U32	RW	RxPDO
60B1h	00h	Velocity offset	pulse/s	I32	RW	RxPDO
60B2h	00h	Torque offset	0.1%	I16	RW	RxPDO
60FFh	00h	Target velocity	pulse/s	I32	RW	RxPDO

1. Operation

3. Cyclic synchronous velocity mode (CSV)



6040h Controlword on Cyclic synchronous velocity mode

6040 h is a command to control slave devices such as PDS state transition.

6040h	Controlword			
Sub-index:	00h	–		
Access:	RW	Data Type:	U16	Unit: –
Default:	–	Range:		0 to 65,535
Description:	Sets control commands to the servo amplifier such as PDS state transition.			
	bit	Descriptions		
	0	Sensor on		
	1	Enable voltage		
	2	Quick stop		
	3	Enable operation		
	4			
	5	Rsv.		
	6			
	7	Fault reset		
	8	Halt		
	9			
	10			
	11			
	12	Rsv.		
	13			
14				
15				

bit 8 (Halt):

0: Permits the cyclic synchronous velocity function.

1: Motor stop by 605Dh (Halt option code)

3. Cyclic synchronous velocity mode (CSV)



6041h Statusword on Cyclic synchronous velocity mode

6041 h indicates the status of the slave device.

6041h	Statusword			
Sub-index:	00h	–		
Access:	RW	Data Type:	U16	Unit: –
Default:	–			Range: 0 to 65,535
Description:	Indicates the status of the servo amplifier.			
	bit	Descriptions		
	0	Ready to switch on		
	1	Switch on		
	2	Operation enable		
	3	Fault		
	4	Voltage enable		
	5	Quick stop		
	6	Switch on disabled		
	7	Warning		
	8	Rsv.		
	9	Remote		
	10	Rsv.		
	11	Internal limit active		
	12	Drive follows command value		
	13	Rsv.		
14	Rsv.			
15	Rsv.			

bit 12 (Drive follows command value):

- 0: Not following the command velocity
- 1: Following the command velocity

1. Operation

4. Cyclic synchronous torque mode (CST)



In Cyclic synchronous velocity mode, the command torque is generated by the master controller. The slave device operates by receiving the command torque every interpolation period.

To use cyclic synchronization position mode, set the 6060 h (Modes of operation) object to "10".

Objects Used in Cyclic Synchronous Torque Mode

Index	Sub-Index	Name	Units	Type	Access	PdoMapping
603Fh	00h	Error code	–	U16	RO	TxPDO
6040h	00h	Controlword	–	U16	RW	RxPDO
6041h	00h	Statusword	–	U16	RO	TxPDO
6071h	00h	Target torque	0.1%	I16	RW	RxPDO
6072h	00h	Max torque	0.1%	U16	RW	RxPDO
6080h	00h	Max motor speed	r/min	U32	RW	RxPDO
60B2h	00h	Torque offset	0.1%	I16	RW	RxPDO

4. Cyclic synchronous torque mode (CST)



6040h Controlword on Cyclic synchronous torque mode

6040h is a command to control slave devices such as PDS state transition.

6040h		Controlword		
Sub-index:	00h	-		
Access:	RW	Data Type:	U16	Unit: -
Default:	-	Range:		0 to 65,535
Description:	Sets control commands to the servo amplifier such as PDS state transition.			
	bit	Descriptions		
	0	Sensor on		
	1	Enable voltage		
	2	Quick stop		
	3	Enable operation		
	4			
	5	Rsv.		
	6			
	7	Fault reset		
	8	Halt		
	9			
	10			
	11			
	12	Rsv.		
	13			
14				
15				

bit 8 (Halt):

0: Permits the cyclic synchronous torque function.

1: Motor stop by 605Dh (Halt option code)



6041h Statusword on Cyclic synchronous torque mode

6041 h indicates the status of the slave device.

6041h	Statusword			
Sub-index:	00h	–		
Access:	RW	Data Type:	U16	Unit: –
Default:	–	Range:		0 to 65,535
Description:	Indicates the status of the servo amplifier.			
	bit	Descriptions		
	0	Ready to switch on		
	1	Switch on		
	2	Operation enable		
	3	Fault		
	4	Voltage enable		
	5	Quick stop		
	6	Switch on disabled		
	7	Warning		
	8	Rsv.		
	9	Remote		
	10	Rsv.		
	11	Internal limit active		
	12	Drive follows command value		
	13	Rsv.		
14	Rsv.			
15	Rsv.			

bit 12 (Drive follows command value):

- 0: Not following the command torque
- 1: Following the command torque

5. Homing Mode (HM)



Homing mode is a position control mode in which homing is performed by setting the operating speed, acceleration and operating method.

For an incremental motor, always perform homing after turning on the power.

To set the homing mode, set the 6060 h (Modes of operation) object to "6".

Object used for Homing

Index	Sub-Index	Name	Units	Type	Access	PdoMapping
6040h	00h	Controlword	–	U16	RW	RxPDO
6041h	00h	Statusword	–	U16	RO	TxPDO
607Ch	00h	Home offset	pulse	I32	RW	RxPDO
6098h	00h	Homing method	–	I8	RW	RxPDO
6099h	–	Homing speeds	–	–	–	–
	00h	Highest sub-index supported	–	U8	RO	No
	01h	Speed during search for switch	pulse/s	U32	RW	RxPDO
	02h	Speed during search for zero	pulse/s	U32	RW	RxPDO
609Ah	00h	Homing acceleration	pulse/s ²	U32	RW	No



6040 h Controlword in Homing mode

6040 h is a command to control slave devices such as PDS state transition.

6040h	Controlword			
Sub-index:	00h	-		
Access:	RW	Data Type:	U16	Unit: -
Default:	-	Range:		0 to 65,535
Description:	Sets control commands to the servo amplifier such as PDS state transition.			
	bit	Descriptions		
	0	Switch on		
	1	Enable voltage		
	2	Quick stop		
	3	Enable operation		
	4	Homing operation start		
	5	Rsv.		
	6	Rsv.		
	7	Fault reset		
	8	Halt		
	9	Rsv.		
	10			
	11			
	12			
	13			
14				
15				

When the set value of bit 4 (homing operation start) of 6040 h (Controlword) is changed from 0 to 1, the parameter used in the homing mode is loaded at the rising edge and the operation starts.



6041 h Statusword in homing mode

6041 h indicates the status of the slave device.

6041h	Statusword			
Sub-index:	00h	–		
Access:	RW	Data Type:	U16	Unit: –
Default:	–	Range:	0 to 65,535	
Description:	Indicates the status of the servo amplifier.			
	bit	Descriptions		
	0	Ready to switch on		
	1	Switch on		
	2	Operation enable		
	3	Fault		
	4	Voltage enable		
	5	Quick stop		
	6	Switch on disabled		
	7	Warning		
	8	Rsv.		
	9	Remote		
	10	Target reached		
	11	Internal limit active		
	12	Homing attained		
	13	Homing error		
14	Rsv.			
15				

bit 10 (Target reached):

0: Executing

1: Stop

bit 12 (Homing attained):

0: Homing is not completed.

1: Homing is completed.

bit 13 (Homing error):

0: No Error

1: There is an error related to Homing.

Bit 10, 12, and 13 indicate the homing status.

Statusword	Status of Homing mode
xx00 x0xx xxxx xxxx (b)	"Homing" is in progress
xx00 x1xx xxxx xxxx (b)	"Homing" is interrupted or not started.
xx01 x0xx xxxx xxxx (b)	"Homing" is completed, but the motor has not reached the target position.
xx01 x1xx xxxx xxxx (b)	"Homing" is completed.
xx10 x0xx xxxx xxxx (b)	An error related to "homing" was detected, but operation is continuing.
xx10 x1xx xxxx xxxx (b)	An error related to "homing" was detected, then the motor has stopped.



List of Homing Methods

Method	Type of Homing mode	Support
1	Homing on negative limit sensor and index pulse	●
2	Homing on positive limit sensor and index pulse	●
3, 4	Homing on positive home sensor and index pulse	●
5, 6	Homing on negative home sensor and index pulse	●
7-16	–	×
17	Homing on negative limit sensor	●
18	Homing on positive limit sensor	●
19, 20	Homing on positive home sensor	●
21, 22	Homing on negative home sensor	●
23-32	–	×
33, 34	Homing on index pulse	●
35, 37	Homing on current position	●


As of January 2019.

Method 35 (Homing on current position) was discontinued in CiA402 Work Draft CANopen Drive and motion control device profile part2 Version : 3.0.1.13(26 April 2012). Use "Method 37" for new designs.

5. Homing Mode (HM)



Method 1	Homing on negative limit sensor (NOT) and index pulse
Method 2	Homing on positive limit sensor (POT) and index pulse



Method 1


- When the "**NOT** (backward direction limit sensor : pin No. 8 of I/O connector)" is OFF, the moving direction at the Homing start is to the left of this figure (The motor rotates CCW.).
- When the "NOT" input is turned ON, the motor moves to the right (The motor is CW.) at a low speed.
- Then, the position where the first index pulse is detected becomes the origin. ①

Method 2

- When the "**POT** (forward direction limit sensor : pin No. 7 of I/O connector)" is OFF, the moving direction at the Homing start is to the right of this figure (The motor rotates CW.).
- When the "POT" input is turned ON, the motor moves to the left (The motor is CCW.) at a low speed.
- Then, the position where the first index pulse is detected becomes the origin. ②



Method 3	Homing on positive home sensor and index pulse
Method 4	
Method 5	Homing on negative home sensor and index pulse
Method 6	




Method 3 Method 4 Method 5 Method 6

- The moving direction depends on the input state of "**HOME** (Origin sensor: pin No. 9 of I/O connector)" when "Homing" is started.
- When the Origin sensor is detected, the motor changes its moving direction and moves at low speed.
- After that, the position where the first Index pulse is found becomes Origin. (3)(4)(5)(6)

5. Homing Mode (HM)



Method 17	Homing on negative limit sensor (NOT)
Method 18	Homing on positive limit sensor (POT)



Method 17

- When the "**NOT** (backward direction limit sensor : pin No. 8 of I/O connector)" is OFF, the moving direction at the Homing start is to the left of this figure (The motor rotates CCW.).
- The position where the "**NOT**" input signal turns ON is the origin. (17)


Method 18

- When the "**POT** (forward direction limit sensor : pin No. 7 of I/O connector)" is OFF, the moving direction at the Homing start is to the right of this figure (The motor rotates CW.).
- The position where the "**POT**" input signal turns ON is the origin. (18)

• These methods are the same as not using Index Pulse in "Method 1" and "Method 2", respectively.



Method 19	Homing on positive home sensor
Method 20	
Method 21	Homing on negative home sensor
Method 22	




Method 19	Method 20	Method 21	Method 22
-----------	-----------	-----------	-----------

- The moving direction depends on the input state of "**HOME** (Origin sensor: pin No. 9 of I/O connector)" when "Homing" is started.
- The position where the first Index pulse is found becomes Origin. (19)(20)(21)(22)

- These methods are the same as not using Index Pulse in "Method 3-6", respectively.



Method 33	Homing on index Pulse
Method 34	




Method 33	Method 34
-----------	-----------

- The nearest index pulse position detected from "Homing" start position is the origin.
- The moving direction for Method 33 is to the left of the figure (The motor is CCW.). ③③
- The moving direction for Method 34 is to the right of the figure (The motor is CW.). ③④



Method 35	Homing on current position
Method 37	



*) Method 35 (Homing on current position) was discontinued in CiA402 Work Draft CANopen Drive and motion control device profile part2 Version : 3.0.1.13(26 April 2012). Use "Method 37" for new designs.

Method 35	Method 37
-----------	-----------

- The starting point of Homing is the origin. ③⑤③⑦
- At the timing when the "Homing" has started, the following objects are initialized:
 - 6062h** (Position demand value) = **6064h** (Position actual value) = **607Ch** (Home offset)
- These Methods can execute even if the PDS state is not "Operation enable".



Procedure for the Homing

STEP1 Object Settings

Set the parameters for the following objects:.

Object	Things to do
6098h	Select the Homing method (Choose from 1-6, 17-22, or 33-37)
607Ch	Set the Home offset value.
6060h	Change the operation mode to "6 (Homing)"
6099h 01h	Set the motor speed to detect the Origin sensor.
6099h 02h	Set motor speed to detect index pulse.
609Ah	Set the motor acceleration

**STEP2** Start "Homing"

Set bit 4 of 6040h (Controlword) to "1" after Servo ON.

Object	Things to do
6040h	Set 0010h

**STEP3** Searching the Origin

Execute Homing with the method set to 6098h.

**STEP4** Confirm

Check that bit 12 of 6041 h (Statusword) becomes "1".

**STEP5** Exit "Homing"

Object	Things to do
6040h	Make the bit 4 to "0" (Exit Homing).
6060h	Change the operating mode to suit your own application.

Connecting to the Master Controller

1. Preface	2
2. Use Beckhoff's "TwinCAT"	3
1. Connect to the master controller.....	3
2. Use "TwinCAT" to run the motor (test operation)	13
Test motion (Jog motion and single motion)	14
Test motion (Repetitive motion)	16
3. Homing on TwinCAT (hm mode)	18
4. Save Project file	24
5. Open Project file	25

Connecting to the Master Controller

This product can be driven by connecting it to a master controller made by another manufacturer. If you are using a master controller other than those listed below, please refer to the operation manual of the product.

List of the master controller

manufacturer	Name of the software
Beckhoff	TwinCAT® (TwinCAT XAE)


TwinCAT® is a software developed and licensed by Beckhoff Automation GmbH, Germany. for real-time control of industrial machinery.

2. Connecting to the Master Controller

2. Use Beckhoff's "TwinCAT"

1. Connect to the master controller

Open EtherCAT communication and prepare for operation



2



Connecting to the Master Controller

2. Use Beckhoff's "TwinCAT"



You may need to enter a Security Code when starting TwinCAT 3.

1. Make sure that the five characters displayed are correctly transcribed into the text box.
2. Click on **OK** button.




When an exact match is made, the text you type is green.

2. Use Beckhoff's "TwinCAT"

- 1 Save "ESI (*) files (.xml files)" to the appropriate folder on the master controller.

Folder path : "C:\TwinCAT\3.1\Config\Io\EtherCAT\"



The ESI file (.xml files) contains configuration information for the product.

The master controller must be restarted after the .xml file is downloaded to the master.




Be sure to use the ESI file for the device connected to the slave device.
Make sure the ESI file version matches the amplifier version.

2. Connecting to the Master Controller

2. Use Beckhoff's "TwinCAT"

2 Start the software "TwinCAT XAE".



The TwinCAT.XAE icon is in the task tray.



It is useful to create a shortcut on your desktop.

When the EtherCAT cable is connected correctly between the master and the slave (amplifier), the ECIN LED (green) of the amplifier lights up.

When multiple amplifiers are connected, the ECIN and ECOUT LEDs of the connected amplifiers light up.



Operation modes in TwinCAT3

The icon color distinguishes the mode currently selected by the icon color.



RUN

This mode allows real-time operation of PLC and C/C++ tasks. You can set TwinCAT to automatically enable RUN mode at startup.



CONFIG


This mode is used to configure network, I/O, motion, and program development and configuration. When Free Run is enabled, network communication occurs in non-real-time. You can also check the operation of the I/O terminal.



The red icon indicates "Mode is switching".

3 Create a new project.

Select "File" → "New" → "Project" from the menu to create a new project.



Switch TwinCAT operation mode to "CONFIG" mode after creating a project.



Saving the project file allows you to save the connection information with the amplifier, settings, and test operation conditions. Saved settings can be read when starting the software.




P. 24 4. Save project
P. 25 5. Open project

2. Connecting to the Master Controller

2. Use Beckhoff's "TwinCAT"

4 The master controller scans the EtherCAT network.

Select "I/O" → "Device" in the TwinCAT System Manager navigation tree, right-click and select "Scan".




Before execute "Scan" verify the following:

1. EtherCAT cable must be connected between master and slave.
2. Power must be turned on for the master and the slave.
3. The "Link" LED of the master and slave must be on.


The screen shows the slave devices that are connected.

Make sure the checkbox has "check mark".



When button is clicked, the dialog "Scan for Boxes" is displayed, so select button.


Select "NC" or "CNC" according to the slave device whose connection has been confirmed.





If the slave device is a servo driver, select .


2. Use Beckhoff's "TwinCAT"

After "Scan" completes, "MOTION" is added to the TwinCAT System Manager navigation tree and "Device" is added to "I/O".

" Drive (S-Flag2)" is added to the "Device" tree.



The Activate Free Run dialog will appear.
Click on  button.




TIP !



About Free Run

In Free Run mode, EtherCAT communication operation can be performed in CONFIG mode. In Free Run status, "RUN LED" of the slave lights up.




2. Connecting to the Master Controller


2. Use Beckhoff's "TwinCAT"

5 Set the system clock.

Set the "System clock (= Base Time)" to 125 μ s by double-clicking "Real-Time" from the "SYSTEM" in the TwinCAT System Manager navigation tree.



Double-click "NC-Task" in the "MOTION", and set Cycle ticks to "2".




2

Connecting to the Master Controller

2. Use Beckhoff's "TwinCAT"


6 Set the servo amplifier.

Double-click "Axis1" in "MOTION" → "NC-Task xxx" → "Axes", and set the Position Lag Monitoring setting in the Parameter tab to "FALSE" (*).



*) 【暫定】 この設定により、マスタによる「位置偏差過大」が誤検出されるのを防ぎます。

Double-click "Axis1" in "MOTION" → "NC-Task xxx" → "Axes" and select the Unit setting in the Setting tab.



画面は "Degree" を選択している例です。

TIP !



About the "Unit"

Degree: The angle of the motor's mechanical axis.

mm : The amount of mechanical movement such as the slider.

2. Connecting to the Master Controller


2. Use Beckhoff's "TwinCAT"

6 Set the servo amplifier.

Enter a value for the Scaling Factor Numerator in the Parameter tab,

(When "Degree" is selected in Unit)
 "Scaling Factor Numerator" value = 0.002746582 deg/INC

This is an example of a 17 bit encoder.
 $360 \text{ (deg)} / 131,072 \text{ (INC)} = 0.002746582$



Be sure to enter the value in all digits that can be entered accurately.
 If the number is rounded, the motor may not operate correctly.


On the Parameter tab, set "Reference Velocity" and "Maximum Velocity" to 36,000.0 respectively.

Examples

"Reference Velocity" value = 36,000.0 Degree/s
 "Maximum Velocity" value = 36,000.0 Degree/s

Set the maximum speed of the motor to be used.


This is an example of a motor with a maximum speed of 6,000 rpm.
 $6,000 \text{ rpm} \times 360 \text{ (deg)} / 60 \text{ (s)} = 36,000 \text{ Degree/s}$




This is an example of setting 18,000.0 (= 3000 rpm).

2. Use Beckhoff's "TwinCAT"

6 Set the servo amplifier.



When you have completed all the settings, click  Activate Configuration to accept the settings.




A confirmation dialog for switching to "RUN mode" is displayed.
Select to go on.


Finish

Operation preparations are complete.

You can switch the TwinCAT 3 operation mode using the  (RUN mode) or  (CONFIG mode) button on the toolbar.



The operational mode of TwinCAT3 is displayed in the bottom right corner of the task tray or TwinCAT3 window.



2. Connecting to the Master Controller

2. Use Beckhoff's "TwinCAT"

2. Use "TwinCAT" to run the motor (test operation)

Setting operating conditions for test operation

Set the maximum speed, acceleration time and deceleration time of the motor.


Double-click "Axis1" in "MOTION" → "NC-Task xxx" → "Axes" to display the Dynamics tab.

Examples

"Maximum Velocity (V max)" value = 18,000 Degree/s

"Acceleration Time" value = 0.2 s

"Deceleration Time" value = 0.2 s



This example sets the maximum speed to 3,000 rpm, the acceleration time to 0.2 s, and the deceleration time to 0.2 s.



In order to take the test operation safety,

- Set the maximum rotation speed to a small value.
- Set the acceleration/deceleration time to a larger value.

Adjust the value gradually after confirming safety.

TIP !



About Acceleration/Deceleration time

These settings specify the time from the current speed (Include the state of shutdown) to the target speed.

Setting a larger value makes gradual acceleration/deceleration.

Setting a lower value makes sudden acceleration/deceleration.


2. Use Beckhoff's "TwinCAT"

Test motion (Jog motion and single motion)

"Jog motion" moves the motor while the button is pressed.

"Single motion" moves the motor toward the set target position.

Double-click "Axis1" in "MOTION" → "NC-Task xxx" → "Axes" to display the Online tab.



1 Current Position

The current position is displayed in the unit set in "Unit" on the Setting tab.

2. Connecting to the Master Controller

2. Use Beckhoff's "TwinCAT"


2 Servo Status

Displays the Servo status. To control the Servo status, click on the **Set** button and go to the configuration screen.

Servo on

To turn Servo on, click on the **Set** button and check the checkbox in the dialog below. The "Override" value must be 100%.

Click on the **OK** button to accept the settings.



Controller : Check the box to turn it on "Servo On".

Feed Fw : Check the box to accept "Forward" command.

Feed Bw : Check the box to accept "reverse" command.

Servo off

To turn Servo off, click on the **Set** button and uncheck the checkbox in the dialog below.

Click on the **OK** button to accept the settings.

3 Motion Control

Move the motor with Jog motion or Single motion.


(You can also press the button on your keyboard that matches each button.)

Key	Works
	Jog motion The motor moves while the button is pressed. The motor moves at high speed in the reverse direction .
	Jog motion The motor moves at low speed in the reverse direction .
	Jog motion The motor moves at low speed in the forward direction .
	Jog motion The motor moves at high speed in the forward direction .
	Single motion The motor moves under the conditions set in "Target Position" and "Target Velocity".
	Single motion The motor stops single operation.
	Reset the motor operation.

Test motion (Repetitive motion)

The motor can be "repetitive motion" assuming actual equipment.


Double-click "Axis1" in "MOTION" "NC-Task xxx" "Axes" to display the Functions tab.



About "Servo state" control

Servo ON/OFF control function is not available in the "Function" tab.

To control the servo status, click the **Set** button in the "Enabling" frame of the "Online" tab.



Before starting repetitive motion, do enough Jog motion or single motion to make sure you can move safely.

Then, perform sufficient repetitive motion at low speed to ensure safe operation before incorporating the motor into actual equipment.

2. Connecting to the Master Controller

2. Use Beckhoff's "TwinCAT"


1 Current Position

The current position is displayed in the unit set in "Unit" on the Setting tab.

2 Motion Control

Items	Descriptions
Start Mode	Select the motion type. <ul style="list-style-type: none"> • Reversing Sequence • Absolute • Relative • Endless + (Continuous operation in one direction) ...and so on.
Target Postion1	Set the target position (Start Position).
Target Velocity	Set the operating velocity.
Target Position2	Set the target position (stop position).
Idle Time	Set the time to wait for the next motion.
Last Time	Displays the duration(*) of the last motion. *) Time from "Motion Start" to "Positioning completion". The "Idle Time" is not included.
<div>Start</div> Button <div>Stop</div> Button	motion control buttons.

Example of "Repetitive motion"



Executes Homing motion specified by EiA402 by using TwinCAT3.

TIP !




Possession of the object

If Master controller recognizes the slave device as "NC" when scanning EtherCAT network, the Master has no permission to access to object.

(System Manager navigation tree view showing "MOTION")

To directly rewrite values such as Controlword and TargetPosition object, use the "Online Force" function described on the following pages.



The object which has no permission, is shown as "X" in the object tree view.

Name	Online	Type	Size	>Addr...	In/Out	User ID	Linked to
Status word	X	UINT	2.0	58.0	Input	0	nState1, nState2
Position actual value	X	DINT	4.0	60.0	Input	0	nDataIn1 . In . Inputs . E...
WcState	X	BIT	0.1	1522.2	Input	0	nState4, nState4
InputToggle	X	BIT	0.1	1524.2	Input	0	nState4, nState4
State	8	UINT	2.0	1548.0	Input	0	
AdsAddr	192.168.3.1.3.1:1001	AMSADDR	8.0	1550.0	Input	0	
Chn0	0	USINT	1.0	1558.0	Input	0	
DcOutputShift	X	DINT	4.0	1559.0	Input	0	nDcOutputTime . In . In...
DcInputShift	X	DINT	4.0	1563.0	Input	0	nDcInputTime . In . Inpu...
Control word	X	UINT	2.0	58.0	Output	0	nCtrl1, nCtrl2
Target position	X	DINT	4.0	60.0	Output	0	nDataOut1 . Out . Outpu...



Before starting Homing motion, do enough Jog motion or single motion to make sure you can move safely.


When using an Origin sensor, etc., confirm that the sensor is connected correctly and that it operates correctly.

Ensure that all equipment operates safely.

2. Connecting to the Master Controller

2. Use Beckhoff's "TwinCAT"

Homing



2

Connecting to the Master Controller


2. Use Beckhoff's "TwinCAT"

2. Use Beckhoff's "TwinCAT"

1 Servo ON.

Use "Controlword (6040 h)" to make a PDS state transition.

- Double-click "Device1 (S-Flag2)" in "I/O" to display the "General" tab.
- Right-click "Control word" in the object list and select "Online Force".



Set the Control word value as follows.

Transition to the "Shutdown" state.

Dec: OK


Transition to the "Switch on" state.

Dec: OK

Transition to the "Enable operation" state.

Dec: OK


Servo ON



2 Switch the operation mode to the homing mode.

Switches Modes of Operation (6060 h) from "CSP mode" to "hm mode".

- Switch to the "CoE" tab.
- Check the "Auto Update" checkbox.
- Double-click "6060 Modes of Operation" from the object list.



Set the Modes of operation value to "6" (hm mode).

Switch to "hm mode".


Dec:

6

OK

Click

Changed to homing mode




2. Use Beckhoff's "TwinCAT"

3 Set the Homing motion conditions.

Set the "Homing method (6098 h)", "Homing speeds (6099 h)", and "Homing acceleration (609 Ah)".

- Double-click "6098 Homing method", "Homing speeds", and "homing acceleration" respectively from the object list.

**Homing method**

Selects the type of homing operation. (Range: 1 -6, 17 -22, 33 -35, 37)

See [**1 Operations**] for more information.

Homing speeds

Sets the speed of homing operation. (Unit: pulse/s)

sub-index: "01h"... Speed at home sensor detection (high speed)

Corresponds to amp parameter No. 648.0 (Unit: rpm).

sub-index: "02h"...Speed to detect index pulse (low speed)

Corresponds to amp parameter No. 649.0 (Unit: rpm).

Homing acceleration

Sets the acceleration of homing operation. (Unit: pulse/s²)

Corresponds to amp parameter No. 650.0 (Units: ms/1,000 rpm).

Configuration Complete

Relations between amplifier parameter values and TwinCAT3 settings**Convert [rpm] to [pulse/s] (For a 17 bit encoder)**

Example: The motor rotational velocity of 100 rpm is converted to pulse/s unit for setting by TwinCAT3.

$$100 \text{ [rpm]} = 100 \text{ [rev]} \times 131,072 \text{ [pulse/rev]} / 60 \text{ [s]} = \mathbf{218,453.33 \dots [\text{pulse/s}]}$$

Convert [ms/(1,000 rpm)] to [pulse/s²] (For a 17 bit encoder)

Example: The motor acceleration/deceleration time of 30 ms/(1,000 rpm) is converted to pulse/s² units for setting in TwinCAT3.

$$\begin{aligned} 30 \text{ [ms/(1,000 rpm)]} &= 0.03 \text{ [s]/(1,000 [rev] \times 13,1072 \text{ [pulse/rev]})} / 60 \text{ [s]} \\ &= 0.03 / (1,000 \times 131,072) \times 60 \text{ [s}^2\text{/pulse]} \end{aligned}$$

invert the result of this calculation → **72,817,777.77...[pulse/s²]**

4 Start homing.

Setting bit 4 of Controlword (6040 h) to 1 starts homing.

- Right-click "Control word" in the object list and choose "Online Force".

Being the Servo ON state, the "Control word" value is "15 (= 000Fh)".

Set "31 (= 001Fh)" to set bit 4 (Homing operation start) to "1".

Homing starts.

Dec:

OK

Click

Set Value Dialog

Dec:

Hex:

Float:

Bool: ☐ 0 ☒ 1

Binary: 2

Bit Size: ☐ 1 ☐ 8 ☒ 16 ☐ 32 ☐ 64 ☐ ?

OK Cancel Hex Edit...

Homing starts.

- When the homing operation is completed^{*)}, right-click "Control word" and select "Online Force".

Set bit4 (Homing operation start) back to "0".

Then, set the value to "15 (= 000Fh)".

Closes the homing operation.

Dec:

OK

Click

Set Value Dialog

Dec:

Hex:

Float:

Bool: ☐ 0 ☒ 1

Binary: 2

Bit Size: ☐ 1 ☐ 8 ☒ 16 ☐ 32 ☐ 64 ☐ ?

OK Cancel Hex Edit...

Homing is completed.

^{*)} You can check the completion of homing with Statusword (6041 h).

See [1 Operations] for more information.

After the homing operation is completed

The "Position Actual Value" becomes "0".

Name	Online	Type	Size	>Addr...	In/Out	User ID	Linked to
Status word	X 1591	UINT	2.0	58.0	Input	0	nState1,1
Position actual value	X 0	DINT	4.0	60.0	Input	0	nDataIn1
WcState	X 0	BIT	0.1	1522.2	Input	0	nState4,1
InputToggle	X 0	BIT	0.1	1524.2	Input	0	nState4,1
State	8	UINT	2.0	1548.0	Input	0	
AdsAddr	192.168.31.3:1001	AMSADDR	8.0	1550.0	Input	0	
Chn0	0	USINT	1.0	1558.0	Input	0	


2. Use Beckhoff's "TwinCAT"

4. Save Project file

Save the project.

The project file stores connection information, settings, and test operation conditions.
You can retrieve a saved project file.

Save the project file by choosing "Save All" from the "File" menu.



Finish

Saving the project file is complete.


2. Connecting to the Master Controller

2. Use Beckhoff's "TwinCAT"

5. Open Project file


Open a saved project file.

Select "Project/Solution" in "File" → "Open" to open the saved project.



Turn on the control power to the amplifier.


Wait until the L/A IN LED turns green to indicate that EtherCAT communication has been established.



Click on Activate Configuration to accept the configuration.



If there is no button on the toolbar, there is also a "Activate Configuration" button in the "TwinCAT" menu.



Finish

Reading the project file is complete.

MEMO

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Timing Diagrams

1. Timing Diagram Overview	2
2. Timing Diagrams	3
1. Turning the Power On.....	3
2. Servo OFF → ON.....	4
3. Servo ON → OFF (Motor idling).....	5
4. Servo ON → OFF (Motor rotating).....	6
5. Alarm Occurs.....	7
6. Alarm Reset	8
7. Brake Release	9
8. Dynamic Brake Release.....	10
9. Deceleration Stop Status During Free Run	11
10. Deceleration Stop Status on "Quick Stop" configuration ..	12

3. Timing Diagrams


1. Timing Diagram Overview

List of Timing Diagrams

When designing a host controller system, consider the timing of control signal input from the controller to the amplifier, or alarm signal output from the amplifier.

Description	Refer to
1. Turning the Power On	P. 3
2. Servo OFF → ON	P. 4
3. Servo ON → OFF (Motor idling)	P. 5
4. Servo ON → OFF (Motor rotating)	P. 6
5. Alarm Occurs	P. 7
6. Alarm Reset	P. 8
7. Brake Release	P. 9
8. Dynamic Brake Release	P. 10
9. Deceleration Stop Status During Free Run	P. 11
10. Delay time for Quick Stop Complete	P. 12

Timing Diagram Overview



OUT : Output Signal

Output State	I/O Output Status (EtherCAT Command State)
OFF	Output Transistor is OFF. (0)
ON	Output Transistor is ON. (1)

IN : Input Signal


Input State	I/O Input Status (EtherCAT Command State)
OFF	Open (0)
ON	Close (1)

Internal : Internal Status of the Amplifier

3. Timing Diagrams

2. Timing Diagrams

1. Turning the Power On



*1) After Clear Parameter execution, T1 needs approximately 10 seconds for parameter initialization.

*2) **SRDY** turns ON when **Primary Circuit Power** and **PRDY** turns ON consecutively while **Internal Error Status** remains No Errors.


3

Timing Diagrams

2. Timing Diagrams

2. Timing Diagrams

2. Servo OFF → ON




*1) **Motor Excitation Status** remains OFF until **Motor Rotational Speed** drops to 30 r/min or below.

*2) T1 is specified by Brake-Release Delay Time (No.238.0).

3. Timing Diagrams

2. Timing Diagrams

3. Servo ON → OFF (Motor idling)



*) T1 is specified by Servo OFF Delay time (No.237.0).


3

Timing Diagrams

2. Timing Diagrams

2. Timing Diagrams

4. Servo ON → OFF (Motor rotating)



*1) The motor decelerates according to the method specified by Deceleration Stop Method (No.224.0)

*2) Quick stop or Short brake ends when deceleration stop conditions set by parameters (No.224.1, No.226.0, and No.227.0) are met.

*3) Deceleration Stop Method (No.224.0) = 2 (quick stop) or 1 (short brake)


MBRK turns OFF when one of the following conditions is met :

a) **Deceleration Stop Status** turns OFF

b) The rotational speed drops to the value specified by **Deceleration stop Rotational speed to cancel** (No.227.0) or below.

Deceleration Stop Method (No.224.0) = 0 (free run)


MBRK turns OFF when **Motor Excitation Status** becomes OFF.



- *1) The motor will stop per Deceleration Stop Method (No.224.0) as follows.
 2 (quick stop) or 1 (short brake) : the motor decelerates and stops by short brake.
 0 (Free-run) : no brake.
- *2) **Deceleration Stop Status** ends when deceleration stop conditions set by the parameters (No.224.1, No.226.0, and No.227.0) are met.
- *3) Timing of **MBRK** turning OFF
 If Deceleration Stop Method (No.224.0) = 2 (quick stop) or 1 (short brake),
MBRK turns OFF when one of the following conditions is met.
 1) **Deceleration Stop Status** turns OFF
 2) **Motor Rotational Speed** drops to the value specified by the parameter No.227.0 or below.
 If Deceleration Stop Method (No.224.0) = 0 (no brake),
MBRK turns OFF when **Motor Excitation Status** turns OFF.
- If any of the following alarms occurs,
MBRK turns OFF when the internal error status becomes **ERROR**.
 a) Encoder related errors b) Control Power voltage drop error
 c) Errors related to Inverter output part d) Overvoltage error
 If any alarm except above four occurs, the motion pattern will be exactly as this timing diagram suggests.
- *4) Deceleration Stop behaves as follows depending on the error type :
 a) Encoder related errors : Deceleration Stop per Deceleration stop operating time (Parameter No.226.0)
 b) Control Power voltage drop error : Deceleration Stop per Deceleration stop (upon control power failure) Operating time (No.228.0)
 c) Errors related to Inverter output part : Free-run
- *5) In case of the following alarms, **Servo Status** will remain ON until **Deceleration Stop Status** turns OFF.
 a) Encoder related errors
 b) Control power voltage drop error


2. Timing Diagrams

6. Alarm Reset



7. Brake Release


Deceleration Stop : Timing for Engaging Brake (No.232.3) = 0



*1) MBRK turns OFF is when one of the following becomes true, a) Deceleration Stop completes, or b) Motor rotational speed drops to the value of Deceleration stop - Rotational speed to cancel (No.227.0) or below.

*2) If the deceleration stop method is quick stop, the motor will remain excited during deceleration stop.

Deceleration Stop : Timing for Engaging Brake (No.232.3) = 1




*1) MBRK turns OFF is when one of the following becomes true, a) Deceleration Stop completes, or b) Motor rotational speed, after the time specified by Parameter No.234.0 elapses, drops to the value specified by Parameter No.235.0 or below.

*2) If the deceleration stop method is quick stop, the motor will remain excited during deceleration stop.

2. Timing Diagrams

8. Dynamic Brake Release


Upon Servo ON, if Deceleration stop (when Servo is OFF) : Method (No.224.0) = 3 (dynamic brake)



*1) **SERVO** does not turn ON until **Motor Rotational Speed** drops below 30 r/min.

*2) When **DBRK** output (No.224.3) = 1 (dynamic brake) after a stop per Deceleration Stop (when Servo is OFF)

Upon Alarm Clear, if Deceleration stop (when Servo is OFF) Method (No.224.0) = 3 (dynamic brake)




3. Timing Diagrams

2. Timing Diagrams


9. Deceleration Stop Status During Free Run

Deceleration Stop Status where Deceleration Stop Method (at Servo OFF) (No.224.0) and Deceleration Stop Method (at Alarm ON) (No.233.0) are set to free run.

Deceleration stop : Deceleration stop status during free-run (No.232.1) = 0 (OFF)



Deceleration stop : Deceleration stop status during free-run (No.232.1) = 1 (ON)



*1) **MBRK** turns OFF when one of the following conditions is met :

- Deceleration Stop Status** turns OFF.
- Motor Rotational Speed** drops to the value of Deceleration stop - Rotational speed to cancel (No.227.0) or below.


*2) **Deceleration Stop Status** turns OFF when deceleration stop conditions (No.224.1, 226.0, or 227.0) are met.

2. Timing Diagrams

10. Deceleration Stop Status on "Quick Stop" configuration

When Servo becomes OFF while motor is in motion and then the motor decelerates to stop by the quick stop method.

Deceleration stop : Method (at Servo OFF) (No.224) = 2 (quick stop)



*1) **Deceleration Stop Status** turns OFF after the deceleration stop conditions set by the Parameters (No.224.1, 226.0, and 227.0) are met and the time amount set to **Quick Brake Delay Time** (No.236.0) elapses.

*2) When **DBRK** output (No.224.3) = 1 (dynamic brake) after Deceleration Stop (at Servo OFF) ends.

Z

APPENDICES

1. Troubleshooting
2. Technical Information

Troubleshooting

1. Checking Warnings and Alarms	2
1. Using the Setup Panel	2
2. Using S-TUNE II.	3
2. Warnings and Remedies	4
1. Warning Output	4
2. Warning Details	5
3. Alarms and Remedies	7
1. List of Alarms	7
2. Alarm Details	9
4. Troubleshooting	18
Problem 1. No display on the Setup Panel	19
Problem 2. Servomotor not turning ON	20
Problem 3. No motor rotation.	21
Problem 4. Unstable motor motions	22
Problem 5. Positional aberration.	23
Problem 6. Vibration and abnormal noise.	24
Problem 7. EtherCAT communication cannot be established.	25
Problem 8. Servomotor not turning ON-2	26
Problem 9. No motor rotation-2	27

1. Checking Warnings and Alarms

Warnings and alarm numbers can be viewed on the Setup Panel or S-TUNE II.

When an alarm and a warning occur at the same time, the alarm will be displayed first.

For possible cause and remedy, verify on the warning or alarm list.

The alarm history keeps up to ten alarms including the current one. ^(*)

^(*) Alarm No.22 (control power supply error) and Warning numbers are not logged in the alarm history.

The alarm numbers and the cumulative run time (in hours) up to the time of alarm are logged.

Note: The amplifier version can be checked with S-TUNE II.

 **D-1** About S-TUNE II

1. Using the Setup Panel

When a warning occurs, the amplifier LED blinks green. In addition, the Setup Panel will automatically display the corresponding warning No.

When an alarm occurs, the amplifier LED changes from solid green to solid red. In addition, the Setup Panel will automatically display the alarm No.

 **C-1** Setup Panel

EtherCAT communication node address



Displays the node address of the EtherCAT communication.

Displays for approximately 2 seconds.

If an alarm occurs when the amplifier is started, the node address is not displayed.

Servo status



Indicates the servo status of the amplifier.

The servo status is not displayed when an alarm occurs.




Servo **OFF**



Servo **ON**

Alarm status




Alarm No. —

Displays the alarm number that has occurred.

The alarms are from No.00 to No.34.

Warning status



Warning No. —

Displays the warning number that has occurred.

The warnings are from No.900 to No.904.

1. Troubleshooting

1. Checking Warnings and Alarms


2. Using S-TUNE II

Turn on the control power AC200 V to the amplifier and start S-TUNE II.

For information on the warning/alarm, check "Alarm currently occurring" under the [Alarm] tab.

If you are not sure what to do, contact us with the alarm number and its description.


 D-1 About S-TUNE II



Step1 Select the Alarm tab in S-TUNE II.

Step2 See [Current alarm] and [Cause for the alarm] and [What to do] windows for details.

Checking the Alarm History in S-TUNE II



The alarm history area shows a list of the alarms.






2. Warnings and Remedies

1. Warning Output

There are two ways to output warnings.

1. Setup Panel Output

During warning output, the warning number will appear on the Setup Panel.

Warning No.	Display	Warning Description	Refer to
900		Encoder overheat detection	P. 6
901		Encoder battery voltage drop error detection	P. 6
902		Emergency stop	P. 6
903		Encoder communication warning	P. 7
904		Excessive position deviation	P. 7

2. S-TUNE II

Select the Alarm tab in S-TUNE II.

See [Current alarm] and [Alarm history] windows for details.

 D-1 About S-TUNE II

1. Troubleshooting

2. Warnings and Remedies

2. Warning Details

Warning No.	900	Encoder overheat detection
Symptom and Possible Cause	The temperature inside the absolute encoder has exceeded the temperature value specified by Encoder: Overheat detection - Value (No.267.0). An alarm can be output in place of the warning.	
Remedy	Lower ambient temperatures and improve thermal radiation conditions. Check the setting of Encoder: Overheat detection - Value (No.267.0).	
Reset Method	After eliminating the cause, then input RESET signal to the RESET terminal on the connector C5.	

Warning No.	901	Encoder battery voltage drop error detection
Symptom and Possible Cause	The battery voltage of the absolute encoder dropped below the voltage set by Encoder: Battery voltage drop detection - Value (No.268.0).	
Remedy	Replace the battery in the absolute encoder. Check the Encoder: Battery voltage drop detection - Value (No.268.0).	
Reset Method	After eliminating the cause, then input RESET signal to the RESET terminal on the connector C5.	

Warning No.	902	Emergency stop
Symptom and Possible Cause	E-STOP by I/O is open.	
Remedy	Close E-STOP of the I/O. Check for proper I/O connections.	
Reset Method	After eliminating the cause, then input RESET signal to the RESET terminal on the connector C5.	
Related To	Z- 2 Technical Information	

2. Warnings and Remedies
















Warning No.	903	Encoder communication warning
Symptom and Possible Cause	Failed to obtain ABS encoder temperature and battery voltage data.	
Remedy	<p>Check for wire disconnection or loose connection of pins. Keep the cable length no longer than 20 meters. Check for noise interference.</p> <ul style="list-style-type: none"> → Use a shielded twist-pair cable. → Keep the encoder cable away from the motor power cable. → Connect FG firmly. → Use ferrite core for the motor power cable and encoder cable. <p>If any of the above didn't resolve the issue, please contact our distributor.</p>	
Reset Method	After eliminating the cause, then input RESET signal to the RESET terminal on the connector C5.	

Warning No.	904	Excessive position deviation
Symptom and Possible Cause	The position deviation consecutively exceeded the setting of Position deviation warning detection: Value (No.363.0) and the setting of Position deviation warning detection: Delay time (No.365.0).	
Remedy	<p>Adjust the tuning parameters. Check the command from the host controller. Check the wiring. Verify that the brake is released. Verify that the motor is not in a torque limit state per torque command limit. Check the settings of Position deviation warning detection: Value (No.363.0) and Position deviation warning detection: Delay time (No.365.0).</p>	
Reset Method	After eliminating the cause, then input RESET signal to the RESET terminal on the connector C5.	
















1. Troubleshooting

3. Alarms and Remedies

1. List of Alarms

Alarm No.	Display	Alarm Name	Refer to
0		System error	P. 9
1		EEPROM data error	P. 9
2		Product code error (Mismatching code)	P. 9
3		EtherCAT communication error	P. 9
4		Overspeed error	P. 10
5		Velocity deviation error	P. 10
6		Position deviation error	P. 10
7		Overload error	P. 11
8		Command overspeed error	P. 11
10		Positioning command overflow error /Homing failure	P. 12
11		Multi-turn counter error	P. 12
12		Overheat error	P. 12
14		Overvoltage error	P. 13
15		Power supply error (Primary circuit AC power)	P. 13
16		Encoder error (Received data)	P. 14





3. Alarms and Remedies

Alarm No.	Display	Alarm Name	Refer to
17		Encoder error (No response)	P. 14
18		Encoder error (Hardware)	P. 14
19		Encoder error (Communication)	P. 14
20		Encoder error (Multi-turn data)	P. 14
21		Encoder error (Voltage drop)	P. 15
22		Voltage error (Internal control power DC24V)	P. 15
23		Switch circuitry error	P. 15
24		Overcurrent error	P. 15
25		Inverter error 1	P. 16
26		Inverter error 2	P. 16
27		Current sensor error	P. 16
28		Encoder error (Overheat)	P. 16
29		Voltage error (Internal control power DC5V)	P. 16
32		Power supply error (Control circuit AC power)	P. 17
34		Product code error (Undefined model code)	P. 17


1. Troubleshooting


3. Alarms and Remedies


2. Alarm Details

Alarm No.	0	System error
Symptom and Possible Cause	Error in the control circuit The control circuit CPU is not operating normally.	
Remedy	Please contact our distributor.	
Reset Method		
Alarm No.	1	EEPROM data error
Symptom and Possible Cause	Error at Write Parameters	
Remedy	Check the interface cable and re-write the parameters.	
Reset Method		
Alarm No.	2	Product code error (Mismatching code)
Symptom and Possible Cause	Unable to read the product code The amplifier-motor pairing was wrong. The encoder cable was not connected to the amplifier correctly. (This includes wiring disconnection)	
Remedy	Check the motor-amplifier pairing. Check the encoder cable connections.	
Reset Method		
Alarm No.	3	EtherCAT communication error
Symptom and Possible Cause	EtherCAT communication is not working properly.	
Remedy	<ul style="list-style-type: none"> • Check the "command mode (Parameter No.3.0)" value is 10. • Check the EtherCAT communication cable. • Check the connection status (ESM) with the host controller. • Check for noise. <ul style="list-style-type: none"> → Use a shielded cable. If any of the above didn't resolve the issue, please contact our distributor.	
Reset Method		

3. Alarms and Remedies

Alarm No.	4	Overspeed error
Symptom and Possible Cause	The motor rotational speed exceeded the rated maximum rotational speed. The command from the host controller was not appropriate. There were residual pulses due to drive restriction or other reasons.	
Remedy	Adjust the Tuning parameters. Check the command. Verify that the location of the limit sensor hasn't shifted.	
Reset Method		

Alarm No.	5	Velocity deviation error
Symptom and Possible Cause	Position control/Speed control error. The command was not appropriate. The load was too heavy and could not keep up with the command speed. Speed deviation error detection: Value (No.90.0) was not appropriate.	
Remedy	Check the command from the host controller. Adjust the tuning parameters. Check the setting of Speed deviation error detection: Value (No.90.0) . Verify that the brake is released. Verify that the motor is not in a torque limit state per torque command limit.	
Reset Method		

Alarm No.	6	Position deviation error
Symptom and Possible Cause	Position Control Error. The acceleration time was too short. There was wrong connection or disconnection of the motor power cable or encoder cable. Position deviation error detection: Value (No.87.0) was not appropriate.	
Remedy	Adjust the tuning parameters. Check the command from the host controller. Check the wiring. Check the setting of Position deviation error detection: Value (No.87.0) . Verify that the brake is disengaged. Verify that the motor is not in a torque limit state per torque command limit.	
Reset Method		



RESET Signal

- ① Eliminate the cause.
- ② input RESET signal to the RESET terminal on the connector C5.



Control-power cycle



- ① Eliminate the cause.
- ② Cycle control-power.






CLEAR Encoder

- ① Eliminate the cause.
- ② Execute CLEAR Encoder
- ③ Cycle control-power.
After power cycle, perform Homing.

3. Alarms and Remedies


Alarm No.	7	Overload error
Symptom and Possible Cause	<p>Position Control Error.</p> <p><u>Immediately after the operation started</u></p> <ol style="list-style-type: none"> 1. The motor did not move at all. 2. The motor moved a little. 3. An alarm occurred after the motor started moving. <p><u>During operation</u></p> <ol style="list-style-type: none"> 4. An alarm occurred at the same timings during of motions. The acceleration time was too short. The motor was not accelerating when the alarm occurred. (The machine collided with some object.) 5. The motor capacity was too small (i.e. the load was too large). 6. The vibration was significant upon alarm occurrence. 7. Tuning parameters or command(s) were not appropriate. (The motor changed its rotational direction abruptly) 8. Noise was generated. 	
Remedy	<p>Executing overloaded motions continuously may burnout the motor.</p> <ol style="list-style-type: none"> 1. 2. Check the motor power cable connections. 3. Verify that the user-selected motor capacity is appropriate. Verify that the brake is disengaged. Verify that the deceleration ratio is appropriate. 4. During Acceleration - Check the acceleration time, torque wave form and load ratio. Not During Acceleration - Verify that there are no obstacles inside the work area of the equipment. 5. Check the torque waveforms and load ratio. Check the inertia ratio. Increase the motor capacity. Install a decelerator 6. 7. Adjust the Tuning parameters. Verify that there are no commands to cause a sudden change in the motor rotational direction. Configure moderate commands, for example, use command smoothing filter. 8. Configure countermeasures for noise such as a notch filter or low-pass filter. 	
Reset Method		
Alarm No.	8	Command overspeed error
Symptom and Possible Cause	<p>Position Control Error.</p> <p>The position control input exceeded the max rotational speed.</p> <p>The command from the host controller was not appropriate.</p>	
Remedy	<p>Check the EtherCAT communication command: Ratio (No.34.0 and No.36.0).</p> <p>Check the commands from the host controller.</p>	
Reset Method		


3. Alarms and Remedies

Alarm No.	10	Positioning command overflow error/Homing failure
Symptom and Possible Cause	<p>External position command exceeded the absolute value range of $\pm 1,073,741,823$. The shift amount per one of commands exceeded the $\pm 2,147,483,647$ range. Homing failed and timed out.</p>	
Remedy	<p>Select a value different from the current setting of Internal Position: Overflow detection (No.643.0). Adjust the parameters such that the shift amount will be within the $\pm 1,073,741,823$ range. Adjust the shift amount of Positioner motion, inching and testing each. Adjust the Homing related parameters.</p>	
Reset Method		
Alarm No.	11	Multi-turn counter error
Symptom and Possible Cause	<p>Multi-turn data of the encoder has exceeded the $\pm 32,767$ range.</p>	
Remedy	<p>Check the setting of Absolute system (No.257.0). Verify that the multi-turn motion amount is within the $\pm 32,767$ range.</p>	
Reset Method		
Alarm No.	12	Overheat error
Symptom and Possible Cause	<p>The control circuit temperature has exceeded the upper limit.</p>	
Remedy	<p>Check the amplifier's installation method and environment. Lower the ambient temperature to below the rating.</p>	
Reset Method		

1. Troubleshooting

3. Alarms and Remedies

Alarm No.	14	Overvoltage error
Symptom and Possible Cause	The primary circuit voltage of the control component has exceeded the amplifier circuit limits.	
Remedy	<p><u>If the alarm occurs only during deceleration</u></p> <p>By using the Setup Panel or S-TUNE II , check the regeneration status, which tells you if a regenerative resistor is necessary. If necessary, install a regenerative resistor.</p> <p>Check the motion patterns of commands.</p> <p>Use a command filter and gradually decrease the speed.</p> <p><u>If the alarm occurs regardless of deceleration</u></p> <p>Verify that the primary circuit power voltage is within specification.</p> <p>Check for voltage changes while the whole system is operating.</p>	
Reset Method		

Alarm No.	15	Power supply error (Primary circuit AC power)
Symptom and Possible Cause	<p>The primary circuit voltage is abnormally high or low.</p> <p>The primary circuit power was not supplied.</p> <p>The primary circuit power was not within the input range.</p> <p>The primary power voltage fluctuated and exceeded the rated range.</p> <p>Enable Operation (0x6040,3) signal was input without primary circuit power supply.</p> <p>Anomaly of the regenerative control circuit operating time lasted longer than a specific amount of time.</p> <p>Regeneration ON status lasted.</p>	
Remedy	<p><u>If the alarm occurred between servo on and operation startup</u></p> <p>Verify that the primary circuit power is connected to the amplifier.</p> <p>Check the primary circuit power voltage.</p> <p>Check the timing of primary circuit power input and Enable Operation (0x6040,3) signal input.</p> <p><u>If the alarm occurred during motor operation</u></p> <p>Check for no voltage fluctuations due to the whole system operation.</p> <p>Provide enough power supply so that the system experiences no voltage fluctuations.</p> <p><u>If the alarm occurs during deceleration</u></p> <p>Check the regenerative voltage warning spinal on the Setup Panel or S-TUNE II .</p> <p>If a regenerative voltage warning occurs, install a regenerative resistor.</p> <p>Check the motion patterns directed by commands.</p> <p>Gradually decrease speeds by using a command smoothing filter.</p>	
Reset Method		



RESET Signal

- ① Eliminate the cause.
- ② Input RESET signal to the RESET terminal on the connector C5.



Control-power cycle



- ① Eliminate the cause.
- ② Cycle control-power.







CLEAR Encoder

- ① Eliminate the cause.
 - ② Execute CLEAR Encoder
 - ③ Cycle control-power.
- After power cycle, perform Homing.





3. Alarms and Remedies

Alarm No.	16	Encoder error (Received data)
Symptom and Possible Cause	Encoder data changed rapidly for a short period of time.	
Alarm No.	17	Encoder error (No response)
Symptom and Possible Cause	Encoder communications were disconnected.	
Alarm No.	19	Encoder error (Communication)
Symptom and Possible Cause	The initial communication with the encoder failed.	
Alarm No.	20	Encoder error (Multi-turn data)
Symptom and Possible Cause	Absolute encoder data changed rapidly for a short period of time. At the time of starting, the encoder failed to receive multi-turn data internally.	
Remedy	<p>Check for wire disconnection or loose connection of pins. Keep the cable length no longer than 20 meters. Check for noise interference.</p> <ul style="list-style-type: none"> → Use a shielded twist-pair cable. → Keep the encoder cable away from the motor power cable. → Connect FG firmly. → Use ferrite core for motor power cable and encoder cable. <p>Check that the encoder temperature does not exceed the specified range. If any of the above didn't resolve the issue, please contact our distributor.</p>	
Reset Method		
Alarm No.	18	Encoder error (Hardware)
Symptom and Possible Cause	<p>Anomaly of the encoder itself has been detected. The encoder temperature has exceeded the specification and output data has become abnormal. The battery voltage of the absolute encoder dropped or the battery became disconnected. (Alarm No.21 is output in this case)</p>	
Remedy	<p>Check for wire disconnection or loose connection of pins. Keep the cable length no longer than 20 meters. Check for noise interference.</p> <ul style="list-style-type: none"> → Use a shielded twist-pair cable. → Keep the encoder cable away from the motor power cable. → Connect FG firmly. → Use ferrite core for motor power cable and encoder cable. <p>Check that the encoder temperature does not exceed the specified range. If you are using an absolute system</p> <ul style="list-style-type: none"> → Replace the battery, connect it, and initialize the encoder. <p>If any of the above didn't resolve the issue, Check the alarm number in the S-TUNE II and contact our distributor.</p>	
Reset Method		


3. Alarms and Remedies



Alarm No.	21	Encoder error (Voltage drop)
Symptom and Possible Cause	The battery voltage dropped. The batter became disconnected. It was the first start-up after the battery was connected.	
Remedy	Check for low battery voltage. Check for loose battery cable. Initialize the encoder.	
Reset Method		
Alarm No.	22	Voltage error (Internal control power DC24V)
Symptom and Possible Cause	The control power voltage (24VDC) inside of the amplifier has dropped.	
Remedy	Check the control power AC200 V voltage. Check for insufficient control power capacity. This alarm may be output at the same time as other alarms such as Alarm No.15 (Power error). Check all the alarms that are occurring. This alarm will not remain in the alarm history.	
Reset Method		
Alarm No.	23	Switch circuitry error
Symptom and Possible Cause	Control circuit is faulty.	
Remedy	Please contact our distributor.	
Reset Method		
Alarm No.	24	Overcurrent error
Symptom and Possible Cause	Anomaly of motor control current inside of the amplifier has been detected.	
Remedy	Check the motor power cable. → Grounding fault → Wiring mistake in the motor power cable connection Check the Tuning parameters and motor motion patterns. → Increase the acceleration/deceleration time of command. → Enable/Disable Position command filter 1 and 4 (No.66.0, No.66.1, No.80.0, and No.81.0). Allow motor motion by disengaging the brake or removing from the stopper. Check the encoder cable. → Connection (bad connection) → Use a twist-pair cable If any of the above didn't resolve the issue, please contact our distributor.	
Reset Method		

3. Alarms and Remedies

Alarm No.	25	Inverter error 1
Symptom and Possible Cause	Anomaly in the control circuit has been detected.	
Alarm No.	26	Inverter error 2
Symptom and Possible Cause	Anomaly in the control circuit has been detected. SERVO ON timed out.	
Remedy	Check the motor power cable. → Grounding fault → Wiring mistake in motor power cable connections If any of the above didn't resolve the issue, please contact our distributor.	
Reset Method		
Alarm No.	27	Current sensor error
Symptom and Possible Cause	The ambient temperature of the current sensor was high. Anomaly of the current sensor has been detected.	
Remedy	Check the installation method and environment. If any of the above didn't resolve the issue, please contact our distributor.	
Reset Method		
Alarm No.	28	Encoder error (Overheat)
Symptom and Possible Cause	The encoder board temperature has reached the upper limit.	
Remedy	Check the installation method and environment of the motor. Decrease the ambient temperature of the motor below the specification.	
Reset Method		
Alarm No.	29	Voltage error (Internal control power DC5V)
Symptom and Possible Cause	The control power voltage (5VDC) inside of the amplifier has dropped.	
Remedy	Verify that there is no short-circuit in encoder cable connections. If any of the above didn't resolve the issue, please contact our distributor.	
Reset Method		

3. Alarms and Remedies

Alarm No.	32	Power supply error (Control circuit AC power)
Symptom and Possible Cause	Abnormality of high or low control voltage <ul style="list-style-type: none">• The control power was not input.• The control power supply voltage was out of the input range.• The control power supply voltage fluctuated and went out of range.	
Remedy	<ul style="list-style-type: none">• Check the control power supply voltage.• Check that there is no voltage fluctuation due to the operation of the entire equipment.• Use a power supply with sufficient supply capacity to prevent voltage fluctuation. <p>If any of the above didn't resolve the issue, please contact our distributor.</p>	
Reset Method		

Alarm No.	34	Product code error (Undefined model code)
Symptom and Possible Cause	Encoder communication was lost. The motor model code is incorrect.	
Remedy	Please contact our distributor.	
Reset Method	 	

4. Troubleshooting

Check the following if the amplifier does not start and the motor does not rotate although no alarm is output.

Problem	Symptom	Refer to
Problem 1 No display on the Setup Panel	The Setup Panel does not show.	P. 19

Problem	Symptom	Refer to
Problem 2 Servomotor not turning ON	The Setup Panel shows, but the servo cannot be turned on.	P. 20

Problem	Symptom	Refer to
Problem 3 No motor rotation	The servo is on, but the motor does not rotate.	P. 21

Problem	Symptom	Refer to
Problem 4 Unstable motor motions	The motor does rotate, but its motions are unstable.	P. 22

Problem	Symptom	Refer to
Problem 5 Positional aberration	The motor does rotate, but position aberration occurs.	P. 23

Problem	Symptom	Refer to
Problem 6 Vibration and abnormal noise	The motor is experiencing vibration or abnormal noise.	P. 24

Problem	Symptom	Refer to
Problem 7 EtherCAT communication cannot be established	Cannot transition to OP mode (ErrLED flashing)	P. 25

Problem	Symptom	Refer to
Problem 8 Servomotor not turning ON-2	The motor is not energized.	P. 26

Problem	Symptom	Refer to
Problem 9 No motor rotation-2	The motor does not rotate or rotates but stops.	P. 27

4. Troubleshooting

Problem 1. No display on the Setup Panel

The Setup Panel does not show.

Cause	Remedy
The controller power is not connected to the user I/O connector.	Connect the controller power to the amplifier.
Loose user I/O connector	Connect the user I/O connector firmly.
The control power voltage is low.	Check the control power voltage capacity.
The amplifier is faulty.	Please contact our distributor.

4. Troubleshooting

Problem 2. Servomotor not turning ON



The Setup Panel shows, but the servo cannot be turned on.

Cause	Remedy
The Enable Operation (0x6040,3) signal is not being input.	Check the EtherCAT communication cable for proper connections. Input the Enable Operation (0x6040,3) signal.
The primary circuit power is not supplied. (Alarm No.15 is displayed)	Verify that CHARGE LED is on. If it is off, verify that the primary circuit power is not loose, and the primary circuit power is output.
The motor power connector is loose.	Connect the user I/O connector firmly.
The amplifier is faulty.	Please contact our distributor.

4. Troubleshooting

Problem 3. No motor rotation

The servo is on, but the motor does not rotate.

Cause	Remedy
The parameters are not set right.	Correctly set the parameters required for the control mode that you are using.  F-1 Operations
Command from the host controller is not correctly input.	Check the command from the host controller. Use S-TUNE II to measure the input command waveforms and verify that normal commands are input. Check the parameters such as pulse ratio. It is possible that the motor is rotating very slowly.
The command input pins of user I/O connector are not connected correctly.	Check for proper connections.  B-2 Mounting and Wiring
Torque command limit is not set right.	Verify that Torque command limit: Value 1 and Value 2 (No.147.0, No.148.0) are set correctly.

4. Troubleshooting

Problem 4. Unstable motor motions

The motor does rotate, but its motions are unstable.

Cause	Remedy
FG and GND are not connected correctly.	Connect FG and GND correctly.
Speed/Position commands are unstable.	On the waveform monitor in S-TUNE II, check the command from the host controller. Check for proper connection of the I/O connector.
Tuning is incomplete.	Adjust the parameters.

4. Troubleshooting


Problem 5. Positional aberration

The motor does rotate, but position aberration occurs.

Cause	Remedy
The command signal is interfered with noise.	<p>Check the following two items.</p> <ol style="list-style-type: none">1. Status 810h Target Position (EtherCAT communication position command input) agrees with the host controller output.2. Status No.65 "Position command" and Status No.67 "Position feedback" agree. <p>If any of the above conditions fails, take countermeasures for noise.</p> <ul style="list-style-type: none">-Connect FG correctly.-Select a shielded twist-pair wire for the I/O cable.-For the encoder cable, select a shielded twist-pair wire of no longer than 20 m.
The position deviation is not converging.	<p>Verify that Status No.65 (Position command value) and Status No.67 (Position feedback) agree.</p> <p>If not, adjust the tuning parameters.</p>
The host controller is not obtaining encoder Z-phase correctly.	<p>Check the command from the host controller.</p> <p>Verify that a normal command is input.</p> <p>Verify that the host controller is obtaining Z-phase correctly.</p>
Output pulse frequency of the host controller is above the upper limit.	<p>Verify that the output pulse frequency of the host controller such as PLC is not above the upper limit.</p>

Problem 6. Vibration and abnormal noise

The motor is experiencing vibration or abnormal noise.

Cause	Remedy
Tuning parameter settings are not appropriate.	Set the Control Gain 1, Control Gain 2, Integral Gain to lower values. Especially for highly rigid equipment such as ball screws, set the Current control gain (No.193.0) to "1" if noise occurs at servo-on stop.  C- 3 Tuning
Cranky or loose machines and equipment	Check the installation of the motor, decelerator, couplers, and so on.
Noise interference is occurring.	Check the length or shield of each cable. Isolate the high voltage cable such as motor power cable from the signal cable such as encoder cables.
The equipment and the motor are resonating.	For low-frequency vibration, adjust the position command smoothing filter. For high-frequency vibration, adjust the low-pass filter or notch filter.
Motor load is substantially large (*) (Alarm No.7 is displayed)	Set the inertia condition parameter to "Heavy" Keep adjusting the Position Command Smoothing Filter to smooth command until the vibration at the time of acceleration becomes eliminated. Set the Inertia ratio (No.102.0) to 3,000. To stabilize the motions, increase Integral gain value according to Control Gain 1 and Control Gain 2.
The current pairing of amplifier and motor is not right.	Check the motor model code under "Communication Settings" tab in S-TUNE II. In case of wrong pairing, clear the parameters saved in EEPROM and change the motor model code.

*) This problem may occur in a low-rigidity case such as belt drive whose load inertia ratio is over 30 times.

4. Troubleshooting

Problem 7. EtherCAT communication cannot be established

Cannot transition to OP mode (ErrLED flashing)

Cause	Remedy
The amplifier is set to internal command mode.	Check if the value of parameter No.3.0 (command mode) is 10 (EtherCAT directive).
EtherCAT communication cycle out of specification.	The communication cycles are 250 μ s, 500 μ s, 1 ms, 2 ms, and 4 ms. Set to one of the above values.
ESM (EtherCAT State Machine) State Transition Control is Incorrect,	Set the amplifier in the following order: Init → PreOP → SafeOP → OP.
ESI file is incorrect	Use an ESI file with the same version as the F/W version of the amplifier.
Unsupported object is mapped to PDO.	Check the PDO mapping.
Incorrect LAN cable connection	Check the wiring of the LAN cable.

4. Troubleshooting

Problem 8. Servomotor not turning ON-2

The motor is not energized.

Cause	Remedy
DC (Distribution clock) is disabled (FreeRun or SM).	Enable the DC setting. In "Disable" setting, EtherCAT communication and Object Dictionary Read/Write are possible, but motor operation such as servo ON is not possible.
Mode of operation is set to a mode other than the available mode.	Set to CSP (8), CSV (9), CST (10) or Homing (6).
PDS (Power Drive Systems) State Transition Control is Incorrect,	Check the specifications for the CiA 402 PDS transition. Check that the amplifier transition is complete before issuing the next transition command. (Switch on disabled -> Ready to switch on -> Switched on -> Operation enabled)
EtherCAT communication cycle out of specification.	Set the amplifier in the following order: Init → PreOP → SafeOP → OP.
The torque upper limit value is not appropriate.	Check the Max torque (6072h) setting.
Main circuit power is not supplied correctly. (SRDY not successful)	Check the wiring and voltage.
E-Stop (emergency stop) signal is input.	Check the wiring of the E-Stop signal. Check the polarity setting of the E-Stop signal input.
The amplifier is in an alarm state.	Recover from the alarm state.
The motor power cable is not connected.	Check the connection of the motor power cable.

4. Troubleshooting

Problem 9. No motor rotation-2

The motor does not rotate or rotates but stops.

Cause	Remedy
"Mode of operation" and "command input method" do not match.	The command for each mode must be inputted with the following object CSP (8) : Target position (607Ah) CSV (9) : Target velocity (60FFh) CST (10) : Target Torque (6071h) Homing(6) : The command is generated inside the amplifier. Homing starts using Controlword (6040h) bit 4.
The setting of the speed upper limit or the torque upper limit is not appropriate.	Check the settings for each of the following objects. Max torque (6072h) Max motor speed (6080h) Max profile velocity (6081h)
Drive inhibit signal is input.	Check the wiring and setting of the drive inhibit signal (POT or NOT).

MEMO

This image shows a full page of blank, lined paper. It features approximately 20 evenly spaced horizontal grey lines across its entire surface, typical of notebook or composition paper. The lines are uniform in thickness and color, providing a guide for handwriting. There are no margins, text, or other markings present on the page.

Technical Information

1. Absolute System.	2
1. Overview	2
2. System Configuration.	3
3. Backup Battery	4
4. Absolute Encoder Cable	6
5. Initializing Absolute Encoder.	7
6. Obtaining Absolute Data.	10
7. Alarm.	11
2. Function	13
1. Emergency Stop	13
3. Amplifier Circuit System Block Diagram	14
1. Amplifier Circuit System Block Diagram.	14
4. Status Display.	17
1. Introduction	17
2. List of Status Variables.	18
3. Details of Each Status Variable.	19

1. Absolute System

1. Overview

By using the absolute system, you do not have to perform Homing after cycling power.

Preparations

To configure an absolute system, prepare the following items.

① A motor equipped with absolute-encode and an amplifier that supports absolute system.

② A backup battery

 P. 4 Backup Batteries

③ An absolute encoder Cable

 P. 6 Absolute Encoder Cable

Checking the model code

Use the modes that supports absolute systems.

Motor Product Code:

Motor Product Code: M 2 A * *



Common to 23 Bit and 17 Bit encoder





Encoder	
Code	Specifications
N	Incremental
A	Absolute

2. Technical Information


1. Absolute System

2. System Configuration

Connection Method

1. To ensure safety, power off the primary power and the control power first, and then connect the absolute encoder cable.
 Refer to the figure below.
2. Be sure of the right connecting direction, and connect the backup battery correctly.
 P. 4 Backup Battery
3. After connecting the battery, secure the battery to the absolute encoder cable by using a cable tie.
 P. 5 Securing the Battery
4. Initialize the absolute encoder.
 P. 7 Initializing Absolute Encoder

Cable and Battery Connections



1. Absolute System


3. Backup Battery

Recommended Specifications

Item	Specifications	Remark
Model Code	CR17335E-R-CH3	Manufactured by FDK (*) Series battery:CR17335E-R
Nominal Voltage	3.0 V	–
Nominal Capacity	1,600 mAh	Nominal capacity is determined at the voltage of 2.0 V when the battery was discharged at a standard current level under the 23°C environment.
Maximum Continuous Discharge Current	500 mA	Under the 23°C environment
Dimensions	See the figure below.	No obvious deformation or damage Clear label print
Exterior	Insulation tubing	–
Terminal	Housing :DF3-2S-2C Contact :DF3E-2428SCFC Lead wire:UL 1007 AWG26 Red (+), Black (–)	Connector: Hirose Electric
Mass	17 g	reference value
Temperature Range	Operating temperature: –40°C to +70°C	No dew condensation
Recommended Storage Conditions	Temperature:10°C to 30°C Humidity:60% RH or less	–

*) This is a primary lithium battery. Do not try to charge it, or it may explode.

Dimensions



1. Absolute System

Precautions for Battery Storage and Installation

Avoid places subjected to any of the following:

- Direct sunlight, rain drops
- Corrosive atmosphere, oil mist, or iron powder
- Poor ventilation or high humidity
- Dirt or dust
- Vibrations
- Impact to the installed battery

Securing the Battery

1. Securing the Battery

Secure the battery to the cable, for example, using a cable tie.
We recommend using a cable tie tensioning tool.
Holding strength of the cable tie should be 11.6 to 44.2 N.



2. Protecting the Battery Connector Part

Protect the exposed part of the battery connector terminal with a heat shrink tube.



Replacing the Battery

When the battery voltage drops, Alarm No.21 (Encoder voltage drop) occurs. In this case, you need to replace the battery to a new one.

When replacing the battery, be sure to keep the control power (24 V) of the amplifier ON. Otherwise, you will lose the multi-turn data and need to perform homing again.



CAUTION



- Be careful not to connect the battery in the wrong way.
- Do not attempt to disassemble the battery.
- Do not short circuit the battery.
- Never attempt to charge the recommended battery.



Disposal of Batteries

Dispose of used batteries according to local government regulations.








1. Absolute System

4. Absolute Encoder Cable

Recommended Products

You can purchase recommended cables at the online shop of Misumi Corporation.

Making Your Own Cable

 CAUTION		
	Ensure correct wiring.	  
	Select a battery that meets the specifications of the recommended one. Replace the battery at a reasonable interval, taking the battery life into consideration.	

The connectors and cables needed to make your own cable are user-supplied.

 **B-2** Mounting and Wiring

2. Technical Information

1. Absolute System

5. Initializing Absolute Encoder

When using an absolute system for the first time or using it after replacing the motor, you need to initialize the encoder.

Use the Encoder Clear function by using S-TUNE II to initialize the encoder. And then restart your amplifier.

Only multi-turn data will be initialized and single-turn absolute data will not.




Initialize the absolute encoder before performing homing.



1. Absolute System

Initializing Encoder with S-TUNE II



2. Technical Information

1. Absolute System

Initializing Encoder with S-TUNE II (continued)

Step 3B

1. Under the Alarms tab, check the following alarms that are occurring.
No. 18 Encoder error (hardware)
No. 20 Encoder error (multi-turn data)
No. 21 Encoder error (voltage drop)
2. Under the Auxiliary functions tab, select Encoder.
3. Click on Get Encoder Status.
4. Check one of the boxes.
5. Click **Clear encoder**.
Until checking the boxes, the encoder clear button does not work.
6. Click **Yes**.
7. Cycle the control power.

Confirm

Turn on the control power and start communicating with the amplifier by using S-TUNE II.

1. Under the Auxiliary functions tab, select Encoder.
2. Click on Show Encoder Status.
3. Verify that this value is 0.

If an alarm occurs

- ① Check the following.
 - Is the battery connected correctly ?
 - Is the battery voltage normal ?
 - Is the encoder cable connected correctly ?
 - Are the wiring and connections all correct ?
- ② Repeat Step 3.

↓
END

1. Absolute System

6. Obtaining Absolute Data



Start S-TUNE II and start communicating with the amplifier.

Use the [Status monitor] tab.

1. Display the Status monitor view.

2. Select Encoder/Rotor mechanical angle (integrated value)

Encoder mechanical angle (integrated value) ... **A**
(=Absolute data)

3. Set the sampling cycle, and then click **Start recording**.

Data capture continues until you click **Stop recording**.

Use the [Auxiliary functions] tab.

1. Under the Auxiliary functions tab, select Encoder.

2. Click on **Get encoder state**.

3. Encoder data is displayed.

Encoder mechanical angle (1 rotation) ... **B**

Encoder Multi-turn data ... **C**

The formula to calculate the absolute data

Below is the formula to derive absolute data (Encoder mechanical angle (integrated value)).

$$\text{A} = \text{B} + \text{C} \times (\text{Encoder Resolution})$$

A: Encoder mechanical angle (integrated value)
(=Absolute data)



B: Encoder mechanical angle (1 rotation)

C: Encoder Multi-turn data

1. Absolute System

By using S-TUNE II, you can check alarms that has occurred when using an absolute system. These alarms cannot be cleared by Alarm Reset or cycling the control power. To reset alarms, execute ENCODER CLEAR at the Auxiliary functions tab, and then cycle the control power.

1. Click on the Alarms tab.
2. Check the alarms that are occurring.



Alarm No.	Alarm Description	Symptoms and Remedy
11	Multi-turn counter error	<ul style="list-style-type: none"> • Multi-turn data of the encoder has exceeded the specification. • Check the setting of Absolute system (No.257.0). • Verify that rotational data is no higher than 32,767 rotations.
18	Encoder error (Hardware)	<ul style="list-style-type: none"> • Anomaly of the encoder itself. • Check the alarm details.
20	Encoder error (Multi-turn data)	<ul style="list-style-type: none"> • Multi-turn data being reset. • Check for the encoder cable connection problems such as poor pin contact. • Take noise countermeasures. For example, separate the motor power cable from the encoder cable.
21	Encoder error (Voltage drop)	<ul style="list-style-type: none"> • Multi-turn data being reset due to low battery voltage. • Check for low battery voltage and loose connection of the battery cable. • Initialize the encoder.

1. Absolute System

Encoder Alarms


Use S-TUNE II to check alarms from the encoder. In case of Alarm No.18, No.20, or No.21, you can check the details under the Auxiliary Functions tab in S-TUNE II.

These alarms cannot be cleared by Alarm Reset or cycle the control power. To reset alarms, execute ENCODER CLEAR, and then cycle the control power.

If cycling power does not solve the problem, please contact our distributor.

1. Click on the Auxiliary Functions Tab.

2. Check alarms that are occurring.



No.	Name	Description of Symptom
0	Overvelocity error	Multi-turn sensor error occurred during backup, or overvelocity error occurred upon the control power on.
1	Angle sensor output Amplitude error	Abnormal amplitude of Angle sensor output amplitude.
2	Multi-turn ABS sensor communication error	Could not obtain multi-turn data during upon the control power on.
3	Position error	The single-turn sensor value and multi-turn sensor value do not agree because of faulty sensor; the encoder position data is unreliable.
4	Voltage drop error	Relevant only to absolute encoders. The supply voltage fell below the rated voltage range upon the control power OFF.
5	EEPROM error	The saved data in EEPROM is unreliable.
6	Overheat warning	The temperature of the encoder board exceeded the user-specified temperature.

Encoder battery voltage drop warning (Warning No.901 E9 0.1)

The Setup panel displays a warning when the battery voltage falls below the parameter No.268.0 setting value.

This warning isn't show to **[Auxiliary functions]** tab but is shown to **[Alarm]** tab of S-TUNE II.

The battery voltage is checked at the time of power turning on and every time interval. hour afterwards.

- 17bit ... Every one hour
- 23bit ... Every one second

2. Technical Information

2. Function

1. Emergency Stop

When you open User I/O E-STOP, Emergency Stop Status becomes ON.


Servo-OFF triggers deceleration stop and motor motion stops.

No alarm is output. A warning is output by parameter settings. Close E-STOP to cancel Emergency Stop Status to resume motor operation.

The emergency stop function is always enabled regardless parameter settings; however, you need to set related parameters so that a warning is output upon Emergency Stop Status ON.

Deceleration Stop Setup

When you turn Servo status OFF while operating the motor, the motor makes a deceleration stop according to the method predetermined by parameters.



3. Amplifier Circuit System Block Diagram

1. Amplifier Circuit System Block Diagram



3. Amplifier Circuit System Block Diagram

Amplifier

Motor rated
output power

50 W

100 W

200 W

400 W

750 W


850 W

1 kW

1.3 kW

1.5 kW

2 kW



*) When having single-phase power wired to a 1 kW amplifier (DB64A11), wire the main power AC200 V between the L1 and L3 terminals of the amplifier.

3. Amplifier Circuit System Block Diagram

Amplifier

Motor rated
output power

50 W

100 W

200 W

400 W

750 W


850 W

1 kW

1.3 kW

1.5 kW

2 kW



2. Technical Information

4. Status Display

1. Introduction

You can check status data by using S-TUNE II.

Note

This manual uses the following two types of pulse units to explain status variables.

Unit of **E-pulse** (= Encoder pulse)

This unit is pulse count of the amplifier control block, based on the pulses equivalent to single turn of the motor which is 23-bit (or 17-bit). It is a pulse value resulting from division/ multiplication in the amplifier.

Unit of **C-pulse** (= Command pulse)

This unit is based on pulse count corresponding to single turn of the motor in the host controller's perspective. This is a pre-division/multiplication value.

4. Status Display

2. List of Status Variables

Status Variables of Servo Amplifier

Status No.	Status Variable	Units	Refer to
16	I/O Status	—	P. 19
24	Control Component Temperature	°C	P. 19
64	Positioning Status	—	P. 20
65	Internal Command Value	E-pulse	P. 20
67	Position Feedback	E-pulse	P. 20
69	Position Deviation	E-pulse	P. 20
74	ABS Position Command	C-pulse	P. 21
76	Absolute Position Feedback	C-pulse	P. 21
78	Command Position Deviation	C-pulse	P. 21
80	ABS Position Deviation	C-pulse	P. 21
97	Speed Command Value	r/min	P. 21
98	Speed Feedback	r/min	P. 22
99	Speed Deviation	r/min	P. 22
113	Torque Command Value	0.1%	P. 22
131	Load Factor	digit	P. 23
132	Load Factor(%)	%	P. 23
194	Encoder/Rotor mechanical angle (single-turn value)	E-pulse	P. 23
195	Encoder/Rotor mechanical angle (integrated value)	E-pulse	P. 23
205	Encoder Temperature	°C	P. 24
206	Encoder Battery Voltage	0.1 V	P. 24
216	Encoder Communication Retry Count	times	P. 24
218	Encoder Data Error Count	times	P. 24
228	Regeneration Status	—	P. 25
232	Primary Circuit Power Supply Voltage	0.1 V	P. 25
371	Inertia Ratio Estimate	%	P. 25

Status Variables of EtherCAT Communication Objects

Status No.	Status Variable	Units	Refer to
2064	Target Position	C-pulse	P. 26
2074	Position actual value	C-pulse	P. 26
2080	Target Velocity	C-pulse/s	P. 26
2090	Velocity actual value	C-pulse/s	P. 26
2096	Target Torque	0.1%	P. 26
2098	Torque actual value	0.1%	P. 26


2. Technical Information

4. Status Display

3. Details of Each Status Variable

Status	I/O Status	Units
Status No.	16	—
Description	<p>This item indicated the I/O Status of the CN1 connector.</p> <p>You can check the I/O Status under 【waveform monitor】 and 【status monitor】 in S-TUNE II .</p> <p>【waveform monitor】 displays total value of I/O bits in decimal.</p> <p>【status monitor】 displays I/O bits in binary.</p>	

Bit Tables



Status	Control Component Temperature	Units
Status No.	24	℃
Description	<p>Indicates the temperature at the amplifier control block.</p> <p>Install the amplifier in a place where the temperature at the control block will not exceed 85℃.</p>	

4. Status Display

Status	Positioning Status	Units
Status No.	64	—
Description	Indicates whether positioning is completed or not 0: Not completed 1: Completed	

Status	Internal Command Value	Units
Status No.	65	E-pulse
Description	Indicates the command value being input to the positioning loop. This is a value of the position command input divided/multiplied and smoothed.	

Status	Position Feedback	Units
Status No.	67	E-pulse
Description	Indicates the position data of the motor returned from the encoder to the amplifier.	

Status	Position Deviation	Units
Status No.	69	E-pulse
Description	<p>Indicates deviation between the position command and position feedback.</p> <p>This value is important for tuning in position control mode, enabling you to do the following: To check the positioning time—for the position deviation to settle into your desired range after the position command became 0—and vibration. To adjust gains such that the positioning time will be shorter and vibration will be suppressed, so the specifications for the equipment will be satisfied</p> <p>To check resonant frequency, in case of equipment vibration, by using waveforms of position deviation or torque limit value. To see whether vibration was suppressed by checking waveforms after specifying the vibration frequency for the following position command filters.</p> <ul style="list-style-type: none"> · Filter 1 (Smoothing filter 1) Moving average counter (No.80.0) · Filter 4 (Smoothing filter 2) Moving average counter (No.81.0) 	

2. Technical Information

4. Status Display

Status	ABS Position Command	Units
Status No.	74	C-pulse
Description	This indicates a position command value based on the home-position offset.	

Status	Absolute Position Feedback	Units
Status No.	76	C-pulse
Description	Indicates the absolute position data returned from the encoder to the amplifier.	

Status	Command Position Deviation	Units
Status No.	78	C-pulse
Description	Indicates the deviation between a position command value and the feedbacked position value.	

Status	ABS Position Deviation	Units
Status No.	80	C-pulse
Description	Indicates the deviation between a value of ABS Position Command (Status No.74) and the value of ABS Positioning Feedback (Status No.76).	

Status	Velocity Command Value	Units
Status No.	97	r/min
Description	<p>Indicates the velocity command value.</p> <p>While tuning, by measuring this value (waveform data displayed in S-TUNE II) and position deviation (or speed deviation) at the same time, you can check command response with positioning time and vibration.</p> <p>Verify that no commands with extremely short acceleration/deceleration time are input from the host controller.</p> <p>If a command's acceleration/deceleration time is too short, the motor will be unable to keep up and vibration will easily occur.</p> <p>If you want to set a short acceleration/deceleration time, use a position command smoothing filter.</p>	

4. Status Display

Status	Speed Feedback	Units
Status No.	98	r/min
Description	Indicates the speed value returned from the encoder to the amplifier. With this, you can check command response and motor rotational speed.	

Status	Speed Deviation	Units
Status No.	99	r/min
Description	<p>Deviation between the speed command and the speed feedback.</p> <p>This item is used in Velocity Control Mode. With this, you can check the deviation during acceleration/deceleration, and adjust gains so that the value becomes within the desired range for the equipment.</p> <p>If the speed deviation is too large, make the adjustment with Control Gain 1 first, then Integral Gain next.</p> <p>This item is a reference value In Position Control Mode</p>	

Status	Torque Command Value	Units
Status No.	113	0.1 %
Description	<p>Indicates the value of torque command. The value of 1,000 equals to the rated torque.</p> <p>You can check the torque range during acceleration time and compare to the rated torque and the instantaneous maximum torque.</p> <ul style="list-style-type: none"> • RMS torque: Keep this below the rated torque. • Instantaneous torque: Use the motor such that this will be approximately 80% of instantaneous peak torque. <p>When the RMS torque command value reaches the instantaneous max torque value (that is, torque saturation), the torque output will be limited and an alarm will occur after the predetermined time will have elapsed.</p> <p>Torque saturation causes slow response. Take countermeasures.</p> <p>For example,</p> <ol style="list-style-type: none"> ① Set Position command filter. <ul style="list-style-type: none"> • Filter 1 (Smoothing filter 1) Moving average counter (No.80.0) • Filter 4 (Smoothing filter 2) Moving average counter (No.81.0) ② Smooth acceleration/deceleration of the command output from the host controller. ③ Install a speed reducer to decrease the inertia ratio. ④ Select a new motor to increase the rotor inertia or increase the capacity to decrease the inertia ratio. 	

2. Technical Information

4. Status Display

Status	Load Factor	Units
Status No.	131	digit
Description	<p>Indicates the motor load factor. The value of 1,000 is equivalent to 100% of the rated load. This item becoming 1,440 (120%) is an indicator of overload. Adjust the operating conditions such that this value remains under 1,000. Calculation formula: Motor load factor% = $\sqrt{\text{Load factor digit} \times 10}$</p>	

Status	Load Factor (%)	Units
Status No.	132	%
Description	The motor load factor is presented in%. (S-TUNE II only)	

Status	Encoder/rotor mechanical angle (single-turn value)	Units
Status No.	194	E-pulse
Description	<p>Indicates single-turn data of the motor. This value is an absolute value.</p>	

Status	Encoder/rotor mechanical angle (integrated value)	Units
Status No.	195	E-pulse
Description	<p>This indicates multi-turn data of the motor. It is presented as a total of encoder feedback pulses. (Single-turn value) + (Encoder resolution × Encoder Multi-turn data)</p> <p>This item is the absolute data if you are using an absolute encoder.</p>	

4. Status Display

Status	Encoder temperature	Units
Status No.	205	℃
Description	Indicates the encoder internal temperature. (for reference only)	


Status	Encoder battery voltage	Units
Status No.	206	0.1 V
Description	Indicates the voltage of the encoder backup battery.	

Status	Encoder communication retry times	Units
Status No.	216	times
Description	Indicates the communication retry count upon encoder communication error.	


Status	Encoder Data Error Counter	Units
Status No.	218	times
Description	Indicates the cumulative count of errors in receiving encoder data.	

2. Technical Information

4. Status Display

Status	Regeneration Status	Units
Status No.	228	—
Description	<p>This item indicates the regeneration status of the amplifier power circuit.</p> <p><u>Setup Panel</u></p> <p> C- 1 Setup Panel</p> <p><u>S-TUNE II</u></p> <p>【waveform monitor】 displays total value of I/O bits in decimal. 【status monitor】 displays I/O bits in binary.</p>	

Bit Tables



bit	Name and Meaning
0	Regeneration control output Indicates the operation status of the regenerative power processing circuit.
8	Regeneration voltage warning Indicates the primary circuit power voltage has reached the warning level. You need to connect a regenerative resistor to the amplifier.
9	Regeneration voltage threshold Indicates the primary circuit power voltage has reached the threshold. A power error, alarm No.14 or No.15 , will occur if the regenerative resistor is not connected.

Status	Primary Circuit Power Voltage	Units
Status No.	232	0.1 V
Description	Indicates the primary circuit power voltage (for reference only).	

Status	Inertia Ratio Estimate	Units
Status No.	371	—
Description	This item indicates the inertia ratio value estimated in auto turning.	

4. Status Display

Status	Target Position	Units
Status No.	2064	C-pulse
Description	Set the position command value.	

Status	Position actual value	Units
Status No.	2074	C-pulse
Description	Displays the actual position of the motor.	

Status	Target Velocity	Units
Status No.	2080	C-pulse/s
Description	Sets the velocity command.	

Status	Velocity actual value	Units
Status No.	2090	C-pulse/s
Description	Displays the actual velocity of the motor.	

Status	Target Torque	Units
Status No.	2096	0.1%
Description	Sets the torque command value.	

Status	Torque actual value	Units
Status No.	2098	0.1%
Description	Displays the actual torque value.	

[illegible]

